



at&t

User's manual

**TL92271/TL92371/TL92471**  
**DECT 6.0 cordless telephone/**  
**answering system with**  
**BLUETOOTH® wireless technology**



# Congratulations

on purchasing your new AT&T product. Before using this AT&T product, please read **Important safety information** on pages 110-111 of this user's manual. Please thoroughly read the user's manual for all the feature operations and troubleshooting information you need to install and operate your new AT&T product. You can also visit our website at **www.telephones.att.com** or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.

Model number: TL92271 (two handsets)  
TL92371 (three handsets)  
TL92471 (four handsets)

Type: DECT 6.0 cordless telephone/answering system  
with Bluetooth wireless technology

Serial number: \_\_\_\_\_

Purchase date: \_\_\_\_\_

Place of purchase: \_\_\_\_\_

Both the model and serial number of your AT&T product can be found on the bottom of the telephone base.



Telephones identified with this logo have reduced noise and interference when used with most T-coil equipped hearing aids and cochlear implants. The TIA-1083 Compliant Logo is a trademark of the Telecommunications Industry Association. Used under license.




The ENERGY STAR® program ([www.energystar.gov](http://www.energystar.gov)) recognizes and encourages the use of products that save energy and help protect our environment. We are proud to mark this product with the ENERGY STAR® label indicating it meets the latest energy efficiency guidelines.

The *Bluetooth*® word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by Advanced American Telephones and its parent, VTech Holdings Limited, is under license. VTech Holdings Limited is a member of Bluetooth SIG, Inc. Other trademarks and trade names are those of their respective owners.


© 2011 Advanced American Telephones. All Rights Reserved. AT&T and the AT&T logo are trademarks of AT&T Intellectual Property licensed to Advanced American Telephones, San Antonio, TX 78219. Printed in China.

# Parts checklist

Your telephone package contains the following items. Save your sales receipt and original packaging in the event warranty service is necessary.




User's manual




Quick start guide



Cordless handsets  
(2 for TL92271)  
(3 for TL92371)  
(4 for TL92471)




Charger for cordless handset with power adapter installed  
(1 for TL92271)  
(2 for TL92371)  
(3 for TL92471)



Wall mount bracket



Power adapter for telephone base



Telephone line cord



Battery compartment covers  
(2 for TL92271)  
(3 for TL92371)  
(4 for TL92471)



Batteries for cordless handsets  
(2 for TL92271)  
(3 for TL92371)  
(4 for TL92471)



Telephone base

# TL92271/TL92371/TL92471 DECT 6.0 cordless telephone/ answering system with BLUETOOTH® wireless technology



## Table of contents

### Getting started

Quick reference guide - telephone base.....	1
Quick reference guide - handset.....	2
Installation.....	5
Telephone base installation.....	6
Charger installation.....	7
Battery installation and charging.....	8
Battery charging.....	9
Installation options.....	10
Tabletop to wall mount installation.....	10
Wall mount to tabletop installation.....	11

### Bluetooth

Introducing Bluetooth.....	12
Glossary of terms.....	13
Bluetooth setup.....	14
Add a cell phone.....	14
Add a headset.....	16
Auto connection.....	17
Device list and connection.....	18
Review the active device list.....	18
Connect/disconnect an active device.....	18
Remove a device.....	19
Rename a device.....	20
Replace an active device.....	21
Bluetooth connection from idle mode.....	21
Download directory.....	22
Interruption to directory download.....	24

View the directory download information.....	24
Change PIN.....	25

### Telephone settings

Handset settings.....	26
Ringers.....	26
Ringer volume.....	26
Ringer tone.....	27
Set date and time.....	28
Settings.....	29
LCD language.....	29
Display alerts.....	30
Missed call indicator.....	30
Voicemail indicator.....	31
No line.....	32
Download fail.....	32
Use caller ID to automatically set date and time.....	33
Rename handset.....	33
Key tone.....	34
Dial mode.....	34
Caller ID announce.....	35
Website.....	35
Home area code.....	36
Cell area code.....	37
Telephone settings.....	38
Telephone base ringer volume.....	38
Answering system settings.....	38

### Telephone operation

Making, answering and ending a call.....	39
Using a handset for home calls.....	39

# Table of contents

Using a Bluetooth headset for home calls.....	39
Call waiting on the home line .....	40
Make, answer or end a cell call .....	41
Call waiting on the cell line.....	41
Answer a cell call while on a home call.....	42
Cell phone voicemail.....	42
Answer a home call while on a cell call.....	42
Conference calls.....	43
Conference home and cell calls .....	43
Options while on calls.....	44
Handset speakerphone.....	44
Volume control .....	44
Silencing the ringer.....	44
Mute.....	44
Temporary tone dialing .....	45
Hold.....	45
Equalizer.....	45
Chain dialing.....	46
Transfer a call.....	47
Redial.....	48
Review the redial list.....	48
Dial a redial entry.....	48
Save a redial entry to the directory.....	49
Delete a redial entry.....	49
<b>Multiple handset use</b>	
Multiple handset use .....	50
Handset locator.....	50
Join a call in progress.....	50
Intercom.....	51
Answer an incoming call during an intercom call.....	52
Call transfer using intercom.....	53
Push-to-talk (PTT) .....	54
PTT on/off.....	54
PTT to a single handset.....	55
PTT to a group of handsets.....	56
Answer a PTT call.....	57

Change a one-to-one PTT call to an intercom call .....	57
End a PTT call.....	58
Answer an incoming call during PTT .....	58
Make an outgoing call during PTT .....	58

## Directory

About the directory.....	59
Create and review entries.....	60
Create a new entry in the home directory.....	60
To add a predialed telephone number to the directory.....	62
Review the directory.....	63
3-character alphabetical search.....	63
Dial, edit or delete a directory .....	64
Dial a directory entry.....	64
Edit a directory entry.....	64
Edit the type of a directory entry.....	65
Delete a directory entry.....	65
Remove a downloaded directory.....	65
Speed Dial.....	66
Assign a speed dial slot.....	66
Reassign a speed dial slot.....	66
Dial a speed dial entry.....	66
Delete a speed dial entry.....	67

## Caller ID

About caller ID .....	68
Information about caller ID with call waiting .....	68
Caller ID operation.....	69
How the caller ID history (caller ID log) works.....	69
Memory match.....	69
To review the caller ID log .....	70
View dialing options.....	71
Dial a caller ID log entry .....	71
Save a caller ID log entry to the directory.....	72

# Table of contents

To delete a single entry .....	73	Telephone base indicator	
To delete all entries .....	73	lights .....	90
Reasons for missing caller ID		Screen messages .....	91
information .....	73	Display screen messages .....	91
<b>Answering system</b>		Expand your telephone system .....	94
Answering system settings .....	74	Add and register a handset	
Answer on/off .....	74	(optional) .....	94
Announcement .....	75	Deregister handsets .....	95
Play your announcement .....	75	Troubleshooting .....	96
Record your own		Maintenance .....	109
announcement .....	75	Important safety information .....	110
Delete your announcement .....	76	Especially about cordless	
Call screening .....	77	telephones .....	110
Number of rings .....	78	Precautions for users of	
Remote access code .....	79	implanted cardiac pacemakers .....	111
Message alert tone .....	79	Pacemaker patients .....	111
Recording time .....	80	Especially about telephone	
About the answering system .....	81	answering systems .....	111
Answering system and		FCC Part 68 and ACTA .....	112
voicemail .....	81	FCC Part 15 .....	113
Using the answering system and		Limited warranty .....	114
voicemail together .....	81	Technical specifications .....	116
Message capacity .....	82	DECT 6.0 digital technology .....	116
Voice prompts .....	82	Telephone operating range .....	116
Call screening .....	82	Extended range and clarity .....	116
Call intercept .....	82	HD audio .....	116
Temporarily turning off the		<b>Index .....</b>	<b>117</b>
message alert tone .....	83		
Message playback .....	84		
Delete all old messages .....	86		
Record and play memos .....	86		
Base message counter displays .....	87		
Message window displays .....	87		
Remote access .....	88		
To remotely access the			
answering system .....	88		
Remote commands .....	88		
<b>Appendix</b>			
Handset screen icons .....	89		
Alert tones and lights .....	90		
Handset alert tones .....	90		
Telephone base alert tones .....	90		
Handset indicator lights .....	90		

# Quick reference guide - telephone base

## **⏻/ANS ON**

Press to turn the answering system on or off (page 74).

## **📶/HANDSET LOCATOR**

Press to page all system handsets (page 50).  
Press and hold to begin handset deregistration (page 95).

## **🔄/REPEAT**

Press to repeat a message or press twice to play the previous message (page 84).

## **▶/■/PLAY/STOP**


Press to play messages (page 84).  
Press to stop message playback (page 84).

## **X/DELETE**

Press to delete the message currently playing (page 84).  
When the phone is not in use, press twice to delete all previously reviewed messages (page 86).

## **▶▶/SKIP**

Press to skip to the next message (page 84).



## **Message counter**

Number of messages (or during playback, message number currently playing).

## **IN USE light**

On when the handset is in use, when the answering system is answering an incoming call, or when you are registering a handset.

Flashes when another telephone is in use on the same line, or when you are deregistering handsets from the telephone base.

Flashes quickly when there is an incoming home call.



## **DEVICE1/DEVICE2 lights**

On when the telephone base is paired and connected with a Bluetooth device.


Flash alternately while pairing with a Bluetooth device.

Flashes quickly when there is an incoming cell call.

## **▼ VOLUME ▲**

Press to adjust the volume during message playback (page 84).

When the phone is not in use, press to adjust the telephone base ringer volume (page 38).



# Getting started

## Quick reference guide - handset

### **CHARGE** light

On when the handset is charging in the telephone base or charger.

### **Softkeys (2)**

Press to select a menu item displayed above the key.

While in a menu, press to select an item or save an entry or setting.

### **CELLULAR**

Press to make or answer a cell call (page 41).

During a cell call, press to answer an incoming call when you hear a call waiting alert (page 41).

Flashes quickly when there is an incoming cell call.

Flashes slowly when a cell call is on hold.

### **HOME/FLASH**

Press to make or answer a home call (page 39).

During a home call, press to answer an incoming call when you hear a call waiting alert (page 40).

Flashes quickly when there is an incoming home call or when the answering system is recording a call.

Flashes slowly when a home call is on hold.

### **1**

While reviewing a caller ID history entry, press repeatedly to add or remove **1** in front of the telephone number before dialing or saving it in a directory (page 71).

### **TONE X**

Press to switch to tone dialing temporarily during a call if you have pulse service (page 45).

Press to toggle the name order when saving a caller ID log entry into directory (page 72).

### **SPEAKER**

Press to make or answer a home or cell call using the speakerphone.


Press to turn on the handset speakerphone.

Press again to resume normal handset use (page 44).

### **REDIAL/PAUSE**

Press repeatedly to view the last 10 numbers dialed (page 48).

While entering numbers, press and hold to insert a dialing pause (page 60).



# Quick reference guide - handset



## DIR▲/VOLUME

Press to scroll up while in menus.  
During a call or message playback, press to increase the listening volume (page 44 and page 85).  
Press to show directory entries when the telephone is not in use (page 63).  
While entering names or numbers in the directory, press to move the cursor to the left (page 60).

## MUTE/DELETE

During a call, press to mute the microphone (page 44).  
While predialing, press to delete digits (page 39).  
While reviewing the redial list, directory or caller ID history, press to delete an individual entry (pages 49, 65 and 73).  
While entering or editing a directory entry, press to erase a digit or character.  
While the handset is ringing, press to silence the ringer temporarily (page 44).  
During message or announcement playback, press to delete a message or announcement (page 85 or page 76).

## OFF/CANCEL

While using menus, press to cancel an operation, back up to the previous menu, or exit the menu display (page 4).  
Press and hold to return to idle mode.  
During a call, press to hang up (page 39).  
Press and hold while the telephone is not in use to erase the displayed messages (**XX Missed calls** and **Download fail**) (page 30 and page 32).  
While the handset is ringing, press to silence the ringer temporarily (page 44).

## CID▼/VOLUME

Press to scroll down while in menus.  
During a call or message playback, press to decrease the listening volume (page 44 and page 85).  
Press to show the caller ID history when the telephone is not in use (page 70).  
While entering names or numbers in the directory, press to move the cursor to the right (page 60).

## # (pound key)

Press repeatedly to display other dialing options when reviewing a caller ID history entry (page 71).

## EQ

During an outside call, intercom call, message or announcement playback, press to change the quality of the audio to best suit your hearing (page 45).



### PUSH TO TALK

Press to begin a one-to-one or one-to-group broadcast.

Press and hold to begin a one-to-group broadcast when the handset is not in use.

### Main menu

The selected menu item is highlighted.



### Feature menu

Play messages (page 85)

Answering sys (page 74)

Directory (page 59)

Caller ID log (page 68)

Intercom (page 51)

Bluetooth (page 12)

Ringers (page 26)

Set date/time (page 28)

Settings (page 29)

Website (page 36)

### Using menus

1. Press **MENU** in idle mode (when the telephone is not in use) to enter the main menu.
2. Use **CID** or **DIR** to scroll through menu items.
3. Press **SELECT** to select or save the highlighted item.  
**-OR-**  
Press **OFF/CANCEL** to cancel an operation, back up to the previous menu, or exit the menu display.  
**-OR-**  
Press and hold **OFF/CANCEL** to return to idle mode.

**i** **NOTE:** If no key is pressed, the handset automatically returns to idle mode after 30 seconds.

You must install and charge the handset battery before using the cordless handset.



See pages 8-9 for easy instructions.

Install the telephone base close to a telephone jack and a power outlet not controlled by a wall switch. The telephone base can be placed on a flat surface or vertically mounted on the wall (page 10). For optimum range and better reception, place the telephone base in a central and open location.

You may hear interference if your cellular phone is too close to the telephone base during a **CELLULAR** call. Make sure that your Bluetooth enabled cellular phone is within 15 feet of the telephone base in order to maintain a clear and consistent connection between your Bluetooth cell phone, telephone base and cell tower.

If you subscribe to high-speed Internet service (digital subscriber line - DSL) through your telephone line, you must install a DSL filter between the telephone line cord and the telephone wall jack (page 6). The filter prevents noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters.

Your product may be shipped with a protective sticker covering the handset or telephone base display - remove it before use.

For customer service or product information, visit our website at **[www.telephones.att.com](http://www.telephones.att.com)** or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.

#### **Avoid placing the telephone base too close to:**

- Communication devices such as television sets, VCRs, or other cordless telephones.
- Excessive heat sources.
- Noise sources such as a window with traffic outside, motors, microwave ovens, refrigerators, or fluorescent lighting.
- Excessive dust sources such as a workshop or garage.
- Excessive moisture.
- Extremely low temperature.
- Mechanical vibration or shock such as on top of washing machine or work bench.


# Telephone base installation

If you subscribe to high-speed Internet service (digital subscriber line - DSL) through your telephone line, you must install a DSL filter between the telephone line cord and the telephone wall jack. The filter prevents noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters.


Follow the steps below to install the telephone.

**NOTE:** The telephone base comes ready for tabletop use. If you want to mount your telephone on a wall, refer to **Installation options** on pages 10-11 for details.

- Plug the large end of the larger power adapter into an electrical outlet not controlled by a wall switch.
- Plug one end of the telephone line cord into a telephone wall jack.



## Charger installation



### IMPORTANT INFORMATION:

1. Use only the power adapter(s) provided with this product. To obtain a replacement, visit our website at [www.telephones.att.com](http://www.telephones.att.com) or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.
2. The power adapters are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.

# Battery installation and charging

Install the battery as shown below.



## Step 1

Plug the battery connector securely into the socket inside the handset battery compartment, matching the color-coded label. Insert the supplied battery with the label **THIS SIDE UP** facing up as indicated.



## Step 2

Align the cover flat against the battery compartment, then slide it upwards until it clicks into place.

## CHARGE light



## Step 3

Charge the handset by placing it face up in the telephone base or charger. The **CHARGE** light is on when charging.

After you install your telephone or power returns following a power outage, the handset will prompt you to set the date and time. For instructions, see **Set date and time** on page 28. To skip setting the date and time, press **OFF/CANCEL** or **BACK**.



To replace the battery, press the tab and slide the battery compartment cover downwards. Lift out the old battery and disconnect it from the handset. Follow the instructions above to install and charge the new battery.



## IMPORTANT INFORMATION:

- Use only the supplied rechargeable battery or replacement battery (model BT166342).


To order, visit our website at **www.telephones.att.com** or call

**1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.



- If you do not use the handset for a long time, disconnect and remove the battery to prevent possible leakage.


## Battery charging

Once you have installed the battery, the screen indicates the battery status (see table below). If necessary, place the handset in the telephone base or charger to charge the battery. For best performance, keep the handset in the telephone base or charger when not in use. The battery is fully charged after 16 hours of continuous charging. See the table on page 116 for battery operating times.

If the screen is blank, you need to charge the handset without interruption for at least 30 minutes to give the handset enough charge to use the telephone for a short time. When the battery is low, the handset shows **Low battery** and a flashing . If you are on a call in low battery mode, the handset beeps every minute.

The following table summarizes the battery charge indicators and actions to take.

Battery indicators	Battery status	Action
The screen is blank or shows <b>Place in charger</b> and  flashes.	The battery has no or very little charge. The handset cannot be used.	Charge without interruption (at least 30 minutes).
The screen shows <b>Low battery</b> and  flashes.	Battery has enough charge to be used for a short time.	Charge without interruption (at least 30 minutes).
The screen shows <b>HANDESET X.</b>	Battery is charged.	To keep the battery charged, place it in the telephone base or charger when not in use.

 **NOTE:** If you are on a phone call in low battery mode, you hear four short beeps every minute.


## Installation options

Your telephone base is ready for tabletop use. If you want to mount your telephone on a wall, use the provided wall mount bracket to attach to a standard dual-stud telephone wall mounting plate. If you do not have this wall mounting plate, you can purchase one from many hardware or consumer electronics retailers. You may need a professional to install the wall mounting plate.


### **Tabletop to wall mount installation**

---


1. With the upper tabs (marked **A**) on top, align the holes of the wall mount bracket with the studs on the standard wall mounting plate and slide the bracket down until it locks securely.



2. Plug one end of the telephone line cord into the jack on the bottom of the telephone base and plug the other end into the telephone wall jack (or DSL filter). Plug the small end of the telephone base power adapter into the jack on the bottom of the telephone base and plug the other end into an electrical outlet not controlled by a wall switch. Route the telephone line cord and the power cord through the grooves at the bottom of the telephone base accordingly.




3. Hold the cords to the side of the telephone base. Align the upper slots on the back of the telephone base just above the upper tabs (marked **A**) of the wall mount bracket. Make sure the lower slots of the telephone base are also aligned above the lower tabs (marked **B**) of the wall mount bracket. Push the telephone base down until it clicks securely in place.



## Installation options

4. Bundle the telephone line cord and power adapter cord neatly with twist ties. Place the bundled cords into the space behind the telephone base.




### **Wall mount to tabletop installation**

---

To change the telephone base from the wall mount position to tabletop position, follow the steps below.

1. If the telephone line cord and power adapter cord are bundled, untie them first. Push the wall mount bracket up to remove it from the wall.
2. Unplug the telephone line cord (or DSL filter) from the wall. Unplug the power adapter from the power outlet. Lift the telephone base up to detach it from the wall mount bracket.
3. See **Telephone base installation** on page 6.



## Introducing Bluetooth

Your new AT&T **TL92271/TL92371/TL92471** telephone system with Bluetooth wireless technology has the following features:

- Pair up to 4 Bluetooth enabled devices (cell phones or headsets) with the telephone base.
- Connect a maximum of 2 cell phones to make and receive cell calls. Only one cell phone can be active on a call at a time.
- Connect a Bluetooth enabled headset for making and receiving home calls.
- Conference cell and home calls.
- Make and receive calls using your cell phone plan with your cordless system handsets.

### **IMPORTANT INFORMATION**

- After plugging in the telephone base, wait at least 20 seconds before connecting a Bluetooth device. The screen shows **Bluetooth system busy** if you try to connect too soon.
- Refer to the user's manual of your Bluetooth enabled cell phone or headset for more information about how that device uses Bluetooth connectivity.
- Bluetooth wireless technology operates within a short range (up to 30 feet) from the telephone base. Keep connected cell phones and headsets within this range.
- If your cell phone has poor reception in your home, the **TL92271/TL92371/TL92471** cannot improve the reception. However, if you have a location in your house with better reception, you can leave your cell phone in that location while you use the **TL92271/TL92371/TL92471** cell line. In order for this to work, the cell phone must be within 15 feet of the telephone base for optimal performance.
- Charge your cell phone while it is connected to the telephone base. Your cell phone's battery discharges faster while it is connected to the telephone base via Bluetooth wireless technology.
- Monitor your cell phone's usage, because minutes may be deducted from your cellular plan for the duration of all cell calls, depending on the terms of your plan.

Refer to the **Bluetooth setup** section (pages 14-25) to learn how to set up your Bluetooth device. Refer to the **Telephone operation** section (page 39) on how to operate your Bluetooth devices with your new **TL92271/TL92371/TL92471** AT&T telephone system with Bluetooth wireless technology. Refer to the **Troubleshooting** section (pages 96-108) if you experience difficulty when using the telephone system.


The *Bluetooth*® word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by Advanced American Telephones and its parent, VTech Holdings Limited, is under license. VTech Holdings Limited is a member of Bluetooth SIG, Inc. Other trademarks and trade names are those of their respective owners.


## Glossary of terms

Below are some terms used in this user's manual to help you become familiar with using your Bluetooth devices and your new AT&T telephone system.

**Active device slots** - the **Device list** has two active slots for two cell phones, or one cell phone and one headset. When a device in the list is active it will have a **D1:** or **D2:** in front of the device name. In order to use a Bluetooth device on a call, it must be in an active slot and be connected.

**Bluetooth cell phone** - refers to a mobile Bluetooth enabled cellular telephone.

**CELLULAR** line - the telephone line associated with your cell phone service. On your **TL92271/TL92371/TL92471** handset, press  **CELLULAR** to use the cell line.

**Connected** - when you pair a Bluetooth device to the **TL92271/TL92371/TL92471** it is placed in an active slot and automatically connected. When a device is connected, a **1** and/or **2** will display after  on the handset screen and the **DEVICE 1** and/or **DEVICE 2** light on the telephone base will be on. If a device loses its connection to the telephone base, it must be reconnected before you can use the device with the **TL92271/TL92371/TL92471**.

**Disconnected** - when a device is disconnected, **1** and/or **2** displays after  on the handset screen and the **DEVICE 1** and/or **DEVICE 2** light on the telephone base is off.

**Discoverable mode** - before a Bluetooth enabled device can be paired, it must be set to this mode. When pairing your cell phone, the telephone base is in this mode. When pairing a headset, the headset must be set to this mode. Depending on the manufacturer, this mode is sometimes referred to as **Find Me** or **Visibility**.

**HOME** line - your conventional telephone land line. On your **TL92271/TL92371/TL92471** handset, press  **HOME/FLASH** to use the home line.

**Paired devices** - Bluetooth enabled devices (cell phone or headset) that have shared registration information with the telephone base. A total of four Bluetooth enabled devices can be paired with the telephone base. However, only two paired devices can be connected to the base at a time.

**Pairing** - sometimes refers to as **bonding**. The process of sharing registration information between two Bluetooth enabled devices. Your Bluetooth enabled cell phone or headset must first be paired to the telephone base in order to use it with this cordless phone system.

**PIN** - by default, the PIN is **0000** for the telephone base and for most Bluetooth devices. PIN information must be exchanged between Bluetooth devices before they can be used. This is also known as a **Passkey** or **Passcode**.

## Bluetooth setup

To use a Bluetooth enabled cellular phone with your telephone, you must first pair and connect your Bluetooth cellular phone with the telephone base. All **TL92271/TL92371/TL92471** handsets can be used to make or answer calls on the cell phone line.


Bluetooth wireless technology operates within a short range (up to 30 feet). When you pair a Bluetooth cell phone or Bluetooth headset to the telephone base, keep the device within 15 feet of the telephone base for optimal performance.

### Add a cell phone

Before you begin, make sure that you have cellular coverage and your Bluetooth enabled cell phone is not connected to any other Bluetooth device. Refer to your cell phone user's manual to learn how to search for or add new Bluetooth devices.



#### To pair and connect a cell phone:

1. Press **MENU** in idle mode to enter the main menu.
2. Press **CID** or **▲DIR** to highlight **Bluetooth**, then press **SELECT**.
3. Press **SELECT** to choose **Add device**.
4. Press **SELECT** again to choose **Add cellular**. The screen displays **Please wait...** followed by **1. If cell is connected to BT device, please disconnect it.**
  - If there are already 4 paired devices on the device list, the 4th device on the device list will be automatically removed, regardless of whether the new device pairing is successful or not.
  - If there are already 2 active devices on the device list with prefix **D1:** or **D2:**, the handset shows **Only 2 devices can be ready for connection.** You are prompted to deactivate an active device.
5. Press **NEXT**. The screen displays **2. Place cell phone next to base.**
  - All devices that are connected to the telephone base are disconnected until the pairing process is completed.
6. Press **NEXT** to turn on the telephone base discoverable mode. The screen displays **Set cell to search base: AT&T DECT 6.0 discoverable PIN: 0000**. Promptly turn on the Bluetooth feature of your cell phone and search for or add new devices.



## Bluetooth setup

7. Your cell phone may require a passcode. In this case the handset screen displays **Check cellular. ENTER PASS CODE**. Enter the cell phone passcode into the handset and press **SET** to save.
8. Enter the PIN of the telephone base (the default PIN is **0000**) into your cell phone to continue the pairing process. The handset displays **Adding Cell Phone A to device list...**
9. When a device is successfully connected, the handset displays **Cell Phone A is added and connected to base**. You hear a confirmation tone. The corresponding status icon (**1** or **2**) displays. The corresponding device light on the telephone base (**DEVICE 1** or **DEVICE 2**) turns on.



**If you have trouble pairing your cell phone, it may not be compatible with your TL92271/TL92371/TL92471. Check the Bluetooth compatibility list at [www.telephones.att.com](http://www.telephones.att.com).**

### **NOTES:**


- The pairing process may take up to one minute. If the pairing process fails, try again.
- If you put the handset back in the telephone base or charger while pairing, the process is cancelled and the handset returns to idle mode.
- If a device fails to connect, the handset displays **Cell Phone A is added into the device list**, and then displays **Please use cell to connect to base**.

## Add a headset

Before you begin, make sure that your Bluetooth enabled headset is not connected to any other Bluetooth device. Refer to your headset user's manual to learn how to search for or add new Bluetooth devices.

### To pair and connect a headset:


1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID**▼ or **▲DIR** to highlight **Bluetooth**, then press **SELECT**.
3. Press **SELECT** to choose **Add device**.
4. Press **CID**▼ or **▲DIR** to highlight **Add headset**, then press **SELECT**. The screen displays **Please wait...** followed by **If headset is connected to cell, please disconnect it.**
  - If there is another headset already active, the screen shows **Only 1 headset in device list can be ready for connection** and prompt you to replace an existing paired device (page 21).
  - When you already have 2 active devices, the handset shows **Only 2 devices can be ready for connection.** The telephone base will deactivate another headset from an active slot automatically.
5. Press **NEXT**. The screen displays **Pls set headset to discoverable mode.** Set your headset to discoverable mode (refer to the user's manual of your headset), then press **NEXT**.
  - All devices that are connected to the telephone base are temporarily disconnected.
6. The screen displays **Searching for Bluetooth headsets...**
7. When the screen displays the found devices, press **CID**▼ or **▲DIR** to highlight your headset and then press **SELECT**.
8. Enter the PIN of your headset. The PIN for most Bluetooth devices is **0000** (refer to the user's manual of your headset). Then press **NEXT**.



## Bluetooth setup

9. The screen displays **Adding Headset A to device list...** when the base is connecting to your headset.
10. When a device is successfully connected, the handset displays **Headset A is added and connected to base** and the corresponding status icon (📶1 or 📶2). You hear a confirmation tone. The corresponding light on the telephone base (**DEVICE 1** or **DEVICE 2**) turns on.

**If you have trouble pairing your headset, it may not be compatible with your TL92271/TL92371/TL92471. Check the Bluetooth compatibility list at [www.telephones.att.com](http://www.telephones.att.com).**



### **NOTES:**

- The pairing process may take up to one minute. If the pairing process fails, try again.
- If you put the handset back in the telephone base or charger while pairing, the process discontinues and the handset returns to idle mode.
- If a device fails to connect, the handset displays **Headset A is added into the device list**, and then displays **Please use headset to connect to base**.
- When a connected headset is charging, it may disconnect from the telephone base and the corresponding light on the telephone base (**DEVICE 1** or **DEVICE 2**) turns off. For some headset models, you may need to turn on the headset and reconnect it to the telephone base again.

### **Auto connection**

---

An active device may be disconnected from the telephone base when:

- The Bluetooth feature of your cell phone is turned off.
- The power of your device is turned off.
- Your Bluetooth device is not within range of the telephone base.

When the Bluetooth or power on the device is turned on or it moves within range of the base, the base will try to reconnect to the Bluetooth device. If you disconnect the device through the device list, the base will not attempt to reconnect unless your device is moved out of range and then goes back in range again.

# Bluetooth setup

## Device list and connection

Up to 4 devices can be paired to the telephone base. All paired devices are shown on the device list. To use a paired device, it must be connected and in an active slot (**DEVICE 1** or **DEVICE 2**) on the device list. Only one Bluetooth cell phone or a headset can be on a call at a time.

Once you have paired a device with the telephone base, you do not need to repeat the pairing procedure again unless you delete the device from the device list.

**i NOTE:** When connecting a Bluetooth device to the device list, all connected devices will be temporarily disconnected until the procedure is complete. It may take up to 2 minutes to reconnect.

## Review the active device list


1. Press **MENU** on the handset when it is not in use.
2. Press **CID** or **▲DIR** to highlight **Bluetooth**, then press **SELECT**.
3. Press **CID** or **▲DIR** to highlight **Device list**, then press **SELECT**.

## Connect/disconnect an active device

While in the active devices menu, you may connect or disconnect your active device.

1. Press **MENU** on the handset when it is not in use.
2. Press **CID** or **▲DIR** to highlight **Bluetooth**, then press **SELECT**.
3. Press **CID** or **▲DIR** to highlight **Device list**, then press **SELECT**.
4. Press **CID** or **▲DIR** to highlight a device, then press **OPTION**.
5. Press **CID** or **▲DIR** to highlight **Connect/Disconnect** (whichever is applicable), then press **SELECT** to confirm. The handset displays **Device connected/Device disconnected**. You hear a confirmation tone.

**i NOTE:** When your active device is connected, you are prompted to select **Disconnect**. When your active device is disconnected, you are prompted to select **Connect**.



# Bluetooth setup

## Remove a device


When you already have the maximum of 4 paired devices on the device list and you want to add another device, you must first delete a device from the device list.

### To remove a device:

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID▼** or **▲DIR** to highlight **Bluetooth**, then press **SELECT**.
3. Press **CID▼** or **▲DIR** to highlight **Device list**, then press **SELECT**.
4. Press **CID▼** or **▲DIR** to highlight a selected device, then press **MUTE/DELETE**.

**-OR-**

- Press **CID▼** or **▲DIR** to highlight a selected device, then press **OPTION**.
  - Press **CID▼** or **▲DIR** to highlight **Remove**, then press **SELECT**.
5. The handset displays **Remove Headset A?** Press **YES** to confirm. The handset displays **Device removed from device list**. You hear a confirmation tone.




## Rename a device

You can change the name of a paired device on the paired devices list.

1. Press **MENU** on the handset when it is not in use.
2. Press **CID▼** or **▲DIR** to highlight **Bluetooth**, then press **SELECT**.
3. Press **CID▼** or **▲DIR** to highlight **Device list**, then press **SELECT**.
4. Press **CID▼** or **▲DIR** to highlight a device when necessary, then press **OPTION**.
5. Press **CID▼** or **▲DIR** to highlight **Rename**, then press **SELECT**. The screen displays **ENTER NEW NAME**.
6. Use the dialing keys to edit the name (page 61).
  - Press **MUTE/DELETE** to erase a character.
  - Press and hold **MUTE/DELETE** to erase all characters.
  - Press **CID▼** or **▲DIR** to move the cursor to the right or left.
7. Press **SAVE**. The handset displays **Device renamed**. You hear a confirmation tone.

**i NOTE:** Only the first 11 characters of the device name are shown on the device list.





# Bluetooth setup

## Replace an active device

If you already have 2 active devices on the device list and you want to activate a different device, you must deactivate one of the two active devices.

### To replace an active device:

1. Press **MENU** on the handset when it is not in use.
2. Press **CID** or **DIR** to highlight **Bluetooth**, then press **SELECT**.
3. Press **CID** or **DIR** to highlight **Device list**, then press **SELECT**.
4. Press **CID** or **DIR** to highlight the device you want to activate, without a prefix **D1:** or **D2:**, then press **OPTION**.
5. Press **CID** or **DIR** to highlight **Connect**, then press **SELECT**. The handset displays **Only 2 devices can be ready for connection** and then a list of devices for deactivation.
6. Press **CID** or **DIR** to highlight the device to be deactivated, then press **NEXT**. The handset displays **Cell Phone A is deactivated** and you hear a confirmation tone. The screen then displays **Connecting Cell Phone B to the base...**
7. Depending on your cell phone settings, you may need to press a key on your cell phone to confirm the connection. When the new device is successfully activated and connected, the handset displays **Device connected**. You hear a confirmation tone.



## Bluetooth connection from idle mode

When you have active devices that are not connected, **CONNECT** appears on the idle handset. Press **CONNECT** to start connecting an active device. When there are two active devices, the handset will prompt you to choose one before connection.



# Bluetooth setup

## Download directory

You can download up to 4 cell phone directories (phonebooks) to your **TL92271/TL92371/TL92471** telephone system via Bluetooth wireless technology. Each downloaded directory can store up to 1,500 entries with up to 30 digits for each phone number and 15 characters for each name.

Before downloading a directory, make sure the cell phone is paired, active, and connected to your **TL92271/TL92371/TL92471**. Make sure the handset battery is charged for at least 30 minutes.

**Place your cell phone next to the telephone base when you download a cell phone directory to your TL92271/TL92371/TL92471.**

### To download a cell phone directory:

1. Press **MENU** on the handset when it is not in use.
2. Press **CID**▼ or **▲DIR** to highlight **Bluetooth**, then press **SELECT**.
3. Press **CID**▼ or **▲DIR** to highlight **Download dir**, then press **SELECT**.
  - If there is no cell phone paired to the system, the handset displays **Device list is empty**. Press **OK** to return to the Bluetooth menu.
4. Press **CID**▼ or **▲DIR** to select a desired device, then press **SELECT**.
  - If the selected device is active but disconnected, the handset displays **Cellular phone not connected**. Press **CONNECT**.
5. Press **CID**▼ or **▲DIR** to highlight one of the following options:
  - **Phone memory** - download all contacts stored in your phone memory.
  - **SIM card only** - download all contacts stored in your SIM card.
  - **Phone and SIM** - download all contacts stored in both your phone memory and SIM card.


Press **SELECT**. During the download, the handset displays the progress. All other idle system handsets display **Downloading dir**.

- Your cell phone may require a passcode. In this case the screen displays **Check cellular. ENTER PASS CODE**. Enter the cell phone passcode into the handset and press **SET** to save.



## Bluetooth setup

- If the selected device's directory has already been downloaded to **TL92271/TL92371/TL92471** before, the handset displays the date of the last download from your cell phone. The directory stored on the **TL92271/TL92371/TL92471** for that cell phone will be erased and replaced with the current cell phone directory. If you have edited the downloaded entries (page 64), those changes will be lost. Press **NEXT** to start the download, the screen displays **Erasing directory...**
- If you already have 4 downloaded directories, the handset displays **Memory is full. Replace existing directory?** Press **YES** if you want to replace an existing directory. Highlight the cell phone directory to be replaced and press **SELECT**. The screen displays **Replace Cell Phone A directory?** Press **YES** to confirm.



6. When the downloading process is complete, the handset displays **Download ended XXXX entries saved**. You hear a confirmation tone. Press **OK** to return to the download directory menu.

### NOTES:

- With certain cell phones, downloading from the SIM card is not supported. If this is the case, try transferring the contacts from your SIM card to your cell phone memory first, then download from your cell phone memory. For more information on how to transfer contacts from your SIM card to your cell phone memory, see the user's manual of your cell phone.
- If **Phone memory** is chosen but with no entries saved, the handset displays **No entries found. Download from SIM only?** Press **YES** to confirm. If **SIM card only** is chosen but with no entries saved, the handset displays **No entries found. Download from Phone only?** Press **YES** to confirm. If **Phone and SIM** are chosen but with no entries saved in either or both directories, the handset display **No entries found. Download from Phone only?** Press **YES** to confirm.
- When downloading the directory from your Bluetooth enabled cell phone, some data may not transfer. For example, if you have home, mobile and work numbers for a particular contact, the three categories may not transfer to your **TL92271/TL92371/TL92471**.
- On certain cell phones, you may need to press a key to confirm the directory download.

## Bluetooth setup

### Interruption to directory download

---

If you are downloading a directory from a cell phone and the phone receives a call, the download process stops and all handsets display **Download fail**. When you try to view the downloaded directory, the handset displays **Last Download failed: MM/DD/YY**. You need to download the directory again (see page 22).

If you are downloading a directory from a cell phone and the telephone base loses power, the download process stops. When the telephone base regains power, the handset only displays the **Home** directory. You need to download the directory again (see page 22).

The download progress screen may be replaced with **Cell line in use**. To go back to the downloading progress screen, do Steps 1-5 on page 22. The download process continues even if any of the following occur:


- You place the handset in the telephone base or charger.
- You access your cell phone menu features.
- The handset battery becomes depleted or the handset loses connection with the telephone base.

**NOTE:** During the download process, do not attempt to make changes to your cell phone directory.

### View the directory download information

---

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID** or **DIR** to highlight **Directory**, then press **SELECT**.
3. Press **CID** or **DIR** to choose the desired downloaded directory, then press **OPTION**.
4. Press **CID** or **DIR** to highlight **Last update**, then press **SELECT**. The directory download information appears on the screen. Press **OK** to exit.



## Change PIN

---

You are required to enter a PIN when establishing a Bluetooth connection. The default PIN of your telephone base is **0000**.

### To change the PIN:

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID▼** or **▲DIR** to highlight **Bluetooth**, then press **SELECT**.
3. Press **CID▼** or **▲DIR** to highlight **Change PIN**, then press **SELECT**. The handset displays **ENTER NEW PIN** and the existing PIN.
  - Press **MUTE/DELETE** to erase a digit.
  - Press and hold **MUTE/DELETE** to erase all digits.
  - Press **CID▼** or **▲DIR** to move the cursor to the right or left.
5. Press **SET** to save. You hear a confirmation tone.



## Handset settings

**Ringers**


In the ringers menu, you can select the ringer tones and adjust the ringer volume for incoming calls to the home and cell lines.

**Ringer volume**

You can select the ringer volume for the incoming home and cell calls.

**To adjust the handset ringer volume:**



1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID**▼ or **▲DIR** to highlight **Ringers**, then press **SELECT**.
3. Press **SELECT** to choose **Ringer volume**.
4. Press **CID**▼ or **▲DIR** to select **All lines**, **Home**, **Cell-D1** or **Cell-D2**, then press **SELECT**.
5. Press **CID**▼ or **▲DIR** to adjust the ringer volume. You hear a sample of each volume level while adjusting.
6. Press **SET** to save. You hear a confirmation tone.



**-OR-**

Press **OFF** to turn off the ringer, then press **SET** to save. The handset displays **Caller ID won't be announced**. You hear a confirmation tone.

**i NOTES:**

- Changing the handset ringer volume does not affect base ringer volume. For more information on base ringer volume, see page 38.
- When the ringer volume for all calls (home and cellular) is set to off, a ringer off icon  appears steady. When only one or two of the ringer volume settings are set to off, a ringer off icon  flashes.
- The ringer volume level also determines the ringer levels of intercom calls (page 51).



## Ringer tone

You can select the ringer tones for the incoming home and cell calls.

### To select a ringer tone:

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID** or **▲DIR** to highlight **Ringers**, then press **SELECT**.
3. Press **CID** or **▲DIR** to highlight **Ringer tone**, then press **SELECT**.
4. Press **CID** or **▲DIR** to highlight **All lines**, **Home**, **Cell-D1** or **Cell-D2**, then press **SELECT**.
5. Press **CID** or **▲DIR** to sample each ringer tone.
6. Press **SET** to save your preference. You hear a confirmation tone.

**i NOTE:** When you turn off the ringer volume, you will not hear ringer tone samples.



## Handset settings

**Set date and time**

The answering system announces the day and time of each message prior to playing it. If you subscribe to caller ID service, the day, month and time are set automatically with each incoming call. If you do not want to set the date and time automatically with caller ID information, turn this feature off (see **Use caller ID to automatically set date and time** on page 33). However, the year must be correct so that the day of the week can be calculated from the caller ID information. Before using the answering system, set the date and time as follows.

After handset registration or a power failure, the handset will prompt you to set the date and time (see page 8).

**To set the date and time:**

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID** or **▲DIR** to highlight **Set date/time**, then press **SELECT**.
3. Press **CID** or **▲DIR** to select the month, then press **SET**, or enter the 2-digit number (**01-12**) using the dialing keys (**0-9**).
4. Press **CID** or **▲DIR** to select the day, then press **SET**, or enter the 2-digit number (**01-31**) using the dialing keys (**0-9**).
5. Press **CID** or **▲DIR** to select the year, then press **SET**, or enter the 2-digit number (**00-99**) using the dialing keys (**0-9**), then press **SET**.
6. Press **CID** or **▲DIR** to select the hour, then press **SET**, or enter the 2-digit number (**01-12**) using the dialing keys (**0-9**).
7. Press **CID** or **▲DIR** to select the minute, then press **SET**, or enter the 2-digit number (**00-59**) using the dialing keys (**0-9**).
8. Press **CID** or **▲DIR** to highlight **AM** or **PM**, or press **2** for **AM** or **7** for **PM**. Press **SET** to save. You hear a confirmation tone.



**NOTE:** If the date and time are not set when a message is recorded, the system announces, "Time and day not set," before each message plays.

## Handset settings

**Settings**

In the settings menu, you can change and edit the settings for LCD language, display alerts, CID time synchronization, handset name, key tone, dial mode and caller ID announce.

**LCD language**

You can select English, Français or Español to be used in all screen displays.

**To select a language:**

1. Press **MENU** in idle mode to enter the main menu.
2. Press **CID**▼ or **▲DIR** to highlight **Settings**, then press **SELECT**.
3. Press **SELECT** to choose **LCD language**.
4. Press **CID**▼ or **▲DIR** to choose from **English**, **Français** or **Español**, then press **SET** to save. You hear a confirmation tone.



## Display alerts

---

In the display alerts menu, you can change and edit the settings for the display of alerts on the idle screen.

## Missed call indicator

---


When there are missed calls that have not been reviewed in the caller ID log, the handsets show **XX Missed calls**.

Each time you review a caller ID log entry marked **NEW**, the number of missed calls decreases by one. When you have reviewed all the missed calls, the missed call indicator goes away.

If you do not want to review the missed calls one by one, you can reset the missed call indicator. All the entries are then considered old and kept in the caller ID log.

### To reset the missed call indicator:


1. Press **MENU** in idle mode to enter the main menu.
2. Press **CID**▼ or **▲DIR** to highlight **Settings**, then press **SELECT**.
3. Press **CID**▼ or **▲DIR** to highlight **Display alerts**, then press **SELECT**.
4. Press **CID**▼ or **▲DIR** to highlight **Home line** or **Cell line**, then press **SELECT**.
5. Press **CID**▼ or **▲DIR** to highlight **Missed calls**, then press **SELECT** to confirm. The screen displays **Reset missed call indication?** Press **YES** to confirm. You hear a confirmation tone.



You can also press and hold **OFF/CANCEL** to erase the missed call indicator when the telephone is not in use.

## **Voicemail indicator**

---


If you subscribe to voicemail service offered by your telephone service provider, **New voicemail** and  appear on the handsets when you have new voicemail messages. Contact your telephone service provider for more information and assistance about using your voicemail service.

After you have listened to all new voicemail messages, the indicators on the handsets turn off automatically.

Reset the voicemail indicators when the telephone indicates that there is new voicemail but there is none (for example, when you have accessed your voicemail while away from home). Clearing the voicemail waiting indicators only turns off the indicators; it does not delete your voicemail messages. As long as you have new voicemail messages, your telephone service provider continues to send the signal to turn on the indicators.

### **To reset the voicemail indicator:**

1. Press **MENU** on the handset when it is not in use.
2. Press **CID** or **DIR** to highlight **Settings**, then press **SELECT**.
3. Press **CID** or **DIR** to highlight **Display alerts**, then press **SELECT**.
4. Press **CID** or **DIR** to highlight **Home line**, then press **SELECT**.
5. Press **CID** or **DIR** to highlight **Voicemail**, press **SELECT**.
6. The handset displays **Reset voicemail indication?**  
Press **YES** to confirm. You hear a confirmation tone.




## No line

---

If there is no telephone line connected to the telephone base, the handsets show **No home line**. If you do not want to display the message on the handset screens (for example, if you use the cell line only), you can turn off the no line alert.

### To turn the no line alert on or off:

1. Press **MENU** in idle mode to enter the main menu.
2. Press **CID▼** or **▲DIR** to highlight **Settings**, then press **SELECT**.
3. Press **CID▼** or **▲DIR** to highlight **Display alerts**, then press **SELECT**.
4. Press **CID▼** or **▲DIR** to highlight **Home line**, then press **SELECT**.
5. Press **CID▼** or **▲DIR** to highlight **No line**, then press **SELECT**.
6. Press **CID▼** or **▲DIR** to choose **On** or **Off**, then press **SET** to save. When you choose **Off**, the handset displays **If the line is not connected, an alert will not appear**. You hear a confirmation tone.





## Download fail

---

If the directory download process is interrupted, the handsets display **Download fail**. You can reset the download fail indication on the handset.

### To reset the download fail indication:

1. Press **MENU** on the handset when it is not in use.
2. Press **CID▼** or **▲DIR** to highlight **Settings**, then press **SELECT**.
3. Press **CID▼** or **▲DIR** to highlight **Display alerts**, then press **SELECT**.
4. Press **CID▼** or **▲DIR** to highlight **Cell line**, then press **SELECT**.
5. Press **CID▼** or **▲DIR** to highlight **Download fail**, then press **SELECT**.
6. The handset displays **Reset download failure indication?** Press **YES** to confirm. You hear a confirmation tone.



You can also press and hold **OFF/CANCEL** to erase the download fail indicator when the telephone is not in use.

## Handset settings

**Use caller ID to automatically set date and time**

If you subscribe to caller ID service, the date and time will be set automatically by the caller ID information. You can turn off this feature if you want to set the date and time manually.

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID▼** or **▲DIR** to highlight **Settings**, then press **SELECT**.
3. Press **CID▼** or **▲DIR** to select **CID time sync**, then press **SELECT**.
4. Press **CID▼** or **▲DIR** to select **On** or **Off**, then press **SET** to save. You hear a confirmation tone.

**Rename handset**

You can change the name of each handset, the new name of each handset cannot exceed 11 characters.

**To rename a handset:**

1. Press **MENU** on the handset when it is not use.
2. Press **CID▼** or **▲DIR** to highlight **Settings**, then press **SELECT**.
3. Press **CID▼** or **▲DIR** to highlight **Rename handset**, then press **SELECT**. The screen displays **RENAME HANDSET**.
4. Use the dialing keys to edit the name. Press **MUTE/DELETE** to erase a character.
  - Press and hold **MUTE/DELETE** to erase all characters.
  - Press **CID▼** or **▲DIR** to move the cursor to the right or left.
5. Press **SAVE**. You hear a confirmation tone.



## Handset settings

### Key tone

The handset is set to beep with each key press. If you turn off the key tone, there are no beeps when you press keys.

#### To change the setting:

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Use **CID** or **DIR** to scroll to **Settings**, then press **SELECT**.
3. Press **CID** or **DIR** to scroll to **Key tone**, then press **SELECT**.
4. Press **CID** or **DIR** to adjust the key tone volume. You hear a sample of each key tone volume while adjusting. Press **SET** to save your preference.

**-OR-**

Press **OFF** to turn off, then press **SET** to save. You hear a confirmation tone.




### Dial mode

The dial mode is preset to tone dialing. If you have pulse (rotary) service, you must change the dial mode to pulse dialing before using the telephone.

#### To change the setting:

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID** or **DIR** to highlight **Settings**, then press **SELECT**.
3. Press **CID** or **DIR** to highlight **Dial mode**, then press **SELECT**.
4. Press **▼CID** or **DIR** to choose **Tone** or **Pulse**, then press **SET** to save. You hear a confirmation tone.



## Handset settings

**Caller ID announce**

The caller ID announce feature lets you know who's calling without having to look at the display. When you have an incoming call, the handset and/or base speaks "Call from..." and the name of the caller based on the directory or caller ID information. If the caller's name is private or unknown, the phone number up to the last 11 digits will be announced. If the caller's phone number is also private or unknown, no information will be announced. By default, the caller ID announce feature is programmed **On**.

**To change the setting:**

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID▼** or **▲DIR** to highlight **Settings**, then press **SELECT**.
3. Press **CID▼** or **▲DIR** to highlight **Caller ID Annc**, then press **SELECT**.
4. Press **CID▼** or **▲DIR** to highlight **Handset** or **Base**, then press **SELECT**.
5. Press **CID▼** or **▲DIR** to choose **On** or **Off**, then press **SET** to save. You hear a confirmation tone.

**NOTES:**

- To use the caller ID announce feature, you must subscribe to caller ID service from your telephone service provider.
- When there are up to 5 handsets registered, the telephone system supports caller ID announce for all handsets. If six or more handsets are registered, the system supports caller ID announce for the first four registered handsets only.
- This feature is not supported with headsets.
- This feature does not announce information for call waiting calls.
- If both home and cell lines are ringing, only the caller ID information of the first ringing line will be announced.
- Caller ID announce is available in English only.
- It takes at least 2 rings for the phone to receive caller ID information and announce it. If the phone is answered before the end of the second ring, the phone won't have time to announce the caller ID information.
- Pronunciation of names may vary with this feature. Not all names may be pronounced correctly.

## Handset settings

**Website**

You can use this feature to view the AT&T website address.

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Use **CID** or **DIR** to scroll to **Website**, then press **SELECT**. The handset screen shows the AT&T website address.
3. Press **OK** to exit.

**Home area code**

If you dial 7 digits to make a local call (area code not required), enter your area code into the telephone as the home area code. When you receive a call from within your home area code, the caller ID history only displays the 7 digits of the telephone number.

This feature makes it easy for you to place a call from the caller ID log. If you dial 10 digits to make a local phone call, do not use this home area code feature. If you do, you cannot place local calls from your caller ID log, as they will have only 7 digits.

**To set the home area code:**

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID** or **DIR** to highlight **Directory**, then press **SELECT**.
3. Press **OPTION** to choose **Home**.
4. Press **CID** or **DIR** to highlight **Home area code**, then press **SELECT**. The screen displays **Only for 7 digits dialing from Caller ID log**.
5. Use the dialing keys to enter the desired home area code.
  - Press **MUTE/DELETE** to erase a digit.
  - Press and hold **MUTE/DELETE** to erase all digits.
  - Press **CID** or **DIR** to move the cursor to the right or left.
6. Press **SET** to save. The handset displays **Area code will not show in Caller ID log**. You hear a confirmation tone.

**NOTE:** If, in the future, your telephone service provider requires you to dial 10 digits to make a local call (area code + telephone number), you will need to delete your home area code. With the home area code displayed, press and hold **MUTE/DELETE**, and then press **SET**. The home area code is now restored to its default setting of \_\_\_ (empty).

## Cell area code

---

Most cell phone entries are stored in a 10-digit format. If all of your cell phone entries are stored this way, you do not need to program your cell area code.

If your cell phone stores entries in a 7-digit format, we recommend that you program your cell area code so that your 7-digit directory entries can be dialed correctly using your home line.

### To set the cell area code:

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID▼** or **▲DIR** to highlight **Directory**, then press **SELECT**.
3. Press **CID▼** or **▲DIR** to highlight a desired downloaded directory, then press **OPTION**.
4. Press **SELECT** to choose **Cell area code**. The handset displays **Only for 7 digits dialing from Caller ID log**.
5. Use the dialing keys to enter the desired cell area code.
  - Press **MUTE/DELETE** to erase a digit.
  - Press and hold **MUTE/DELETE** to erase all digits.
  - Press **CID▼** or **▲DIR** to move the cursor to the right or left.
6. Press **SET** to save. The handset screen displays **Area code will not show in Caller ID log**. You hear a confirmation tone.

## Telephone settings

### Telephone base ringer volume

---

Press **▼VOLUME▲** on the telephone base to adjust the ringer volume when the telephone is not in use. When you set the ringer volume to zero, the base ringer is off and the system announces, *"Base ringer is off."*

Press **▼/VOLUME** during an incoming call to mute the ringer temporarily.

### Answering system settings

---

Go to **Answering system settings** starting on page 74 for instructions on how to use a system handset to modify the answering system settings shown below.

Setting	Page
Answer on/off	74
Announcement (play, record and delete)	75-76
Call screening	77
Number of rings	78
Remote access code	79
Message alert tone	79
Recording time	80

## Making, answering and ending a call

### Using a handset for home calls

---

#### To make a home call:

- Press **HOME/FLASH** or **SPEAKER**, then enter the telephone number.

#### To predial a home call:

- Enter the telephone number, then press **HOME/FLASH** or **SPEAKER**.

#### To answer a home call:

- Press **HOME/FLASH** or **SPEAKER**.

#### To end a home call:

- Press **OFF/CANCEL** or put the handset in the telephone base or charger.

#### NOTES:

- The screen shows the elapsed time as you talk (in hours, minutes and seconds).
- When predialing (preview numbers before dialing), press **MUTE/DELETE** to backspace and delete; press and hold **REDIAL/PAUSE** to insert a dialing pause (a **p** appears).
- You cannot answer a home call using your connected cell phone.



### Using a Bluetooth headset for home calls

---

You can use a Bluetooth headset on home calls. However, you need to keep the device within 15 feet of the telephone base for optimal performance. Please see the user's manual of your Bluetooth headset for more information.

#### To answer a home call using a Bluetooth headset:

- Press the call key on your headset.

#### To end a home call you answered from a Bluetooth headset:

- Press the call key on your headset.

If you make or answer a home call on a handset, you can transfer the call to your headset. The handset remains active, but the handset earpiece and microphone are muted. If you hang up the handset, the call ends.

## Making, answering and ending a call

### To transfer a call from a handset to a Bluetooth headset:

- Press **OPTION**.
- Press **CID**▼ or **▲DIR** to highlight **Use BT headset**, then press **SELECT** twice. The screen displays **Transferring audio to Headset A**, the message disappears if the call is successfully transferred to the Bluetooth headset.


#### **NOTES:**

- If you answer a call from the headset, that call cannot be transferred to a handset.
- You will not see **Use BT headset** when the Bluetooth headset is already in use, or there are no active Bluetooth headsets in the device list.
- While using the cell line, you cannot choose **Use BT headset**.

### To transfer a call from the Bluetooth headset back to the handset:

- Press **OPTION**, then press **CID**▼ or **▲DIR** to highlight **Use handset** and press **SELECT**.

### To end a call that started at the handset:

- Press  **OFF/CANCEL** or put the handset in the telephone base or charger.



#### **NOTES:**

- If you answer a call using a headset, and you lose the Bluetooth connection or the battery is depleted, the call is lost.
- If you are using a headset for a call which is transferred from a **TL92271/TL92371/TL92471** headset, and you lose the Bluetooth connection or the battery of the headset is depleted, the call is transferred back to the originating handset.

## Call waiting on the home line

---

If you subscribe to call waiting service with your telephone service provider, you hear a tone in the handset earpiece if someone calls while you are already on a call.

- Press  **HOME/FLASH** on the handset to put your current call on hold and take the new call.
- Press  **HOME/FLASH** on the handset at any time to switch back and forth between calls.


## Making, answering and ending a call

### Make, answer or end a cell call


---

You can connect a maximum of 2 Bluetooth enabled cell phones to the telephone base, but only one cell phone can be used on a cell call at a time. All **TL92271/TL92371/TL92471** handsets can be used to make or answer calls on the cell phone line.

#### To make a cell call:

- Enter the telephone number, then press  **CELLULAR**.


#### -OR-

- Press  **CELLULAR**.
- Enter the telephone number, then press **DIAL**.


If you have only one cell phone connected to the telephone base, it is automatically selected to make cell calls. If you have two cell phones connected to the telephone base, the telephone system prompts you to select a cell phone before you make a cell call.

#### To answer a cell call:

- Press  **CELLULAR**.

 **NOTE:** You can also use your cell phone to answer the call. If you answer with your cell phone, it disconnects from the telephone base.



#### To end a cell call:

- Press  **OFF/CANCEL** or put the handset in the telephone base or charger.

### Call waiting on the cell line

---

If you subscribe to call waiting service with your cell phone service provider, you hear a call waiting tone if someone calls while you are already on a call.

- Press  **CELLULAR** on the handset to put your current call on hold and take the new call.
- Press  **CELLULAR** on the handset at any time to switch back and forth between calls.



#### -OR-

- Press **SWAP** to switch. To switch back, press **OPTION**. Press **CID▼** or **▲DIR** to highlight **Swap**, then press **SELECT**.


## Making, answering and ending a call

### Answer a cell call while on a home call


---

If you are on a home call and you receive an incoming cell call, you hear a beep and  1 or  2 displays on the handset you are using. The telephone base and all other handsets ring.

#### To answer the incoming cell call:

- Press  **CELLULAR** on the handset. The home call is automatically placed on hold and all other handsets display **Home call on hold** and **Cell line in use** alternately.

#### To end the cell call:

- Press  **OFF/CANCEL** on the handset. The home line is still on hold. All handsets display **Home call on hold**.

#### To resume the home call on hold:

- Press  **HOME/FLASH** on the handset.


### Cell phone voicemail

---


If you have voicemail service active on your cell phone, and you do not answer the incoming cell call, the call is answered by your cell phone's voicemail. Contact your cell phone service provider for more information about voicemail service.

### Answer a home call while on a cell call


---

If you are on a cell call and you receive an incoming home call, you hear a beep and  displays on the handset you are using. The telephone base and all other handsets will ring.

#### To answer the incoming home call:


- Press  **HOME/FLASH** on the handset. The cell call is automatically placed on hold and all other handsets display **Cell call on hold** and **Home line in use** alternately.

#### To end the home call:

- Press  **OFF/CANCEL** on the handset. The cell line is still on hold. All handsets display **Cell call on hold**.

#### To resume the cell call on hold:

- Press  **CELLULAR** on the handset.

 **NOTE:** If you have turned on your answering system and you do not answer the incoming home call, the call is answered by your answering system.

## Conference calls

### Conference home and cell calls

---

When you have calls established on the home and cell lines, you can create a 3-way conference.


#### To conference both home and cell calls:

1. Press **OPTION**.
2. Press **CID▼** or **▲DIR** to highlight **Conference**.
3. Press **SELECT**. The screen displays **Lines now in conference**.

#### To select an option while on a conference call:

1. Press **OPTION**.
2. Press **CID▼** or **▲DIR** to select one of the following options:
  - **End Home line**
  - **End Cell line**
  - **End Conference**
  - **Directory**
3. Press **SELECT**.

#### To end a conference call:

- Press  **OFF/CANCEL** or put the handset back in the telephone base or charger.

**-OR-**

- Press **OPTION**, then press **CID▼** or **▲DIR** to highlight **End Conference**. Press **SELECT** to end the conference.

#### Using the home and cell lines together:

- You can be on two different calls using the cell line and home line at the same time using two handsets.
- You cannot be on a call using the cell line and a Bluetooth headset via the home line at the same time. These are both Bluetooth devices and only one can be used at a time.
- If you are on a call using the cell line, you cannot join the call using your paired cell phone. However, you can join the call using another **TL92271/TL92371/TL92471** handset. Your cell phone is being used for the phone call so only features that are normally available during a call can be used.

## Options while on calls

### Handset speakerphone

---

During a call or message playback, press **☎/SPEAKER** to switch between speakerphone and normal handset use.

### Volume control

---

During on a call or message playback, press **▲/VOLUME** to increase or press **▼/VOLUME** to decrease the listening volume. You hear a beep from the handset earpiece while adjusting. If you turn off the key tone, the beep will not be heard.

If this is a cell call and the volume is too loud or quiet, try changing the volume on your cell phone. On some cell phones, changing the volume on the cell phone affects your cell call volume on the **TL92271/TL92371/TL92471** handset.

### Silencing the ringer

---

When the telephone is ringing, you can temporarily silence the ringer of the handset or telephone base without disconnecting the call. The next call rings normally at the preset volume.

#### To silence the ringer:

- Press **SILENCE**, **🔇 OFF/CANCEL** or **MUTE/DELETE** on the handset and **Ringer muted** appears.

### Mute

---

Use the mute function to turn off the microphone. You can hear the caller, but the caller does not hear you.

#### To mute a call:

- While on a call, press **MUTE/DELETE**. When mute is on, the handset screen shows **Microphone off** for a few seconds and the **MUTE** icon appears until the mute function is turned off.

#### To take a call off mute:

- Press **MUTE/DELETE** and resume speaking. When mute is off, **Microphone on** appears temporarily on the handset screen.

Mute is automatically canceled when you end the call.



## Options while on calls

### Temporary tone dialing

---

If you have pulse (rotary) service only, you can switch from pulse to touch-tone dialing temporarily during a call. This is useful if you need to send touch-tone signals to access your telephone banking or long distance services.

#### During a call:

1. Press **TO** **NE** **X**.
2. Use the dialing keys to enter the relevant number. The telephone sends touch-tone signals.
3. The telephone automatically returns to pulse dialing mode after you end the call.

### Hold

---

You can place a home or cell call on hold. You hear an alert tone if you have not taken the call off of hold after 14 minutes. You hear another alert tone 30 seconds later. At 15 minutes on hold, the call on hold automatically disconnects.

#### To place a home call on hold:

- Press **HOLD**. **Home call on hold** appears and **HOME/FLASH** flashes.

#### To resume a home call on hold:

- Press **HOME/FLASH**.

#### To place a cell call on hold:

- Press **HOLD**. **Cell call on hold** appears and **CELLULAR** flashes.

#### To resume a cell call on hold:

- Press **CELLULAR**.

### Equalizer

---

The equalizer feature on the handset enables you to change the quality of the handset audio to best suit your hearing.

While on a call, or listening to a message or announcement, press **EQ** to select the equalizer setting **Treble 1**, **Treble 2**, **Bass** or **Natural** (the default setting) for the handset. The current setting is shown on the handset for two seconds.



#### **i**NOTES:

- The equalizer feature does not apply to the speakerphone on the telephone base or the connected Bluetooth headset.
- If you switch the call between the handset and speakerphone by pressing **SPEAKER**, the audio setting remains unchanged.
- The current equalizer setting remains unchanged until a new setting is selected.

## Options while on calls

### Chain dialing

---

Use this feature to initiate a dialing sequence from numbers stored in the directory, caller ID log or redial list while you are on a call.

Chain dialing can be useful if you wish to access other numbers (such as bank account numbers or access codes) from the directory, caller ID log or redial list.

#### To access a number in the directory while on a call:

1. Press **OPTION**.
2. Press **CID▼** or **▲DIR** to highlight **Directory**, then press **SELECT**.
3. Press **CID▼** or **▲DIR** to highlight the desired directory, then press **REVIEW**.
4. Press **CID▼** or **▲DIR** to highlight to the desired entry or perform an alphabetical search (page 63).
5. Press **DIAL** to dial the displayed number.


#### To access a number in the caller ID log while on a call:

1. Press **OPTION**.
2. Press **CID▼** or **▲DIR** to highlight **Caller ID log**, then press **SELECT**.
3. Press **CID▼** or **▲DIR** to highlight the desired directory, then press **REVIEW**.
4. Press **CID▼** or **▲DIR** to scroll to the desired entry.
5. Press **DIAL** to dial the displayed number.

#### To access the redial list while on a call:

1. Press **REDIAL/PAUSE**.
2. Press **CID▼**, **▲DIR**, or **REDIAL/PAUSE** until the desired number displays, then press **DIAL** to dial the displayed number.

### NOTES:

- You cannot edit a directory entry while on a call. For more details about the directory, see page 59.
- You cannot copy a caller ID log entry into the directory while on a call. For more details about caller ID log, see page 69.
- You can only view the numbers in the directory, caller ID log or redial list while on a call and cannot edit, delete or save entries.
- Press  **OFF/CANCEL** to exit redial list, directory or caller ID log while on a call.

## Options while on calls

### Transfer a call

---

While on an outside call, you can transfer the call from one handset to another.

1. Press **OPTION**, then press **SELECT** to highlight **Transfer**.
  - If you have two handsets, your handset displays **Transferring call to HANDSET X**. The destination handset rings and displays **Home Transfer from other handset**.
  - If you have three or more handsets, your handset displays **TRANSFER TO:** and a list of registered handsets. Press **CID** or **▲DIR** to highlight the destination handset and then press **SELECT**. Your handset displays **Transferring call to HANDSET X**, or **Transferring call to all...** when you choose **All handsets**. The destination rings and displays **Home Transfer from HANDSET X to all**.
2. Your handset displays **Call transferred** when the other handset picks up the call. You hear a confirmation tone.

**i** **NOTE:** If the destination handset does not answer within 30 seconds, the caller handset displays **No response to transfer** and rings. If the caller handset does not answer the call on hold within 30 seconds, the call will end automatically.


## Redial

Each handset stores the last 10 dialed numbers (up to 30 digits each) in the redial list. The redial entries are not shared by all the system handsets.

### Review the redial list

---



1. Press **REDIAL/PAUSE** in idle mode.
2. Press **CID▼**, **▲DIR** or **REDIAL/PAUSE** repeatedly to browse the list. The handset beeps twice at the end of the list.

Press  **OFF/CANCEL** to exit.



### Dial a redial entry

---

1. Press **REDIAL/PAUSE** in idle mode.
2. Press **CID▼**, **▲DIR** or **REDIAL/PAUSE** repeatedly to browse until the desired number displays. The handset beeps twice at the end of the list.
3. Press  **HOME/FLASH** or  **SPEAKER** to use the home line.



**-OR-**

Press  **CELLULAR** to use the cell line.

## Redial

### Save a redial entry to the directory

---

1. Press **REDIAL/PAUSE** in idle mode.
2. Press **CID▼**, **▲DIR** or **REDIAL/PAUSE** repeatedly to browse until the desired number displays.
3. Press **SAVE**.
4. The handset displays **EDIT NUMBER**. Use the dialing keys to edit the number, if necessary.
  - Press **MUTE/DELETE** to erase a digit.
  - Press and hold **MUTE/DELETE** to erase all digits.
  - Press **CID▼** or **▲DIR** to move the cursor to the right or left.
  - Press and hold **REDIAL/PAUSE** to insert a dialing pause (a **p** appears).
5. Press **NEXT**.
6. Press **CID▼** or **▲DIR** to select one of the following types:
  - Home
  - Cell
  - Work
  - Other
7. Press **NEXT**. The handset displays **ENTER NAME**. Use the dialing keys (page 61) to enter a name.
  - Press **MUTE/DELETE** to erase a character.
  - Press and hold **MUTE/DELETE** to erase all characters.
  - Press **CID▼** or **▲DIR** to move the cursor to the right or left.
8. Press **SAVE** and then **Saved** displays. You hear a confirmation tone.

### Delete a redial entry

---

1. Press **REDIAL/PAUSE** when the handset is not in use.
2. Press **CID▼**, **▲DIR** or **REDIAL/PAUSE** repeatedly to browse until the desired number displays.
3. Press **MUTE/DELETE** to delete the displayed number. You hear a confirmation tone.

## Multiple handset use

### Handset locator

---

This feature helps you find a misplaced handset.

#### To start paging:

Press **📞/HANDSET LOCATOR** on the telephone base when it is not in use. All idle handsets ring and display **\*\* Paging \*\***.

#### To end paging:

Press **📞/HANDSET LOCATOR** on the telephone base.



**-OR-**

Press **🏠HOME/FLASH, 📞/SPEAKER, 📞CELLULAR, PUSH TO TALK, REDIAL/PAUSE, EQ** or any dialing key (**0-9, #, TONE ✕**) on the handset.

#### **i**NOTES:

- If the handset ringer volume is set to off, the handset still rings when paged.
- If there is no response after 60 seconds, paging ends.

### Join a call in progress

---

Another handset can join you on an outside call. That call continues until all people hang up. You can share an outside call with up to 4 system handsets.

- Press **🏠HOME/FLASH** or **📞/SPEAKER** on another handset to join the call.

**-OR-**

- Press **OPTION** during an intercom, then press **CID▼** or **▲DIR** to highlight **Share call**. Press **SELECT**.

## Intercom

Use the intercom feature for conversations between two system handsets.

You can buy additional expansion handsets (AT&T model TL90071, sold separately) for this telephone system. You can register up to 12 handsets to the telephone base.

### To initiate an intercom call:

1. Press **MENU** on the handset in idle mode.
2. Press **CID**▼ or ▲**DIR** to highlight **Intercom**, then press **SELECT**.
  - If you have two handsets, your handset displays **Calling other handset**. The destination handset rings and displays **Other handset is calling**.
  - If you have three or more handsets, your handset displays **INTERCOM** and a list of registered handsets.
    - ◆ Press **CID**▼ or ▲**DIR** to select a destination handset and then press **SELECT**. Your handset displays **Calling HANDSET X**, or **Calling all handsets** when you choose **All handsets**.



**-OR-**

- ◆ Press **1-9** for **HANDSET 1-9**, **TONE X** and **0** for **HANDSET 10**, **TONE X** and **1** for **HANDSET 11** or **TONE X** and **2** for **HANDSET 12**. Your handset displays **Calling HANDSET X**. The other handset rings and displays **HANDSET X is calling**.

**-OR-**

- ◆ Press **TONE X** and then **#** (pound key) to call all handsets.

The destination handset(s) rings and displays **HANDSET X is calling**, or **HANDSET X is calling all** when you choose all handsets.

### To answer an intercom call at the destination handset:


- Press **HOME/FLASH** or **▶/SPEAKER**. Both handsets show **Intercom**.

## Intercom


### To silence an intercom call:

- Press  **OFF/CANCEL**, **MUTE/DELETE** or **SILENCE** on the destination handset. Its screen displays **Ringer muted** for a few seconds.

### To end an intercom call:



- Press  **OFF/CANCEL**, **END** or place either handset back in the telephone base or charger. Both handsets display **Intercom ended**.

### **NOTES:**



- You can cancel the intercom call before it is answered by pressing  **OFF/CANCEL** or **END** on your originating handset.
- If you are calling all handsets, only the first handset to pick up can answer the intercom call.
- If the destination handset does not answer the intercom call within 100 seconds, is in the directory or caller ID log, or is out of range, the originating handset displays **No answer. Try again.** and returns to idle mode.

### Answer an incoming call during an intercom call

When you receive an incoming home call during an intercom call, the two handsets on the intercom call hear an alert tone, and their screens display **Home Incoming call** and then the caller ID. The telephone base and all other handsets ring.

- Press  **HOME/FLASH** to answer the home call and the intercom call ends automatically.
- Press  **OFF/CANCEL** to end the intercom call without answering the incoming call. The telephone continues to ring.

When you receive an incoming cell call during an intercom call, the two handsets on the intercom call hear an alert tone, and their screens display **Cell Incoming call** and then the caller ID. The telephone base rings and all other handsets ring.

- Press  **CELLULAR** to answer the cell call and the intercom call ends automatically.
- Press  **OFF/CANCEL** to end the intercom call without answering the incoming call. The telephone continues to ring.

## Call transfer using intercom


Use the intercom feature to transfer an outside call to another system handset without first notifying the other party.

1. When on an outside call, press **OPTION**.
2. Press **CID**▼ or **▲DIR** to highlight **Intercom**, then press **SELECT**. The call is automatically put on hold.
  - If you have a two-handset system, the outside call is put on hold and your handset displays **Calling other handset**. The other handset rings and displays **Other handset is calling**.
  - If you have three or more handsets, your handset displays **INTERCOM TO:**
    - ♦ Press **CID**▼ or **▲DIR** to select a destination handset and then press **SELECT**. Your handset displays **Calling HANDSET X**, or **Calling all handsets** when you choose **All handsets**.
    - OR-
    - ♦ Press **1-9** for **HANDSET 1-9**, **TONE X** and **0** for **HANDSET 10**, **TONE X** and **1** for **HANDSET 11** or **TONE X** and **2** for **HANDSET 12**.
    - OR-
    - ♦ Press **TONE X** and then **#** (pound key) to call all handsets.



The destination handset rings and displays **HANDSET X is calling**, or **HANDSET X is calling all** when you choose all handsets.

3. To answer the call on the other handset, press **HOME/FLASH** or **▲SPEAKER**. The outside call is still on hold and both handsets now show **Intercom**.
4. From this intercom call, you have the following options:
  - You can transfer the call. Press **OPTION** and then press **SELECT** to choose **Transfer** on the calling handset. Your screen shows **Call transferred**. The other handset automatically connects to the outside call.
  - You can let the other handset join you on the outside call in a three-way conversation. Press **OPTION**, highlight **Share call**, and press **SELECT**.
  - Either person can press the appropriate line key (**HOME/FLASH** or **CELLULAR**) on the handset to take the held outside call, or press **OFF/CANCEL** or **END** to hang up the intercom call (the outside call will automatically go off hold for the handset that did not hang up).



### **i**NOTES:

- If you want to cancel an intercom call and reconnect to the outside call before the destination handset answers, press **OFF/CANCEL** or **END** on the originating handset.
- If the other handset does not answer the intercom call within 100 seconds, or if the other handset is in the directory or caller ID log, or is out of range, the calling handset shows **No answer. Try again.** and returns to the outside call.

## Push-to-talk (PTT)

You can directly broadcast messages from one handset to the speakerphone of one or all other handsets. Any handset called can respond by pressing **PUSH TO TALK** to begin a two-way communication. If only one handset is available or registered, the handset screen shows **PTT requires two handsets** when you press **PUSH TO TALK**.



- Only one handset can talk at a time. To do so, press and hold the **PUSH TO TALK** button.
- You must release **PUSH TO TALK**, so the other person can respond.
- Only one PTT can be active at a time.
- While PTT is in use between handsets, other handsets cannot use the intercom feature but can access the answering system.
- When you attempt to place a PTT call to another handset which is accessing the answering system, your handset displays **Not available at this time**.

### PTT on/off

You can turn PTT on or off on each handset.

- When on, the handset can begin and receive PTT calls.
- When off, the handset can begin PTT calls but will not receive PTT calls from other handset(s). The idle handset displays **No Incoming PTT**.
- When you attempt to place a PTT call to another handset that has the PTT feature turned off, your handset displays **Not available at this time**.

#### To turn PTT on or off:

1. Press **PUSH TO TALK** when the handset is not in use. The **PUSH TO TALK** menu displays.
2. Press **CID** or **DIR** to highlight **PTT On/Off**, then press **SELECT**.
3. Press **CID** or **DIR** to highlight **On** or **Off**, then press **SELECT** to save. You hear a confirmation tone.



## Push-to-talk (PTT)

### PTT to a single handset

---

1. You have 2 ways to begin a PTT call:

- If you have two handsets, press and hold **PUSH TO TALK** when the handset is not in use.


**-OR-**

- If you have three or more handsets, press **PUSH TO TALK** when the handset is not in use. Then use the dialing keys to enter a handset number (**1-9** for handsets 1-9, **TONE ✕** and **0** for handset 10, **TONE ✕** and **1** for handset 11 or **TONE ✕** and **2** for handset 12), or press **CID▼** or **▲DIR** to scroll to the desired handset then press **SELECT** or **PUSH TO TALK** to create the push-to-talk session.

2. Your handset displays **Connecting to HANDSET X...** for a few seconds. When the connection is made, both your and the destination handsets display **Press and hold [PTT] to talk** and beep once.


3. Press and hold **PUSH TO TALK** on your handset. A chirp indicates your microphone is on. Speak towards the handset. Your voice is broadcast to the destination handset. While you are speaking, the handset displays **PTT To HANDSET X** (**X** represents the destination handset number).

4. Release **PUSH TO TALK** after speaking. Both handsets beep once again. After the handsets beep, you can press and hold **PUSH TO TALK** to continue speaking or the destination handsets can respond (see **Answer a PTT call** on page 57).

5. To end the PTT call, press  **OFF/CANCEL** or **END**. The handset displays **Push to talk Ended** for a few seconds.

**-OR-**

Place the handset in the telephone base or charger to end the PTT call.

 **NOTE:** After **PUSH TO TALK** is released, the PTT call remains open for a short time. If no one presses **PUSH TO TALK** within 10 seconds, the PTT call ends automatically.

## Push-to-talk (PTT)

### PTT to a group of handsets

---

When there are multiple handsets registered to the phone system, PTT supports one-to-group calls. PTT supports a maximum of one-to-four calls when two to five handsets are registered, and a maximum of one-to-three calls when six or more handsets are registered. The first 4 registered handsets will be able to use this feature. Other handsets can only use PTT for one-to-one calls.

1. To begin a PTT call to a group of handsets:

- Press and hold **PUSH TO TALK** when the handset is not in use.  
**-OR-**
- Press **PUSH TO TALK** when the handset is not in use. Press **TONE ✕** and **#**, or press **CID▼** or **▲DIR** to highlight **Group** then press **SELECT** or **PUSH TO TALK**.

Your handset displays **Connecting to group...** for a few seconds. When the connection is made, both your and the destination handsets display **Press and hold [PTT] to talk** and beep once.

2. Press and hold **PUSH TO TALK** on your handset. A chirp indicates your microphone is on. Speak towards the handset. Your voice is broadcast to the destination handset. While you are speaking, the handset displays **PTT To handset X** (X represents the destination handset numbers).
3. Release **PUSH TO TALK** after speaking. All handsets beep once again. After the handsets beep, you can press and hold **PUSH TO TALK** to continue speaking or the destination handsets can respond (see **Answer a PTT call** on page 57).
4. Press **OFF/CANCEL** or **END** to end the PTT call. The handset displays **Push to talk Ended** for a few seconds.

**-OR-**

Place the handset in the telephone base or charger to end the PTT call.

**i** **NOTE:** After **PUSH TO TALK** is released, the PTT call remains open for a short time. If no one presses **PUSH TO TALK** within 10 seconds, the PTT call ends automatically.

## Push-to-talk (PTT)

### Answer a PTT call

---

You can respond to a PTT call whenever the speakerphone light is off, as described below.

1. When your handset receives a PTT call, the handset beeps and displays **Press and hold [PTT] to talk**.
2. When someone else is speaking, your speakerphone light is on, and your handset displays **PTT From HANDSET X To handset: Y** (the first **X** represents the initiating handset number and **Y** represents your handset number; a maximum of 4 handset numbers appear).
3. When your speakerphone light is off (the handset displays **Press and hold [PTT] to talk**), you hear a beep. Press and hold **PUSH TO TALK** on your handset. When you hear a chirp, speak towards the handset.
  - While you are speaking, your handset displays **PTT To handset X** (**X** represents the handset numbers of one or more destination handsets; a maximum of 4 handset numbers appear).
  - Your voice is broadcast to all destination handsets.

Release **PUSH TO TALK** when you finish speaking. Your handset will beep. After the beep, if your speakerphone light is off, you can press and hold **PUSH TO TALK** to continue speaking or the destination handsets can respond.

### Change a one-to-one PTT call to an intercom call

---

You can convert a one-to-one PTT conversation to an intercom call.

1. When your handset displays **Press and hold [PTT] to talk**, press **INTCOM**. Your handset displays **Switch to Intercom?** Press **SELECT** to confirm.
  - If you have a two-handset system, your handset displays **Calling other handset**. The destination handset temporarily displays **Push to talk Ended** and then **Other handset is calling**.
  - If you have three or more handsets, your handset displays **Calling HANDSET Y** (**Y** represents the destination handset number). The destination handset temporarily displays **Push to talk Ended** and then **HANDSET X is calling** (**X** represents the originating handset number).
2. On the destination handset, press **HOME/FLASH** or **SPEAKER** to answer the intercom call. Both handsets now display **Intercom**.
3. To end the intercom call, press **OFF/CANCEL** or place the handset in the telephone base or charger. Both handsets display **Intercom ended**.

## Push-to-talk (PTT)


### End a PTT call

---

- For a one-to-one PTT call, both the originating and destination handsets can end the PTT call.
- For one-to-group PTT calls, the initiating handset can end the PTT call for the group of handsets on that PTT call. If any one of the destination handsets leaves the PTT call, the call continues until all participants or the initiator hangs up.

### To end or leave PTT:








Press  **OFF/CANCEL** or place the handset in the telephone base or charger. The handset displays **Push to talk Ended**.

 **NOTES:** After **PUSH TO TALK** is released, the PTT call remains open for a short time. If no one presses **PUSH TO TALK** within 10 seconds, the PTT call ends automatically.

### Answer an incoming call during PTT







---

When you receive an incoming outside call during PTT, there is a call waiting tone. The caller ID is displayed with PTT screen alternately.

- During a one-to-one PTT call, press  **HOME/FLASH** or  **CELLULAR** on the originating or destination handset. The PTT call ends automatically and the outside call is answered.
- During a one-to-group PTT call, press  **HOME/FLASH** or  **CELLULAR** on the originating handset. The PTT call ends automatically and the outside call is answered.
- During a one-to-group PTT call, press  **HOME/FLASH** or  **CELLULAR** on any one of the destination handsets and that handset answers the outside call. The PTT call continues for the rest of the PTT participants.
- To leave the PTT call without answering the incoming call, press  **OFF/CANCEL**. The telephone continues to ring.

### Make an outgoing call during PTT

---

- During a one-to-one PTT call, press  **HOME/FLASH** or  **CELLULAR** to get a dial tone. The PTT call ends automatically.
- During a one-to-group PTT call, press  **HOME/FLASH** or  **CELLULAR** on the originating handset. The PTT call ends automatically and you get a dial tone.
- During a one-to-group PTT call, press  **HOME/FLASH** or  **CELLULAR** on any one of the destination handsets and that handset gets a dial tone. The PTT call continues for the rest of the PTT participants.

## About the directory

The home directory stores up to 200 entries with up to 30 digits for each phone number and 15 characters for each name. Each of the downloaded directories stores up to 1,500 entries with up to 30 digits for each phone number and 15 characters for each name.

- Directory entries are stored at the telephone base and shared by all system handsets. Any changes made on one handset apply to all.
- Only one handset can review the directory at a time. If another handset tries to enter the directory, its screen shows **Not available at this time.**
- When there are no records in the directory, the screen shows **Directory empty.**
- When the directory is full and you try to save an entry, the screen shows **Directory full.**
- When you try to save a number already stored in the directory, the screen shows **Already saved.**

All of the instructions on pages 60-67 for the directories apply to the home directory and all downloaded directories. Creating a new entry on page 60 only applies to the home directory.

You cannot create new entries in your downloaded directories from the **TL92271/TL92371/TL92471** handset. Entries must be downloaded from your cell phone (see **Download directory** on pages 22-23).

## Create and review entries

### Create a new entry in the home directory


---

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID▼** or **▲DIR** to highlight **Directory**, then press **SELECT**.
3. Press **OPTION** to select **Home**.
4. Press **SELECT** to choose **Add contact**. The screen displays **ENTER NUMBER**.
5. Use the dialing keys to enter a telephone number.
  - Press **MUTE/DELETE** to erase a digit.
  - Press and hold **MUTE/DELETE** to erase all digits.
  - Press **CID▼** or **▲DIR** to move the cursor to the right or left.
  - Press and hold **REDIAL/PAUSE** to insert a dialing pause (a **p** appears).

**-OR-**


Copy a number from the redial list.

- Press **REDIAL/PAUSE** and then **CID▼**, **▲DIR** or **REDIAL/PAUSE** repeatedly to browse for a number. Press **INSERT** to copy the displayed number.
6. Press **NEXT**.
  7. Press **CID▼** or **▲DIR** to select one of the following types:
    - Home
    - Cell
    - Work
    - Other
  8. Press **NEXT**. The screen displays **ENTER NAME**.
  9. Use the dialing keys (see page 61) to enter the name.
    - Press **MUTE/DELETE** to erase a character.
    - Press and hold **MUTE/DELETE** to erase all characters.
    - Press **CID▼** or **▲DIR** to move the cursor to the right or left.
  10. Press **SAVE** to confirm and the screen shows **Saved**. You hear a confirmation tone.

 **NOTE:** You cannot create new entries in your downloaded directories from your **TL92271/TL92371/TL92471** handsets. Entries must be downloaded from your cell phone (see **Download directory** on pages 22-23).

# Create and review entries

Dialing keys	Characters by number of key presses										
	1	2	3	4	5	6	7	8	9	10	11
1	1	.	-	'	(	)	*	#	&	/	,
2	A	B	C	a	b	c	2				
3	D	E	F	d	e	f	3				
4	G	H	I	g	h	i	4				
5	J	K	L	j	k	l	5				
6	M	N	O	m	n	o	6				
7	P	Q	R	S	p	q	r	s	7		
8	T	U	V	t	u	v	8				
9	W	X	Y	Z	w	x	y	z	9		
0	Space	0									
*											
#											

 **NOTE:** When entering a name in the directory, the first letter of each word is automatically capitalized.

## Create and review entries

**To add a predialed telephone number to the directory**

You can save a predialed telephone number to the directory.

1. Enter the telephone number in idle mode (see Step 5 in **Create a new entry in the home directory** on page 60).
2. Press **SAVE** to move on to the number (see Step 3 in **Edit a directory entry** on page 64) and then press **NEXT**.
3. Press **CID**▼ or **▲DIR** to select one of the following types:
  - Home
  - Cell
  - Work
  - Other
4. Press **NEXT**. The screen displays **ENTER NAME**.
5. Use the dialing keys (see page 61) to enter the name.
  - Press **MUTE/DELETE** to erase a character.
  - Press and hold **MUTE/DELETE** to erase all characters.
  - Press **CID**▼ or **▲DIR** to move the cursor to the right or left.
6. Press **SAVE** and the screen shows **Saved**. You hear a confirmation tone.



## Create and review entries

### Review the directory

---

Entries are sorted alphabetically.

1. Press **▲DIR** in idle mode.
2. Press **CID▼** or **▲DIR** to highlight a directory, then press **REVIEW**.
3. Press **CID▼** or **▲DIR** to browse.

**-OR-**

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID▼** or **▲DIR** to highlight **Directory**, then press **SELECT**.
3. Press **CID▼** or **▲DIR** to highlight a directory, then press **REVIEW**.
4. Press **CID▼** or **▲DIR** to browse.

**-OR-**

1. Press **OPTION** while on call.
2. Press **CID▼** or **▲DIR** to highlight **Directory**, then press **SELECT**.
3. Press **CID▼** or **▲DIR** to highlight a directory, then press **REVIEW**.
4. Press **CID▼** or **▲DIR** to browse.

**i NOTE:** When the desired entry displays, press **#** repeatedly to show different dialing options.

### 3-character alphabetical search

---

You can use the enhanced 3-character search to find your contacts quickly and efficiently.

#### To start the search:

1. Follow the steps in **Review the directory** above to enter the directory.
2. When an entry appears, use the dialing keys to enter the letters associated with the name (see page 61). You can enter up to 3 letters for the search. The letters will show in the top left hand corner of the screen. If there is no name matching the letters entered, the next closest match in alphabetical order appears. If necessary, use **CID▼** or **▲DIR** to browse.

**i NOTE:** The cursor automatically moves to the next position two seconds after you enter a letter. If you do not enter another letter in the coming two seconds, the handset starts searching in the directory.



## Dial, edit or delete a directory

### Dial a directory entry

---

You can dial a directory entry on either a home or cell line.

#### To dial a directory entry:

1. Search for the desired entry in the directory (see **Review the directory** or **3-character alphabetical search** on page 63).
2. When the desired entry appears, press **#** (pound key) repeatedly to show different dialing options.
3. When the displayed number is in the correct format, press **HOME/FLASH** or **SPEAKER** to use the home line, or **CELLULAR** to use the cell line.

888-883-2445
1-888-883-2445
883-2445
1-883-2445

### Edit a directory entry

---

You may edit any directory entry. However, be aware that if you download from a cell phone again, the directory is erased and replaced with the current cell phone directory. If you have edited the downloaded entries on the **TL92271/TL92371/TL92471**, those changes are lost. To avoid losing changes made to the downloaded directory, we suggest that you edit the number in your cell phone, then download the directory.

1. Search for the desired entry in the directory (see **Review the directory** or **3-character alphabetical search** on page 63).
2. When the desired entry appears, press **EDIT**. The handset shows **EDIT NUMBER**.
3. Use the dialing keys to edit the number.
  - Press **MUTE/DELETE** to erase a digit.
  - Press and hold **MUTE/DELETE** to erase all digits.
  - Press **CID▼** or **▲DIR** to move the cursor to the right or left.
  - Press and hold **REDIAL/PAUSE** to insert a dialing pause (a **p** appears).
4. Press **NEXT**.
5. Press **CID▼** or **▲DIR** to select one of the following types:
  - Home
  - Cell
  - Work
  - Other
6. Press **NEXT**. The screen displays **EDIT NAME**.
7. Use the dialing keys (see page 63) to enter the name.
  - Press **MUTE/DELETE** to erase a character.
  - Press and hold **MUTE/DELETE** to erase all characters.
  - Press **CID▼** or **▲DIR** to move the cursor to the right or left.
8. Press **SAVE** to confirm and the handset shows **Saved**.

## Dial, edit or delete a directory

**Edit the type of a directory entry**

---

**If you only want to edit the type of a directory entry:**

1. Search for the desired entry in the directory (see **Review the directory or 3-character alphabetical search** on page 63).
2. When the desired entry appears, press **LABEL**. Enter the corresponding shortcut keys shown in the below table.

Type:	Press:
Home	<b>1</b>
Cell	<b>2</b>
Work	<b>3</b>
Other	<b>4</b>

**-OR-**


Press **CLEAR** to erase the assigned label.

**Delete a directory entry**

---

**To delete an entry:**

1. Search for the desired entry in the directory (see **Review the directory or 3-character alphabetical search** on page 63).
2. When the desired entry appears, press **MUTE/DELETE**. The screen displays **Delete contact?** and the name of the entry. Press **YES** to confirm.
3. The screen displays **Contact deleted** and then the next alphabetical entry in the directory. You hear a confirmation tone.

 **NOTE:** Once a directory entry is deleted, it cannot be retrieved.

**Remove a downloaded directory**

---

1. Search for the desired downloaded directory in the directory menu (see **Review the directory** on page 63).
2. When the desired downloaded directory is chosen, press **OPTION**, then press **CID▼** or **▲DIR** to highlight **Remove dir**.
3. Press **SELECT**. The screen displays **Directory Cell Phone A will be erased**. Press **YES** to confirm.
4. The handset displays **Erasing directory...** and then **Directory removed**. You hear a confirmation tone.

## Speed Dial

You can assign 10 of your directory entries to a speed dial location (**0-9**). The speed dial entries are shared by all handsets.

### Assign a speed dial slot

---

Up to 10 speed dial entries can be stored. The speed dial number must be created from an existing entry in the Home or Bluetooth directory.

1. Press **MENU** on handset when it is not in use.
2. Press **CID▼** or **▲DIR** to highlight **Directory**, then press **SELECT**.
3. Press **CID▼** or **▲DIR** to highlight **Speed dial**, then press **REVIEW**.
4. Press **CID▼** or **▲DIR** to highlight an empty slot, then press **ASSIGN**.
5. Press **CID▼** or **▲DIR** to highlight the desired directory, then press **REVIEW**.
6. Search for the desired entry in the directory (see **Review the directory** or **3-character alphabetical search** on page 63). When the desired entry appears, press **ASSIGN**. You hear a confirmation tone.

### Reassign a speed dial slot

---

1. Press **MENU** in idle mode.
2. Press **CID▼** or **▲DIR** to highlight **Directory** and then press **SELECT**.
3. Press **CID▼** or **▲DIR** to highlight **Speed dial**, then press **REVIEW**.
4. Press **CID▼** or **▲DIR** to highlight the desired slot.
5. Press **ASSIGN**. The handset displays the directory at the current assigned entry.
6. Search for the desired entry in the directory (see **Review the directory** or **3-character alphabetical search** on page 63). When the desired entry appears, press **ASSIGN**.
7. The handset displays **Entry B replaces Entry A Accept?** Press **YES** to confirm. You hear a confirmation tone.

### Dial a speed dial entry


---

1. Press and hold a desired speed dial slot (**0-9**).
2. Press **HOME/FLASH** or **◀)/SPEAKER** to use the home line, or **📶)CELLULAR** to use the cell line.

## Delete a speed dial entry

---

1. Press **MENU** in idle mode.
2. Press **CID**▼ or **▲DIR** to highlight **Directory** and then press **SELECT**.
3. Press **CID**▼ or **▲DIR** to highlight **Speed dial**, then press **REVIEW**.
4. Press **CID**▼ or **▲DIR** to highlight assigned slot, then press **MUTE/DELETE**.
5. The handset displays **Delete Entry A speed dial assignment?** Press **YES** to confirm. You hear a confirmation tone.

 **NOTE:** Deleting speed dial entries does not affect the directory entries.

## About caller ID

This product supports caller ID services provided by most telephone service providers. Caller ID allows you to see the name, number, date and time of calls. The available caller ID information will appear after the first or second ring. Caller ID from the home line allows you to see the name, number, date and time of the incoming calls. The caller ID may appear differently if the caller is matched to a directory entry (see **Memory match** on page 69).

### Information about caller ID with call waiting

---

Caller ID with call waiting lets you see the name and telephone number of the caller before answering the telephone, even while on another call.

It may be necessary to change your telephone service to use this feature. Contact your telephone service provider if:

- You have both caller ID and call waiting, but as separate services (you may need to combine these services).
- You have only caller ID service, or only call waiting service.
- You don't subscribe to caller ID or call waiting services.

There are fees for caller ID services. In addition, services may not be available in all areas.

Caller ID information is available only if both you and the caller are in areas offering caller ID service, and if both telephone service providers use compatible equipment.

The caller ID information may not be available for every incoming call. The callers may intentionally block their names and/or telephone numbers. A caller ID log entry can show a maximum number of 24 digits.



**i NOTE:** You can use this product with regular caller ID service, or you can use this product's other features without subscribing to caller ID or combined caller ID with call waiting service.

## Caller ID operation

### How the caller ID history (caller ID log) works

The telephone stores caller ID information about the last 50 incoming calls in the telephone base. Entries are stored in reverse chronological order. The phone deletes the oldest entry when the log is full to make room for new calls. This information is common to all handsets, so changes made using any handset are reflected in all other handsets. If you answer a call before the information appears on the screen, it does not show in the caller ID history.

**NOTE:** If the phone number has more than 24 digits, it will not be saved or shown in the caller ID log.



### Memory match

If the incoming telephone number matches the last 7 digits of a telephone number in your directory, the name that appears on the screen matches the corresponding name in your directory.

For example, if Christine Smith calls, her name appears as **Chris** if this is how you entered it into your directory.

**NOTE:** The number you see on your caller ID is in the format sent by the telephone service provider. It usually delivers 10-digit telephone numbers (area code plus telephone number). If the last 7 digits of the incoming telephone number do not match a number in your directory, the name appears as it is delivered by the telephone service provider.



# Caller ID operation

## To review the caller ID log

Review the caller ID history to find out who called, to easily return a call, or to copy the caller's name and number into your directory. **Caller ID log empty** appears if there are no records in the caller ID log.


1. When a handset is in idle mode, press **CID** to review the caller ID history in reverse chronological order starting with the most recent call.

**-OR-**

You can also review the caller ID history by pressing **MENU**, then press **CID** or **DIR** to scroll to **Caller ID log**, then press **SELECT**.

2. Press **CID** or **DIR** to highlight the desired line (home or cell), then press **REVIEW**.
3. Press **CID** or **DIR** to browse.

**NOTE:** Only one handset can review the caller ID history at time. If another handset tries to enter the directory or caller ID history, it shows **Not available at this time**.



# Caller ID operation

## View dialing options


---

Although the caller ID log entries may contain 10 digits (the area code plus the 7-digit number), in some areas, you may need to dial only the 7 digits, or **1** plus the seven digits, or **1** plus the area code plus the seven digits. You can change the number of digits that you dial from the caller ID log or store to the directory.

While reviewing the caller ID log, press **#** repeatedly to show different dialing options for local and long distance numbers before dialing or saving the telephone number in the directory.

Press **1** repeatedly if you need to add or remove 1 in front of the telephone number before dialing or saving it in the directory.

When the number shows in the correct format for dialing, press **HOME/FLASH** or **SPEAKER** to call the number using the home line.



**-OR-**

Press **CELLULAR** to call the number using the cell line.

## Dial a caller ID log entry

---

1. Search for the desired entry in the caller ID log (see **To review the caller ID log** on page 70).
2. When the desired entry is displayed and is in the correct format for dialing, press **HOME/FLASH** or **SPEAKER** to use the home line, or **CELLULAR** to use the cell line.

## Caller ID operation

### **Save a caller ID log entry to the directory**

---

Caller ID log entries can only be saved to the **Home** directory.

1. Select a desired entry in the caller ID log (see **To review the caller ID log** on page 70).
2. When the desired entry appears, press **#** repeatedly to show different dialing options.
3. When the number is in the correct format, press **SAVE**. The handset shows **EDIT NUMBER**.
4. Use the dialing keys to edit the number.
  - Press **MUTE/DELETE** to erase a digit.
  - Press and hold **MUTE/DELETE** to erase all digits.
  - Press **CID▼** or **▲DIR** to move the cursor to the right or left.
  - Press and hold **REDIAL/PAUSE** to insert a dialing pause (a **p** appears).
5. Press **NEXT**.
6. Press **CID▼** or **▲DIR** to highlight one of the following types:
  - Home
  - Cell
  - Work
  - Other
7. Press **NEXT**. The screen displays **EDIT NAME** and **[\*]-Order**.
8. Use the dialing keys (see page 61) to edit the name.
  - Press **MUTE/DELETE** to erase a character.
  - Press and hold **MUTE/DELETE** to erase all characters.
  - Press **CID▼** or **▲DIR** to move the cursor to the right or left.
  - Press **TONE ✕** to toggle the name order. For example, Robert Brown becomes Brown Robert when you press **TONE ✕**.
9. Press **SAVE** to confirm and the screen shows **Saved**. You hear a confirmation tone.

### **NOTES:**

- If the name received from the telephone service provider is in all capital letters, the first letter of every word remains a capital letter. However, the next letter after the prefix "Mac", "Mc", or "O", is kept as a capital letter. For example, the "D" in "MacDonald" is kept as a capital letter.
- When you try to save a caller ID entry without any caller ID information, the handset displays **Unable to save**.
- When you try to save a number already stored in the directory, the screen shows **Already saved**.

## Caller ID operation

### To delete a single entry

1. Select a desired entry in the caller ID log (see **To review the caller ID log** on page 70).
2. When the desired entry is displayed, press **MUTE/DELETE**. The handset shows the previous caller ID log entry. You hear a confirmation tone.

### To delete all entries

1. Press **CID** on the handset in idle mode.
2. Press **ERASE**. If you choose the home caller ID log, the handset displays **Delete all Home Calls?**. If you choose a cell phone caller ID log, the handset displays **Delete all Cell phone A calls?**. Press **YES** to confirm. You hear a confirmation tone.



**-OR-**

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID** or **DIR** to highlight **Caller ID log**, then press **SELECT**.
3. Press **ERASE**. If you choose the home caller ID log, the handset displays **Delete all Home Calls?**. If you choose a cell phone caller ID log, the handset displays **Delete all Cell phone A calls?**. Press **YES** to confirm. You hear a confirmation tone.

### Reasons for missing caller ID information

There are occasions when other information or no information shows for various reasons:

On-screen message	Reason
L	It is a long distance call.
Private name	The caller prefers not to show the name.
Private number	The caller prefers not to show the phone number.
Private caller	The caller prefers not to show the phone number and name.
Unknown name	Your telephone service provider cannot determine the caller's name.
Unknown number	Your telephone service provider cannot determine the caller's number.
Unknown caller	No information is available about this caller.


# Answering system settings

## Answer on/off

If you turn the answering system on, it answers calls and records messages only on the home line. If your paired cell phone has voicemail, callers can leave messages with that voicemail service.

If your answering system is turned off and you change any of its settings, the answering system automatically turns on again and the handset displays **Calls will be answered.**

When the answering system is turned on, the **ANS ON** light on the telephone base is on and the handsets display **ANS ON.**



### To turn the answering system on or off:

#### Using the telephone base:



Press **ANS ON** to turn the answering system on or off. When the answering system is turned on, it announces, **"Calls will be answered."** When the answering system is turned off, it announces, **"Calls will not be answered."**

#### **i**NOTES:

- If there is no remaining recording time, the answering system announces **"Calls will not be answered."** and cannot be turned on.
- If the total recording time is less than three minutes, the answering system announces **"Less than three minutes to record."** and your handsets display **Rec mem low.**
- If the answering system is off, you may press **ANS ON** on the telephone base to turn on the answering system during an incoming call. The answering system answers the call immediately if there is remaining time.

#### Using a handset:

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID** or **DIR** to highlight **Answering sys**, then press **SELECT**.
3. Press **CID** or **DIR** to highlight **Answer ON/OFF**, then press **SELECT**.
4. Press **CID** or **DIR** to highlight **On** or **Off**, then press **SET** to save. You hear a confirmation tone.




## Announcement

An announcement is the greeting callers hear when calls are answered by the answering system.

The telephone is preset with a greeting that answers calls with *“Hello, please leave a message after the tone.”* You can use this default announcement, or replace it with your own.

### Play your announcement

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID**▼ or **▲DIR** to highlight **Answering sys**, then press **SELECT**.
3. Press **SELECT** again to select **Announcement**.
4. The handset displays **ANNOUNCEMENT**. Press **PLAY**.



### Record your own announcement

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID**▼ or **▲DIR** to scroll to **Answering sys**, then press **SELECT**.
3. Press **SELECT** again to select **Announcement**.
4. The handset displays **ANNOUNCEMENT**. Press **RECORD**.
5. The handset announces, *“Record after the tone. Press STOP when you are done.”* After the tone, speak towards the microphone of the handset.
6. Press **STOP** when you finish recording.
7. The handset automatically plays back the newly recorded announcement. Press **STOP** to stop the playback at any time. After the announcement playback, press **PLAY** to replay the recorded announcement, or **RECORD** to record again if desired.



### NOTES:

- Your announcement can be up to 90 seconds in length.
- Announcements shorter than two seconds are not recorded.

## Delete your announcement

---

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID** or **DIR** to scroll to **Answering sys**, then press **SELECT**.
3. Press **SELECT** again to select **Announcement**.
4. The handset displays **ANNOUNCEMENT**, press **PLAY** to play the announcement.
5. While the announcement is playing, press **DELETE** to delete your own recorded announcement. The handset displays **Reset announcement to default?** Press **YES** to confirm. You hear a confirmation tone.



**i** **NOTE:** When your announcement is deleted, calls are answered with the default announcement. You cannot delete the default announcement.

## Answering system settings

In the answering system setup menu, you can change the settings for call screening, number of rings, remote access code and message alert tone and recording time.

### Call screening


---

The call screening feature lets you listen at the telephone base to a caller leaving a message. While monitoring an incoming message, you can answer the call by pressing **HOME/FLASH** or **SPEAKER** on the handset.

#### To change the settings:

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Use **CID** or **DIR** to scroll to **Answering sys**, then press **SELECT**.
3. Use **CID** or **DIR** to scroll to **Ans sys setup**, then press **SELECT** twice to select **Call screening**.
4. Press **CID** or **DIR** to choose between **On** and **Off**, then press **SET** to save. You hear a confirmation tone.

**NOTE:** For more information on call screening, see page 82.



# Answering system settings


## Number of rings

When the answering system is turned on, it answers all incoming home calls after the number of rings set. You can choose from 2, 3, 4, 5, or 6 rings; or toll saver. With toll saver selected, the answering system answers after 2 rings when you have new messages, and after four rings when you have no new messages.

This enables you to check for new messages and avoid paying unnecessary long distance charges if you are calling from out of your local area. The default number of rings is four.

### To set the number of rings:

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID** or **▲DIR** to highlight **Answering sys**, then press **SELECT**.
3. Press **CID** or **▲DIR** to highlight **Ans sys setup**, then press **SELECT**.
4. Press **CID** or **▲DIR** to highlight **# of rings**, then press **SELECT**.
5. Press **CID** or **▲DIR** to choose from **6, 5, 4, 3, 2** or **Toll saver**, then press **SET** to save. You hear a confirmation tone.



**i NOTE:** If you set the number of rings for the answering system as 2 or 3 rings, the caller ID announce feature may not have enough time to announce the caller's full information.

## Answering system settings

### Remote access code

A 2-digit security code is required to access the answering system remotely from any touch-tone telephone. The preset code is **19**. You can change the code to any number from **00** to **99**.

#### To change the remote code:

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Use **CID▼** or **▲DIR** to scroll to **Answering sys**, then press **SELECT**.
3. Use **CID▼** or **▲DIR** to scroll to **Ans sys setup**, then press **SELECT**.
4. Press **CID▼** or **▲DIR** to scroll to **Remote code**, then press **SELECT**.
5. Use the dialing keys (**0-9**) to enter a 2-digit number from **00-99**.
  - Press **MUTE/DELETE** to erase a digit.
  - Press and hold **MUTE/DELETE** to erase all digits.
  - Press **CID▼** or **▲DIR** to move the cursor to the right or left.
 Press **SET** to save. You hear a confirmation tone.



### Message alert tone

When the message alert tone is set to **On**, the telephone base beeps every 10 seconds to alert you to new messages. The tone stops when all new messages have been reviewed. The default message alert tone setting is **Off**.

#### To change the setting:

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Use **CID▼** or **▲DIR** to scroll to **Answering sys**, then press **SELECT**.
3. Use **CID▼** or **▲DIR** to scroll to **Ans sys setup**, then press **SELECT**.
4. Press **CID▼** or **▲DIR** to scroll to **Msg alert tone**, then press **SELECT**.
5. Press **CID▼** or **▲DIR** to choose between **On** and **Off**, then press **SET** to save your setting. You hear a confirmation tone.



**NOTE:** You cannot set the message alert tone when another handset or the telephone base is accessing the answering system.

## Recording time

---

You can set the recording time limit for each incoming message. The default setting is 3 minutes.

### To change the setting:

1. Press **MENU** on the handset when it is not in use.
2. Press **CID** or **DIR** to highlight **Answering sys**, then press **SELECT**.
3. Press **CID** or **DIR** to highlight **Ans sys setup**, then press **SELECT**.
4. Press **CID** or **DIR** to highlight **Recording time**, then press **SELECT**.
5. Press **CID** or **DIR** to choose from **3 minutes**, **2 minutes**, or **1 minute**, then press **SET** to save. You hear a confirmation tone.



## About the answering system

### **Answering system and voicemail**

---

Your telephone has separate indicators for two different types of voice messages: those recorded on its built-in answering system and those recorded in your service provider's voicemail (fees may apply). Your telephone's built-in answering system messages and voicemail messages are separate. Each alerts you to new messages differently.

If **OO** and **XX New messages** display on the handsets and the message window on the telephone base flashes, there are new messages in the built-in answering system. To listen to messages recorded on your digital answering system, press **▶/■/PLAY/STOP** on the telephone base. To listen to messages with a handset, see **To listen to messages with a handset** on page 85.

If **✉** and **New voicemail** display on the handsets, your telephone service provider is indicating that it has new voicemail for you. To listen to your voicemail, you typically dial an access number provided by your telephone service provider, followed by a security code or PIN.

Some service providers bundle or combine multiple services like voicemail and call waiting, so you may not be aware that you have voicemail. To check what services you have and how to access them, contact your telephone service provider.

To use your voicemail service rather than your answering system, turn off your answering system. To use your answering system rather than your voicemail service, contact your telephone service provider to deactivate your voicemail service.

### **Using the answering system and voicemail together**

---

You can also use your telephone answering system and voicemail together by setting your built-in answering system to answer before voicemail answers as described below. To learn how to program your voicemail settings, contact your telephone service provider. Then, if you are on a call, or if the answering system is busy recording a message and you receive another call, the second caller can leave a voicemail message.

Set your answering system to answer calls at least two rings earlier than your voicemail is set to answer. For example, if your voicemail answers after six rings, set your answering system to answer after four rings. Some voicemail providers may program the delay before answering calls in seconds instead of rings. In this case, allow six seconds per ring when determining the appropriate setting.

## About the answering system

### Message capacity

---

The answering system can record and store up to 99 messages. Each message can be up to 3 minutes in length depending on the message length set (see **Recording time** on page 80). The total storage capacity for the announcement, messages and memos is approximately 14 minutes. The actual recording time depends on individual message characteristics. Messages remain available for replay until you delete them.

### Voice prompts

---

The system provides voice prompts to guide you through the setup procedures at the telephone base, message playback, remote access and recording outgoing announcements.

### Call screening

---

#### Call screening at the telephone base


If the answering system and call screening are on (see **Call screening** on page 77), the announcement and the incoming message broadcast at the telephone base when a call arrives.

During message recording, press ►/■/**PLAY/STOP** repeatedly to turn call screening on and off for this call. Press ▼**VOLUME**▲ on the telephone base to adjust the message volume. To change the call screening setting for all calls, see page 77.

During call screening, press ►/■/**PLAY/STOP** on the telephone base to turn off the call screening. If the call screening is off and the answering system has answered a call, press ►/■/**PLAY/STOP** or **VOLUME**▲ to turn on the call screening.



#### Call screening at the handset:

If the answering system is on and your answering system is recording a message, press **SCREEN** to screen the call on your handset and the screen displays the caller ID information. If you do not subscribe to caller ID service, the handset shows **Incoming call**.

 **NOTE:** The call screening setting does not affect the call screening on the handset.

### Call intercept


---

When a caller is leaving a message on your answering system, you can stop recording and talk to the caller by pressing **HOME/FLASH** or **/SPEAKER** on the handset.

## About the answering system

### **Temporarily turning off the message alert tone**

---

Pressing any telephone base key (except /HANDSET LOCATOR) temporarily silences the message alert tone.

The message alert tone plays with the next incoming message.

If you press **X/DELETE** when in idle mode to temporarily turn off the message alert tone, there is a voice prompt directing you to press **X/DELETE** again to delete all old messages. The message alert tone is temporarily off. Only press **X/DELETE** a second time if you wish to erase all old messages in your answering system.

The message alert tone resumes when you receive a new message.

## Message playback

On the telephone base, if you have new messages, the telephone plays only the new messages in chronological order. If there are no new messages, the telephone plays back all messages in chronological order.

On the handset, if you have both new and old messages, you can play either new or old messages. The caller ID information displays on the handset screen when you play messages and you can call back the caller.

When playback begins, the handset screen displays the message status, caller ID information, and time and date of the message recorded. You hear the total number of messages followed by the day and time of the message. After the last message, the telephone announces, "*End of messages.*" and the screen displays **End of messages**.

### To listen to messages with the telephone base:

- Press ►/■/PLAY/STOP to listen to messages.

#### Options during playback:

- Press ▼VOLUME▲ to adjust the speaker volume.
- Press ►/SKIP to skip to the next message.
- Press ◀/REPEAT to repeat the message currently playing.  
Press ◀/REPEAT twice to listen to the previous message.
- Press X/DELETE to delete the current message. The system advances to the next message.
- Press ►/■/PLAY/STOP to stop.


## Message playback

### To listen to messages with a handset:

1. Press **MENU** in idle mode.
2. Press **SELECT** to select **Play messages**. If you have either new or old messages, the messages play automatically. If you have both new and old messages:
  - To play new messages, press **SELECT** to select **Play new msgs**.
  - To play old messages, press **CID▼** or **▲DIR** to highlight **Play old msgs**, then press **SELECT**.

When the handset is playing a message, its screen shows **[2]-Call info** and the caller's name or number. If the caller's information is unavailable, the handset shows **No caller info**.

### Options during playback:

- Press **EQ**  button to adjust the message playback audio quality.
- Press **⏪/SPEAKER** to play the messages through the handset earpiece.
- Press **CID▼/VOLUME/▲DIR** to adjust the speakerphone volume.
- Press **SKIP** to skip to the next message.
- Press **REPEAT** to repeat the message currently playing. Press **REPEAT** twice to listen to the previous message.
- Press **MUTE/DELETE** to delete the current message. The handset displays **Message deleted** briefly and the system advances to the next message.
- Press **2** to pause the playback and show the caller ID information. If necessary, press **#** (pound key) or **1** to show different dialing options. Press **🏠HOME/FLASH**, **DIAL** or **⏪/SPEAKER** to use the home line, or press **📶CELLULAR** to use the cell line to call back the caller. Press **🔒OFF/CANCEL** or **BACK** to resume the playback. If you do not call back within 10 seconds, message playback resumes.
- Press **🏠HOME/FLASH** or **📶CELLULAR** to pause the message playback. The handset displays **Call back?** with the caller ID information. Press **YES** to call back the caller, or **NO** to resume the message playback. If the dialing format used is not correct, then use the option above to choose the correct dialing format before calling back the caller.
- Press **🔒OFF/CANCEL** to stop.

### NOTES:

- When the answering system has less than three minutes of recording time left, it announces, *"Less than three minutes to record."* and the handset displays **Rec mem low**.
- When the telephone is not in use, if **F** and the number of messages are flashing alternately in the message window, or the handset displays **Rec mem full**, the memory is full. Delete some messages to make room for more.

# Message playback

## Delete all old messages

---

### Using the telephone base:

Press **X/DELETE** when the phone is not in use. The telephone announces, "To delete all old messages, press **DELETE** again." Press **X/DELETE** again. All previously reviewed messages are erased and the telephone announces, "All old messages deleted."

### Using a handset:

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID▼** or **▲DIR** to highlight **Answering sys**, then press **SELECT**.
3. Press **CID▼** or **▲DIR** to highlight **Delete all old**, then press **SELECT**.
4. The handset displays **Delete all old messages?** Then press **YES** to confirm.
5. The handset displays **Deleting...** and then **All old messages deleted!** You hear a confirmation tone.

**iNOTE:** You can only delete old messages, which are messages you have previously reviewed.



## Record and play memos

---

Memos are messages you record as reminders for yourself or others using the same answering system. You can record your own memos using a system handset. Play and delete them the same way as incoming messages.

### To record a memo:

1. Press **MENU** on the handset in idle mode to enter the main menu.
2. Press **CID▼** or **▲DIR** to highlight **Answering sys**, then press **SELECT**.
3. Press **CID▼** or **▲DIR** to highlight **Record memo**, then press **SELECT**.
4. The system announces, "Record after the tone. Press **STOP** when you are done." After the tone, speak towards the microphone.
5. Press **STOP** when you finish recording. The handset announces, "Recorded" and then returns to the previous menu.



### **iNOTES:**

- The system announces "Memory is full," if you attempt to record a memo when the memory is full.
- Each memo can be up to 4 minutes in length.
- Memos shorter than two second are not recorded.

## Base message counter displays

### Message window displays

0	No messages.
0 (flashing)	The time and date need to be set.
0-6	The telephone base ringer level while adjusting.
1-8	The telephone base speaker volume level while adjusting.
1-99	Total number of old messages and memos recorded. The message number currently playing.
0-99 (flashing)	Total number of messages and memos. The number flashes when there are new or missed messages. After a power failure, the number in the message counter flashes to indicate that you need to set the clock.
1-99 & F (alternating)	The answering system memory is full with total number of messages recorded.
.... ..	The system is answering a call, or recording a memo or announcement. The telephone is being accessed remotely. The answering system is being programmed.

















## Remote access

You can access the answering system remotely by dialing your home telephone number from any touch-tone telephone.

### To remotely access the answering system

1. Dial your telephone number from any touch-tone telephone.
2. When the system plays your announcement, enter the 2-digit remote access code (**19** is the preset code, see page 79 to change it).
3. You can also enter the remote commands (see **Remote commands** below).
4. Hang up or press **8** to end the call and save all undeleted messages.

### Remote commands

	Press to listen to all messages.
	Press to listen to new messages only.
	Press to delete the current message (during playback).
 	Press twice to delete all old messages.
	Press to repeat the current message (during playback).
 	Press twice to listen to the previous message.
	Press to stop.
 	Press to listen to a list of remote commands.
	Press to skip to the next message (during playback).
 	Press to record a new announcement.
	Press to hang up the call.
	Press to turn the answering system on or off.

### NOTES:

- If you do not press any keys after you enter the remote access code, all new messages play. If there are no new messages, all old messages play.
- Once the new messages have played, the telephone announces the help menu options. If you do not press any key within 20 seconds, the remote access call automatically disconnects.
- When the answering system is turned off, the telephone answers after 10 rings, and announces, *"Please enter your remote access code."*
- When the memory is full, the answering system answers incoming calls after 10 rings and announces, *"Memory is full. Enter the remote access code."*

Appendix  
Handset screen icons



	<b>HOME</b> line - On steadily when the home line is in use or there is an incoming home call.
	<b>CELL</b> line- On steadily when a cell line is in use or there is an incoming cell call.
	<b>Bluetooth connected devices</b> - There are Bluetooth connected devices on the active devices list.
	<b>Bluetooth disconnected devices</b> - There are Bluetooth disconnected devices on the active devices list.
	<b>Wireless Bluetooth headset</b> - On steadily when a wireless Bluetooth headset is in use on the home line.
	<b>Battery status</b> - Battery is low; place handset in telephone base or charger to recharge.
	<b>Battery status</b> - Battery is charging.
	<b>Speakerphone</b> - The speakerphone is in use.
	<b>Ringer off</b> - On steadily if the home and cell ringers are turned off. Flashes if only one ringer is turned off.
	<b>New voicemail</b> - New voicemail received from your telephone service provider.
	<b>Answering system on</b> - The answering system is turned on.
	<b>New answering system message</b> - New message in the answering system.
	<b>New caller ID log</b> - Missed and new calls.
	<b>Mute</b> - Microphone is muted.

# Appendix

## Alert tones and lights

### Handset alert tones

Two short beeps	You are pressing <b>CID</b> ▼ or <b>▲DIR</b> when the volume is already at its highest or lowest setting. <b>-OR-</b> You have reached the end of the caller ID history.
Three short high-pitched beeps	The telephone has completed the command successfully.
Four short beeps	Low battery warning. <b>-OR-</b> Out of range while the handset is on a call.

### Telephone base alert tones

Beeps once every 10 seconds	Message alert.
Two short beeps	Registration slots are full.
Four short beeps	Registration failure.

### Handset indicator lights



#### CHARGE light

On when the handset is charging in the telephone base or charger.

#### Backlight (lighted display and dial pad)

On when the handset is lifted from the telephone base or charger.

On when a key is pressed.

#### )/SPEAKER light

On when the speakerphone is in use.

### Telephone base indicator lights

#### IN USE light

On when the handset is in use, or when the answering system is answering an incoming call, or when you are registering a handset.

Flashes when another telephone is in use on the same line, or when you are deregistering handset(s) from the telephone base.

Flashes quickly when there is an incoming home call.

#### ANSWER ON light

On when the answering system is on.



#### DEVICE1/DEVICE2 lights

On when the telephone base is paired and connected with a Bluetooth device.

Flash alternately while pairing a Bluetooth device.

Flashes quickly when there is an incoming cell call.

## Screen messages

**Display screen messages**

Already saved	The telephone number you have entered is already stored in the directory.
Bluetooth system busy	You are trying to make a cell call or access the Bluetooth menu when the Bluetooth link is already being used.
Caller ID log empty	There are no entries in the caller ID history.
Call transferred	An outside call from one handset is transferred to another handset.
Calling HANDSET X (For models with more than two handsets)	The handset is calling another handset (for intercom calls).
Calling other handset (For models with two handsets only)	The handset is calling the other handset (for intercom calls). The handset is going to transfer an outside call to the other handset.
Cell	The cell line is on a call.
Cell call on hold	A call on the cell line has been put on hold.
Cell line in use	Another system handset is using the cell line.
Connecting...	The telephone base is trying to establish connection with a Bluetooth device.
Connection failed	A Bluetooth device in the paired or active devices list fails to establish connection with your telephone system.
Directory empty	There are no directory entries.
Directory full	The directory is full. You cannot save any new entries unless you delete some current entries.
Downloading dir	The system is downloading a directory from a cell phone.
Ended	You have just ended a call.
HANDSET X is calling (For models with more than two handsets)	Another system handset is calling.
Home	The home line is on a call.
Home call on hold	A call on the home line has been put on hold.
Home & cell calls on hold	Calls on the home and cell lines have been put on hold.
Home & cell lines in use	Calls on the home and cell lines are being used.

## Screen messages

Home line in use	A system handset or another telephone on the same home line is in use.
Incoming call	There is a call coming in.
Intercom	The handset is on an intercom call.
Intercom ended	The intercom call has just ended.
Low battery	The battery needs to be charged.
Microphone off	The handset microphone is off. The other party cannot hear you but you can hear the other party.
Microphone on	The handset microphone is on.
New voicemail	There are new voicemail messages from your telephone service provider.
No answer. Try again.	You tried to make an intercom call, but the handset you are calling is busy or out of range.
No battery	The battery is not properly installed and the handset is in the telephone base or charger.
No caller info	The caller information is not available.
No entries found. Download from SIM only?	There are no entries found when you download a cell phone directory from the cell memory.
No entries found. Download from Phone only?	There are no entries found when you download a cell phone directory from your SIM card.  There are no entries found in either the cell or SIM card when you download a cell phone directory from both memories.
No connected cellular phones	There is no cellular phone connected to the base.
No home line	There is no telephone line connected.
No Incoming PTT	The incoming PTT function is turned off. The handset will not receive PTT calls.
No message	There is no message recorded on the answering system.
No signal, call ended	The phone lost connection with the telephone base or does not have a strong enough signal and the phone call ended.
Not available at this time	Someone else is already using the directory or caller ID history on another handset.

## Screen messages

Other handset is calling (For models with two handsets only)	The other handset is calling.
Out of range OR No power at base	The handset has lost communication with the telephone base. There is no power connected to the telephone base.
** Paging **	The telephone base is paging all handsets.
Place in charger	The battery is very low. The handset should be placed in the telephone base or charger.
PTT From HANDSET X To handset Y	One handset has started a PTT session to another handset.
PTT To HANDSET X	You have started the PTT process.
Push to talk Ended	The PTT session is ended.
Put handset on BASE to register	Your handset is not registered to the telephone base.
Rec mem full	The answering system has no recording time left.
Ringer muted	The ringer is muted temporarily during an incoming call.
Rec mem low	The answering system has less than three minutes to record.
Registration slots are full	The telephone base already has the maximum of 12 handsets registered to it.
Saved	The entry is now saved in the directory.
Unable to save	You are trying to save an entry with no name and number from the caller ID history.
XX Missed calls	There are new calls in the caller ID history.
XX New messages	There are new messages recorded in the answering system.

## Expand your telephone system

Your telephone can support up to 12 cordless handsets. The handset must be registered to the telephone base before use. You must register each handset separately.

The handsets provided within your product box are already registered as **HANDSET 1** and so forth. Additional handsets are assigned numbers in the sequential order they are registered (up to **HANDSET 12**).

### Add and register a handset (optional)

You can add new handsets (**TL90071**, purchased separately) to your telephone system, but each handset must be registered with the telephone base before use. When first purchased, each expansion handset shows **Put handset on BASE to register** after a battery is installed. Each handset should be charged without interruption for at least 30 minutes before registering to the telephone base. For more details on battery charging, see the table on page 9.

#### To register a handset:

1. Make sure the handset shows **Put handset on BASE to register**.
2. Put the handset you wish to register on the telephone base cradle.
3. The handset displays **Registering handset...** on the handset and the red **IN USE** light on the telephone base turns on. It takes about 90 seconds to complete the registration process. The handset displays **HANDSET X Registered** (**X** represents the registered handset number). The **IN USE** light turns off and the handset beeps when registration completes.

If registration fails, it will automatically try to register again. If it fails after the third try, the handset shows **Registration failed**, then **Put handset on BASE to register**. This may take up to 5 minutes to occur. When the handset displays **Put handset on BASE to register**, please start again from Step 1 above.

#### NOTES:

- You cannot register a handset if any other system handset is in use.
- If you try to register more than 12 handsets to the telephone base, the telephone base shows **Registration slots are full** and sounds 2 beeps.



For registration, put the handset on the telephone base, not the handset charger.

## Deregister handsets

If you want to replace a handset or reassign the designated handset number of a registered handset, you must deregister all the handsets and then individually register each handset.

To make deregistration easier, read all of the instructions on this page before you begin.

### To deregister all handsets:

1. Make sure that all handsets are out of the telephone base and chargers before you begin deregistration.
2. Press and hold **📞/HANDSET LOCATOR** on the telephone base for about 10 seconds until the **IN USE** light flashes, then release **📞/HANDSET LOCATOR**.
3. Quickly press **📞/HANDSET LOCATOR** again while the **IN USE** light is still flashing. The **IN USE** light flashes for about seven seconds. If the light stops flashing, start again with Step 1 above.
4. All system handsets show **Put handset on BASE to register** and you hear a confirmation tone when the deregistration completes. The deregistration process takes about 10 seconds to complete.
5. After deregistering, register each handset again individually. See **Adding and registering handsets** on page 94.



### **i**NOTES:

- You cannot deregister the handsets if any other system handset is in use.
- Even if the battery is depleted, you can still deregister the handsets by following the steps above.
- If the deregistration process fails, you may need to reset the system and try again. To reset, unplug the power from the telephone base and plug it back in.

## Troubleshooting

If you have difficulty with your telephone, please try the suggestions below. For Customer Service, or to purchase accessories or replacement parts, visit our website at **www.telephones.att.com**, or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.

### **I cannot add my cell phone to the telephone base.**

- Make sure you have cellular coverage.
- Make sure the Bluetooth function of your cell phone is turned on. See the user's manual of your cell phone for more information.
- Make sure that you set your cell phone to search for devices.
- If the **TL92271/TL92371/TL92471** is in your cell phone device history list, delete it and try pairing again.
- Carefully follow the pairing instructions on page 14 and make sure that your cell phone is not connected to any other Bluetooth device.
- Turn off your cell phone, then turn it on again.
- Reset the telephone base. Unplug the unit's electrical power. Wait for approximately 15 seconds, then plug it back in. Repeat the above suggestions.

### **I cannot add my headset to the telephone base.**

- Make sure that your Bluetooth headset is in discoverable mode when pairing with the telephone base. See the user's manual of your headset for more information on how to set your headset to discoverable mode.
- Carefully follow the pairing instructions on page 16 and make sure that your headset is not connected to any other Bluetooth device.
- Reset the telephone base. Unplug the unit's electrical power. Wait for approximately 15 seconds, then plug it back in. Repeat the above suggestions.

### **I cannot connect my cell phone with the telephone base.**

- Make sure that the Bluetooth function of your cell phone is turned on. See the user's manual of your cell phone for more information.
- Make sure that your Bluetooth cell phone is not connected to any other Bluetooth device.
- Turn off your cell phone, then turn it on again.
- Make sure that your cell phone is on the paired devices list.
- For some cell phones, you must authorize the **TL92271/TL92371/TL92471** in your cell phone's Bluetooth settings. See the user's manual of your cell phone for more information.
- Manually connect your cell phone to the **TL92271/TL92371/TL92471**. Refer to the user's manual of your cell phone for more information.

## Troubleshooting

### **I cannot connect my headset with the telephone base.**

- Make sure that your Bluetooth headset is not connected to any other Bluetooth device.
- Make sure that your headset is on the paired devices list.

### **I cannot put my headset in discoverable mode.**

- Refer to the user's manual of your headset for information on how to set your headset to discoverable mode.
- Make sure that the headset is not connected to any other Bluetooth device in order to successfully pair and connect to the telephone base.
- Carefully follow the pairing process on page 16.
- Reset the telephone base. Unplug the unit's electrical power. Wait for approximately 15 seconds, then plug it back in. Repeat the above suggestions.

### **I don't know how to search for or add new devices on my cell phone.**

- Most cell phones have the Bluetooth feature in the connection or setup menus. Please refer to the user's manual of your cell phone.
- In general, press the menu key on your cell phone, then look for the Bluetooth menu in the settings or connection menu. In the Bluetooth menu, select the option to search for or add new devices.

### **My cell phone disconnects with the telephone base.**

- Turn off your cell phone, then turn it on again.
- Make sure that you are not using your cell phone when on a cell call.

### **My cell phone is connected to the telephone base, but I cannot make a cell call.**

- Make sure that your cell phone is not in use when you are trying to make a cell call.
- For some smartphones, make sure that the cellular function is turned on.

### **Bluetooth system busy appears on the display.**

- Make sure that your cell phone is not in use when connected and on the active devices list.
- Make sure that your cell phone or headset is not connected to any other Bluetooth device.
- **TL92271/TL92371/TL92471** can only use one Bluetooth device at a time.

## Troubleshooting

### **The PIN on the telephone base does not work.**

- The default PIN is **0000**.
- If you have changed the PIN, it will appear on the handset in the pairing process.

### **I cannot hear any audio on my telephone system when on a cell call.**

- Reset the telephone base. Unplug the unit's electrical power. Wait for approximately 15 seconds, then plug it back in.
- Turn off your cell phone, then turn it on again.

### **I cannot download contacts from my cell phone to my TL92271/TL92371/TL92471.**

- Make sure that your cell phone is paired and connected to the base.
- Make sure you place your cell phone next to the base while downloading.
- If your cell phone does not support the download, you can send the directory from your cell phone. The system can receive the directory automatically. See the user's manual of your cell phone for more information.

### **I see duplicate entries in my downloaded directory.**

- If you see duplicate directory entries, you can delete them manually. Another option is to download again from either your SIM card or phone memory, but not both.

### **Some of my cell phone contacts were not imported to my TL92271/TL92371/TL92471.**

- Make sure to try copying the contacts from your SIM card to your cell phone memory first, then download from your phone memory. If that doesn't work, try copying the contacts from your cell phone memory to your SIM card, then download from your SIM card. For more information on how to transfer contacts between your SIM card and your phone memory, refer to the user's manual of your cell phone.

### **Can the TL92271/TL92371/TL92471 help the poor cell phone reception in my house?**

- If your cell phone has poor reception in your home, the **TL92271/TL92371/TL92471** cannot improve the reception. However, if you have a location in your house with better reception, you can leave your cell phone in that location while you use **TL92271/TL92371/TL92471** cell line. In order for this to work, the cell phone must be within 30 feet of the telephone base for optimal performance.

## Troubleshooting

### **The listening volume of my cell call is too loud or quiet.**

- During a cell call, if the listening volume is too loud or quiet, try changing the volume on your cell phone. On some cell phones, changing the volume on the cell phone affects your cell call volume on the **TL92271/TL92371/TL92471** handset.

### **My telephone doesn't work at all.**

- Make sure the power cord is securely plugged in.
- Make sure that the battery connector is securely plugged into the cordless handset.
- Make sure the telephone line cord is securely and firmly plugged into the telephone base and the telephone wall jack.
- Charge the battery in the cordless handset for at least 16 hours. For optimum daily performance, return the cordless handset to the telephone base or charger when not in use.
- If the battery is depleted, charge the handset for at least 30 minutes before you use it. Refer to page 9 for details.
- Reset the telephone base. Unplug the electrical power. Wait for approximately 15 seconds, then plug it back in. Allow up to one minute for the cordless handset and telephone base to reset.
- You may need to purchase a new battery. Please refer to **Battery installation and charging** (pages 8-9) in this user's manual.

### **I cannot get a dial tone.**

- Try all the suggestions above.
- Move the cordless handset closer to the telephone base. You might have moved out of range.
- Disconnect the telephone base from the telephone jack and connect to a different phone. If there is no dial tone on that phone either, the problem is in your wiring or telephone service. Contact your telephone service provider (charges may apply).
- Your line cord may be defective. Install a new telephone line cord.

## Troubleshooting

### **I cannot dial out.**

- Try all the suggestions in **I cannot get a dial tone** on the previous page.
- Make sure you have a dial tone before dialing. The cordless handset may take a second or two to find the telephone base and produce a dial tone. This is normal. Wait an extra second before dialing.
- Eliminate any background noise. Noise from a television, radio or other appliances may cause the phone to not dial out properly. If you cannot eliminate the background noise, first try muting the cordless handset before dialing, or dialing from another room in your home with less background noise.
- Disconnect the telephone base from the telephone wall jack and plug in a working telephone. If the other phones in your home are having the same problem, the problem is in your wiring or telephone service. Contact your telephone service provider (charges may apply).

### **My cordless handset isn't performing normally.**

- Make sure the power cord is securely plugged into the telephone base. Plug the power adapter into a different, working electrical outlet not controlled by a wall switch.
- Move the cordless handset closer to the telephone base. You might have moved out of range.
- Reset the telephone base. Unplug the electrical power. Wait for 15 seconds then plug it back in. Allow up to one minute for the cordless handset and telephone base to reset.
- Other electronic products such as HAM radios and other DECT phones can cause interference to your cordless telephone. Try installing your telephone as far away as possible from these types of electronic devices.

### **The handset registration is unsuccessful.**

Follow the steps below to re-register the handset.

1. Make sure the handset is out of the telephone base or charger and shows **Put handset on BASE to register** before you begin registration.
2. Place the handset you wish to register on the telephone base cradle. The handset displays **Registering handset...** on the handset and the red **IN USE** light on the telephone base turns on. It takes about 90 seconds to complete the registration process. The handset displays **HANDSET X Registered** (X represents the registered handset number). The **IN USE** light turns off and the handset beeps when registration completes.

Refer to the **Add and register a handset** section on page 94 for details.

## Troubleshooting

### **Out of range OR No power at base appears on my cordless handset.**

- Ensure that the telephone base is powered up.
- Place the cordless handset in the telephone base for one minute to allow the cordless handset and base to synchronize.
- Move the cordless handset closer to the telephone base. You might have moved out of range.
- Reset the telephone base. Unplug the electrical power. Wait for 15 seconds then plug it back in. Allow up to one minute for the cordless handset and telephone base to reset.
- Other electronic products such as HAM radios and other DECT phones can cause interference to your cordless telephone. Try installing your telephone as far away as possible from these types of electronic devices.

### **The batteries do not hold a charge.**

- If the cordless handset is in the telephone base or charger and the charge light does not come on, refer to **The charge light is off** (page 104) in this **Troubleshooting** guide.
- Charge the battery in the cordless handset for at least 16 hours. For optimum daily performance, return the cordless handset to the telephone base or charger when not in use.
- If the battery is depleted, it may take approximately 30 minutes to charge the handset before it shows **Low battery**, refer to page 9 for details.
- You may need to purchase a new battery. Please refer to **Battery installation and charging** (pages 8-9) in this user's manual.

### **I get noise, static, or a weak signal even when I'm near the telephone base.**

- If you subscribe to high-speed Internet service (digital subscriber line - DSL) through your telephone lines, you must install a DSL filter between the telephone line cord and the telephone wall jack (see page 6). The filter prevents noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters.
- You may be able to improve the performance of your cordless phone by installing your new telephone base as far as possible from any other existing cordless telephone system that may already be installed.
- Other electronic products such as HAM radios and other DECT phones can cause interference to your cordless telephone. Try installing your telephone as far away as possible from these types of electronic devices.
- Do not install this phone near a microwave oven or on the same electrical outlet. You may experience decreased performance while the microwave oven is operating.

## Troubleshooting

- If your phone is plugged in with a modem or a surge protector, plug the phone (or modem/surge protector) into a different location. If this doesn't solve the problem, relocate your phone or modem farther apart from one another, or use a different surge protector.
- Relocate your phone to a higher location. The phone may have better reception when installed in a high area.
- Disconnect the telephone base from the telephone wall jack and plug in a working telephone. If the other phones in your home are having the same problem, the problem is in your wiring or telephone service. Contact your telephone service provider (charges may apply).


### **I experience poor sound quality when using the speakerphone.**

- For increased sound quality while using the speakerphone, place the handset on a flat surface with the dial pad facing up.
- When using a speakerphone, controlling background noise in your environment is essential. While you are listening to your party, press **MUTE/DELETE** to temporarily turn your microphone off. When it is your turn to speak, remember to press **MUTE/DELETE** again to turn the microphone on.
- Excessive background noise will cause a speakerphone to fade in and out. Try controlling the background noise by turning off any audio devices near the speakerphone. Also, try to avoid interrupting the person at the other end of the conversation while they are speaking. If background noise cannot be controlled, you should terminate speakerphone operation and return to normal handset mode.

### **I hear other calls while using my phone.**

- Disconnect the telephone base from the telephone wall jack and plug in a working telephone. If the other phones in your home are having the same problem, the problem is in your wiring or telephone service. Call your telephone service provider (charges may apply).

### **While on a call or playing messages, there is too much noise, or the voice sounds tinny, shrill or flat.**

- While on a call or playing messages, press the **EQ**  button on the handset until you find the setting that sounds best (page 45).

## Troubleshooting

### **My cordless handset does not ring when I receive a call.**

- Make sure that the ringer is not turned off. Refer to **Ringer volume** on page 26 in this user's manual.
- Make sure the telephone line cord is plugged securely into the telephone base and the telephone jack. Make sure the power cord is securely plugged in.
- The cordless handset may be too far from the telephone base.
- Charge the battery in the cordless handset for at least 16 hours. For optimum daily performance, return the cordless handset to the telephone base or charger when not in use.
- You may have too many extension phones on your telephone line to allow all of them to ring simultaneously. Try unplugging some of the other phones.
- The layout of your home or office might be limiting the operating range. Try moving the telephone base to another location, preferably to a higher location.
- Disconnect the telephone base from the telephone wall jack and plug in a working telephone. If the other phones in your home are having the same problem, the problem is in your wiring or telephone service. Contact your telephone service provider (charges may apply).
- Test a working phone at the phone jack. If another phone has the same problem, the problem is the phone jack. Contact your telephone service provider (charges may apply).
- Other electronic products such as HAM radios and other DECT phones can cause interference to your cordless telephone. Try installing your telephone as far away as possible from these types of electronic devices.
- Completely remove the battery. Replace the battery and place the cordless handset in the telephone base. Wait for the cordless handset to reestablish its connection with the telephone base. Allow up to one minute for this to take place.
- Your line cord might be defective. Try installing a new line cord.

## Troubleshooting

### **My calls cut in and out while I'm using my cordless handset.**

- Other electronic products such as HAM radios and other DECT phones can cause interference to your cordless telephone. Try installing your telephone as far away as possible from these types of electronic devices.
- Do not install this phone near a microwave oven or on the same electrical outlet. You may experience decreased performance while the microwave oven is operating.
- If you plug your phone in with a modem or surge protector, plug the phone (or modem/surge protector) into a different location. If this doesn't solve the problem, relocate your phone or modem farther apart from one another, or use a different surge protector.
- Relocate your telephone base to a higher location. The phone may have better reception when installed in a high area.
- Disconnect the telephone base from the telephone wall jack and plug in a working telephone. If the other phones in your home are having the same problem, the problem is in your wiring or telephone service. Contact your telephone service provider (charges may apply).
- Excessive background noise will cause a speakerphone to fade in and out. Try controlling the background noise by turning off any audio devices near the speakerphone. Also, try to avoid interrupting the person at the other end of the conversation while they are speaking. If background noise cannot be controlled, you should stop speakerphone operation and return to normal handset mode.
- When using a speakerphone, controlling background noise in your environment is essential. While you are listening to your party press **MUTE/DELETE** to temporarily turn your microphone off. When it is your turn to speak, remember to press **MUTE/DELETE** to turn the microphone on.

### **The charge light is off.**

- Make sure the power and line cords are plugged in correctly and securely.
- Unplug the electrical power. Wait for 15 seconds, then plug it back in. Allow up to one minute for the cordless handset and telephone base to reset.
- Clean the cordless handset and telephone base charging contacts each month using a pencil eraser or cloth.

## Troubleshooting


### **My caller ID isn't working.**

- Caller ID is a subscription service. You must subscribe to this service from your telephone service provider for this feature to work on your phone.
- The caller must be calling from an area that supports caller ID.
- Both your and your caller's telephone service providers must use caller ID compatible equipment.
- If you subscribe to high-speed Internet service (digital subscriber line - DSL) through your telephone lines, you must install a DSL filter between the telephone line cord and the telephone wall jack (see page 6). The filter prevents noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters.

### **System does not receive caller ID when on a call.**

- Make sure you subscribe to caller ID with call waiting features provided by your telephone service provider. Caller ID features work only if both you and the caller are in areas offering caller ID service, and if both telephone companies use compatible equipment.

### **An icon and New voicemail show on the display and I don't know why.**

- Your telephone has voicemail indication that is separate from the built-in answering system. If  appears on the display, then your telephone has received a signal from your telephone service provider that you have a voicemail message waiting for you to retrieve from your telephone service provider. Contact your telephone service provider for more information on how to access your voicemail.

### **I cannot retrieve voicemail messages.**

- Your telephone has both a built-in answering system and voicemail indication. They are independent features and each alerts you to new messages differently (page 81). If you subscribe to voicemail service from your telephone service provider (charges may apply), contact your telephone service provider for more information on how to access your voicemail.

### **I am receiving incomplete messages.**

- If a caller leaves a very long message, part of it may be lost when the system disconnects the call after the maximum recording time you have set (page 80).
- If the caller pauses for longer than seven seconds, the system stops recording and disconnects the call.
- If the system's memory becomes full during a message, the system stops recording and disconnects the call.
- If the caller's voice is very soft, the system may stop recording and disconnect the call.

## Troubleshooting

### **I am having difficulty hearing messages.**

- Press **VOLUME▲** to increase speaker volume on the telephone base.
- Press **VOLUME▲** to increase the listening volume on a handset.

### **System does not answer after correct number of rings.**

- Make sure the answering system is on. When the answering system is on, **ANS ON** should show on the handset and the **ANS ON** light is lit on the telephone base (page 74).
- If toll saver is selected, the number of rings changes to two when there are new messages waiting (page 78).
- If the memory is full or the system is off, the system answers after 10 rings.
- In some cases, the answering system is affected by the ringing system used by the telephone service provider.
- If you subscribe to voicemail service, change the number of rings so that your answering system answers before your voicemail answers (page 81). To determine how many rings activate your voicemail, please contact your telephone service provider.
- If there is a fax machine connected to the same telephone line, try disconnecting the fax machine. If that solves the problem, consult your fax machine documentation for information on compatibility with answering systems.

### **The answering system announces “Time and day not set.”**

- You need to set the date and time (page 28).

### **System does not respond to remote commands.**

- Make sure to enter your remote access code correctly (page 88).
- Make sure you are calling from a touch-tone phone. When you dial a number, you should hear tones. If you hear clicks, the phone is not a touch-tone telephone and cannot activate the answering system.
- The answering system may not detect the remote access code while your announcement is playing. Try waiting until the announcement is over before entering the code.
- There may be interference on the phone line you are using. Press the dial pad keys firmly.

## Troubleshooting

### **The answering system does not record messages.**

- Make sure the answering system is on (page 74).
- Make sure the memory of the answering system is not full. When the answering machine memory is full, it does not record new messages until some old messages are deleted.
- If you subscribe to voicemail service, change the number of rings so that your answering system answers before your voicemail answers (page 81). To determine how many rings activate your voicemail, please contact your telephone service provider.
- If there is a fax machine connected to the same telephone line, try disconnecting the fax machine. If that solves the problem, consult your fax machine documentation for information on compatibility with answering systems.

### **The outgoing announcement is not clear.**

- When you record your announcement, make sure you speak in a normal tone of voice towards the microphone of the handset.
- Make sure there is no background noise (TV, music, etc.) while recording.

### **I subscribe to a nontraditional telephone service that uses my computer to establish connections, and my telephone doesn't work.**

- Make sure your computer is powered on.
- Make sure your Internet connection is working properly.
- Make sure that the software is installed and running for your nontraditional telephone service.
- Make sure to plug your USB telephone adapter into a dedicated USB port on your computer. Do not plug into a multiple port USB hub (USB splitter) that is not powered.
- In a few rare instances, the USB port on your computer may not have enough power. In these instances, try using a USB hub with its own external power supply.
- If you are using a firewall, it may prevent access to your nontraditional telephone service provider. Contact your service provider for more information.

## **Common cure for electronic equipment:**

If the telephone is not responding normally, try resetting the telephone. Do the following in the order listed:

1. Disconnect the power to the telephone base.
2. Disconnect the cordless handset battery, and spare battery, if applicable.
3. Wait a few minutes.
4. Connect power to the telephone base.
5. Completely remove the battery. Replace the battery and place the cordless handset into the telephone base.
6. Wait for the cordless handset to reestablish its connection with the telephone base. Allow up to one minute for this to take place.

## Maintenance

### **Taking care of your telephone**

- Your cordless telephone contains sophisticated electronic parts, so it must be treated with care.
- Avoid rough treatment.
- Place the handset down gently.
- Save the original packing materials to protect your telephone if you ever need to ship it.

### **Avoid water**

- Your telephone can be damaged if it gets wet. Do not use the handset in the rain, or handle it with wet hands. Do not install the telephone base near a sink, bathtub or shower.

### **Electrical storms**

- Electrical storms can sometimes cause power surges harmful to electronic equipment. For your own safety, take caution when using electric appliances during storms.

### **Cleaning your telephone**

- Your telephone has a durable plastic casing that should retain its luster for many years. Clean it only with a soft cloth slightly dampened with water or mild soap.
- Do not use excess water or cleaning solvents of any kind.

Remember that electrical appliances can cause serious injury if used when you are wet or standing in water. If the telephone base should fall into water, DO NOT RETRIEVE IT UNTIL YOU UNPLUG THE POWER CORD AND TELEPHONE LINE CORDS FROM THE WALL. Then pull the telephone out by the unplugged cords.

# Important safety information



This symbol is to alert you to important operating or servicing instructions that may appear in this user's manual. Always follow basic safety precautions when using this product to reduce the risk of injury, fire, or electric shock.

## Safety information

- Read and understand all instructions in the user's manual. Observe all markings on the product.
- Avoid using a telephone during a thunderstorm. There might be a slight chance of electric shock from lightning.
- Do not use a telephone in the vicinity of a gas leak. Under certain circumstances, a spark may be created when the adapter is plugged into the power outlet, or when the handset is replaced in its cradle. This is a common event associated with the closing of any electrical circuit. The user should not plug the phone into a power outlet, and should not put a charged handset into the cradle, if the phone is located in an environment containing concentrations of flammable or flame-supporting gases, unless there is adequate ventilation. A spark in such an environment could create a fire or explosion. Such environments might include: medical use of oxygen without adequate ventilation; industrial gases (cleaning solvents; gasoline vapors; etc.); a leak of natural gas; etc.
- Do not use this product near water, or when you are wet. For example, do not use it in a wet basement or shower, or next to a swimming pool, bathtub, kitchen sink, or laundry tub. Do not use liquids or aerosol sprays for cleaning. If the product comes in contact with any liquids, unplug any line or power cord immediately. Do not plug the product back in until it has dried thoroughly.
- Install this product in a protected location where no one can trip over any line or power cords. Protect cords from damage or abrasion.
- If this product does not operate normally, read the **Troubleshooting** section on pages 96-108 of this user's manual. If you cannot solve the problem, or if the product is damaged, refer to the **Limited warranty** section on pages 114-115. Do not open this product except as may be directed in your user's manual. Opening the product or reassembling it incorrectly may expose you to hazardous voltages or other risks.
- Replace batteries only as described in your user's manual (pages 8-9). Do not burn or puncture batteries — they contain caustic chemicals.
- The power adapters are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.



**CAUTION:** Use only the power adapter provided with this product. To obtain a replacement, visit our website at [www.telephones.att.com](http://www.telephones.att.com), or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.

## Especially about cordless telephones

---

- **Privacy:** The same features that make a cordless telephone convenient create some limitations. Telephone calls are transmitted between the telephone base and the handset by radio waves, so there is a possibility that your cordless telephone conversations could be intercepted by radio receiving equipment within range of the cordless handset. For this reason, you should not think of cordless telephone conversations as being as private as those on corded telephones.
- **Electrical power:** The telephone base of this cordless telephone must be connected to a working electrical outlet which is not controlled by a wall switch. Calls cannot be made from the handset if the telephone base is unplugged, switched off or if the electrical power is interrupted.

## Important safety information

- Potential TV interference: Some cordless telephones operate at frequencies that may cause interference to TVs and VCRs. To minimize or prevent such interference, do not place the telephone base of the cordless telephone near or on top of a TV or VCR. If interference is experienced, moving the cordless telephone farther away from the TV or VCR will often reduce or eliminate the interference.
- Rechargeable batteries: This product contains nickel-metal hydride rechargeable batteries. Exercise care in handling batteries in order not to create a short circuit with conductive material such as rings, bracelets, and keys. The battery or conductor may overheat and cause harm. Observe proper polarity between the battery and the battery charger.
- Nickel-metal hydride rechargeable batteries: Dispose of these batteries in a safe manner. Do not burn or puncture. Like other batteries of this type, if burned or punctured, they could release caustic material which could cause injury.



The RBRC™ Seal means that the manufacturer is voluntarily participating in an industry program to collect and recycle nickel-metal hydride rechargeable batteries when taken out of service within the United States. These batteries may be taken to a participating local retailer of replacement batteries or recycling center. Or you may call 1 (800) 8-BATTERY for locations accepting spent Ni-MH batteries.

### **Precautions for users of implanted cardiac pacemakers**

---

Cardiac pacemakers (applies only to digital cordless telephones): Wireless Technology Research, LLC (WTR), an independent research entity, led a multidisciplinary evaluation of the interference between portable wireless telephones and implanted cardiac pacemakers. Supported by the U.S. Food and Drug Administration, WTR recommends to physicians that:

#### **Pacemaker patients**

---

- Should keep wireless telephones at least six inches from the pacemaker.
- Should NOT place wireless telephones directly over the pacemaker, such as in a breast pocket, when it is turned ON.
- Should use the wireless telephone at the ear opposite the pacemaker.

WTR's evaluation did not identify any risk to bystanders with pacemakers from other persons using wireless telephones.

#### **Especially about telephone answering systems**

---

Two-way recording: This unit does not sound warning beeps to inform the other party that the call is being recorded. To ensure that you are in compliance with any federal or state regulations regarding recording a telephone call, you should start the recording process and then inform the other party that you are recording the conversation.

## **SAVE THESE INSTRUCTIONS**

## Appendix FCC Part 68 and ACTA

This equipment complies with Part 68 of the FCC rules and with technical requirements adopted by the Administrative Council for Terminal Attachments (ACTA). The label on the back or bottom of this equipment contains, among other things, a product identifier in the format US: AAAEQ##TXXXX. This identifier must be provided to your telephone service provider upon request.

The plug and jack used to connect this equipment to premises wiring and the telephone network must comply with the applicable Part 68 rules and technical requirements adopted by ACTA. A compliant telephone cord and modular plug is provided with this product. It is designed to be connected to a compatible modular jack that is also compliant. An RJ11 jack should normally be used for connecting to a single line and an RJ14 jack for two lines. See Installation Instructions in the user's manual.

The Ringer Equivalence Number (REN) is used to determine how many devices you may connect to your telephone line and still have them ring when you are called. The REN for this product is encoded as the 6th and 7th characters following the US: in the product identifier (e.g., if ## is 03, the REN is 0.3). In most, but not all areas, the sum of all RENs should be five (5.0) or less. For more information, please contact your telephone service provider.

This equipment may not be used with Party Lines. If you have specially wired alarm dialing equipment connected to your telephone line, ensure the connection of this equipment does not disable your alarm equipment. If you have questions about what will disable the alarm equipment, consult your telephone service provider or a qualified installer.

If this equipment is malfunctioning, it must be unplugged from the modular jack until the problem has been corrected. Repairs to this telephone equipment can only be made by the manufacturer or its authorized agents. For repair procedures, follow the instructions outlined under the Limited Warranty.

If this equipment is causing harm to the telephone network, the telephone service provider may temporarily discontinue your telephone service. The telephone service provider is required to notify you before interrupting service. If advance notice is not practical, you will be notified as soon as possible. You will be given the opportunity to correct the problem and the telephone service provider is required to inform you of your right to file a complaint with the FCC. Your telephone service provider may make changes in its facilities, equipment, operation, or procedures that could affect the proper functioning of this product. The telephone service provider is required to notify you if such changes are planned.

If this product is equipped with a corded or cordless handset, it is hearing aid compatible.

If this product has memory dialing locations, you may choose to store emergency telephone numbers (e.g., police, fire, medical) in these locations. If you do store or test emergency numbers, please:

- Remain on the line and briefly explain the reason for the call before hanging up.
- Perform such activities in off-peak hours, such as early morning or late evening.

### **Industry Canada**

Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference, including interference that may cause undesired operation.

The term "IC:" before the certification/registration number only signifies that the Industry Canada technical specifications were met.

The Ringer Equivalence Number (REN) for this terminal equipment is 0.1. The REN is an indication of the maximum number of devices allowed to be connected to a telephone interface. The termination on an interface may consist of any combination of devices subject only to the requirement that the sum of the RENs of all the devices does not exceed five.

This product meets the applicable Industry Canada technical specifications.

## Appendix FCC Part 15

This equipment has been tested and found to comply with the requirements for a Class B digital device under Part 15 of the Federal Communications Commission (FCC) rules.

These requirements are intended to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications to this equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Privacy of communications may not be ensured when using this telephone.

To ensure safety of users, the FCC has established criteria for the amount of radio frequency energy that can be safely absorbed by a user or bystander according to the intended usage of the product. This product has been tested and found to comply with the FCC criteria. The handset may be safely held against the ear of the user. The telephone base shall be installed and used such that parts of the user's body other than the hands are maintained at a distance of approximately 20cm (8 inches) or more.

This Class B digital apparatus complies with Canadian ICES-003.

## Limited warranty

The AT&T brand is used under license - any repair, replacement or warranty service, and all questions about this product should be directed to: In the United States of America, call

**1 (800) 222-3111** or visit **www.telephones.att.com**; in Canada, call **1 (866) 288-4268**.

### 1. What does this limited warranty cover?

The manufacturer of this AT&T branded product warrants to the holder of a valid proof of purchase ("CONSUMER" or "you") that the product and all accessories provided in the sales package ("PRODUCT") are free from defects in material and workmanship, pursuant to the following terms and conditions, when installed and used normally and in accordance with the PRODUCT operating instructions. This limited warranty extends only to the CONSUMER for products purchased and used in the United States of America and Canada.

### 2. What will be done if the PRODUCT is not free from defects in materials and workmanship during the limited warranty period ("materially defective PRODUCT")?

During the limited warranty period, the manufacturer's authorized service representative repairs or replaces at the manufacturer's option, without charge, a materially defective PRODUCT. If the manufacturer repairs the PRODUCT, they may use new or refurbished replacement parts. If the manufacturer chooses to replace the PRODUCT, they may replace it with a new or refurbished PRODUCT of the same or similar design. The manufacturer will retain the defective parts, modules, or equipment. Repair or replacement of the PRODUCT, at the manufacturer's option, is your exclusive remedy. The manufacturer returns the repaired or replacement products to you in working condition. You should expect the repair or replacement to take approximately 30 days.

### 3. How long is the limited warranty period?

The limited warranty period for the PRODUCT extends for ONE (1) YEAR from the date of purchase. If the manufacturer repairs or replaces a materially defective PRODUCT under the terms of this limited warranty, this limited warranty also applies to repaired or replacement PRODUCT for a period of either (a) 90 days from the date the repaired or replacement PRODUCT is shipped to you or (b) the time remaining on the original one-year limited warranty; whichever is longer.

### 4. What is not covered by this limited warranty?

This limited warranty does not cover:

- PRODUCT that has been subjected to misuse, accident, shipping or other physical damage, improper installation, abnormal operation or handling, neglect, inundation, fire, water, or other liquid intrusion; or
- PRODUCT that has been damaged due to repair, alteration, or modification by anyone other than an authorized service representative of the manufacturer; or
- PRODUCT to the extent that the problem experienced is caused by signal conditions, network reliability or cable or antenna systems; or
- PRODUCT to the extent that the problem is caused by use with non-AT&T accessories; or
- PRODUCT whose warranty/quality stickers, PRODUCT serial number plates or electronic serial numbers have been removed, altered or rendered illegible; or
- PRODUCT purchased, used, serviced, or shipped for repair from outside the United States of America or Canada, or used for commercial or institutional purposes (including but not limited to products used for rental purposes); or
- PRODUCT returned without a valid proof of purchase (see item 6 below); or
- Charges for installation or setup, adjustment of customer controls, and installation or repair of systems outside the unit.

## Limited warranty

### 5. How do you get warranty service?

To obtain warranty service in the United States of America, visit

**www.telephones.att.com** or call **1 (800) 222-3111**; in Canada, please

dial **1 (866) 288-4268**. NOTE: Before calling for service, please review the user's manual. A check of the PRODUCT's controls and features might save you a service call.

Except as provided by applicable law, you assume the risk of loss or damage during transit and transportation and are responsible for delivery or handling charges incurred in the transport of the PRODUCT(s) to the service location. The manufacturer will return repaired or replaced PRODUCT under this limited warranty. Transportation, delivery or handling charges are prepaid. The manufacturer assumes no risk for damage or loss of the PRODUCT in transit. If the PRODUCT failure is not covered by this limited warranty, or proof of purchase does not meet the terms of this limited warranty, the manufacturer notifies you and requests that you authorize the cost of repair prior to any further repair activity. You must pay for the cost of repair and return shipping costs for the repair of products that are not covered by this limited warranty.

### 6. What must you return with the PRODUCT to get warranty service?

You must:

- Return the entire original package and contents including the PRODUCT to the service location along with a description of the malfunction or difficulty; and
- Include "valid proof of purchase" (sales receipt) identifying the PRODUCT purchased (PRODUCT model) and the date of purchase or receipt; and
- Provide your name, complete and correct mailing address, and telephone number.

### 7. Other limitations

This warranty is the complete and exclusive agreement between you and the manufacturer of this AT&T branded PRODUCT. It supersedes all other written or oral communications related to this PRODUCT. The manufacturer provides no other warranties for this PRODUCT. The warranty exclusively describes all of the manufacturer's responsibilities regarding the PRODUCT. There are no other express warranties. No one is authorized to make modifications to this limited warranty and you should not rely on any such modification.

**State/Provincial Law Rights:** This warranty gives you specific legal rights, and you might also have other rights that vary from state to state or province to province.

**Limitations:** Implied warranties, including those of fitness for a particular purpose and merchantability (an unwritten warranty that the PRODUCT is fit for ordinary use) are limited to one year from date of purchase. Some states/provinces do not allow limitations on how long an implied warranty lasts, so the above limitation might not apply to you. In no event shall the manufacturer be liable for any indirect, special, incidental, consequential, or similar damages (including, but not limited to lost profits or revenue, inability to use the PRODUCT or other associated equipment, the cost of substitute equipment, and claims by third parties) resulting from the use of this PRODUCT. Some states/provinces do not allow the exclusion or limitation of incidental or consequential damages, so the above limitation or exclusion might not apply to you.

**Please retain your original sales receipt as proof of purchase.**

## Technical specifications

RF frequency band	1921.536MHz — 1928.448MHz
Channels	5
Operating temperature	32°F — 122°F 0°C — 50°C
Telephone base voltage (AC voltage, 60Hz)	96 — 129 Vrms
Telephone base voltage (AC adapter output)	6VDC @400mA
Handset voltage	2.4 — 3.2 VDC
Charger voltage (AC adapter output)	6VAC @300mA
Operating time*	Talk time (handset): up to 7 hours Talk time (speakerphone): up to 5 hours Standby: up to 7 days

\* Operating times vary depending on your actual use and the age of the battery.

### DECT 6.0 digital technology

The AT&T DECT 6.0 products offer unsurpassed range performance and sound clarity. This is achieved through a unique antenna design and advances in noise-filtering technology. An independent laboratory has confirmed that AT&T DECT 6.0 products perform up to 45% better in range competitions against similarly equipped phones of the leading competition. Now calls can be taken in the basement, backyard and garage with exceptional sound quality.

### Telephone operating range

This cordless telephone operates within the maximum power allowed by the Federal Communications Commission (FCC). Even so, this handset and telephone base can communicate over only a certain distance — which can vary with the locations of the telephone base and handset, the weather, and the construction of your home or office.

### Extended range and clarity

This telephone base comes with an antenna which gives much better clarity and covers a longer range than before.

### HD audio

HD audio improves sound quality by expanding and rebuilding frequencies that are lost with traditional phone calls. There is no additional telephone service requirement to use HD audio. It is designed to work with standard telephone service. Your system will automatically enhance all received sound with HD audio.

# Index

## A

---

Add a cell phone, 14  
Add a handset, 94, 100  
Add a headset, 16  
Alert tones, 90  
Alphabetical search, 63  
Announcement, 75  
Answer a cell call, 41–42  
Answer a cell call while on a home call, 41  
Answer a home call, 39  
Answering system and voicemail, 81  
Answering system settings, 74–80  
Answer on/off, 74  
Appendix, 89

## B

---

Battery charging, 8–9  
Battery installation, 8  
Bluetooth, 12–25  
Bluetooth connection from idle mode, 21  
Bluetooth glossary, 13  
Bluetooth setup, 14

## C

---

Caller ID, 68  
Caller ID Announce, 35  
Caller ID history, 69  
Caller ID log, 69  
Caller ID display screen messages, 73  
Call intercept, 82  
Call screening, 77, 82  
Call waiting on the cell line, 41  
Call waiting on the home line, 40  
Cell area code, 37  
Cell call, 41  
Cell phone - download directory, 22  
Cell phone voicemail, 42  
Chain dialing, 46, 47  
Change a one-to-one PTT to intercom call, 57  
Charger installation, 7  
Charging, 9

Clock, 8, 28  
Conference home and cell calls, 43  
Connect an active device, 18  
Create a new directory entry, 60

## D

---

Date, 8, 28  
Delete a directory entry, 65  
Delete all old messages, 86  
Delete a message, 84–85  
Delete a redial entry, 49  
Delete from the caller ID log, 73  
Delete the announcement, 76  
Deregister handsets, 95  
Dial a caller ID log entry, 71  
Dial a directory entry, 64  
Dialing options, 71  
Dial mode, 34  
Directory, 22, 59–67  
Disconnect an active device, 18  
Display alerts, 30  
Display screen messages, 91  
Download directory, 22  
Download fail, 32  
DSL filter, 6

## E

---

Edit a directory entry, 64  
Edit the type of a directory entry, 65  
End a cell call, 41  
End a home call, 39  
End a PTT call, 58  
End mute, 44  
Equalizer, 45  
Expand your telephone system, 94

## F

---

Find handset, 50  
Flash (switch hook flash), 40

## G

---

Glossary of Bluetooth terms, 13

# Index

## H

---

Handset icons, 89  
Handset lights, 90  
Handset locator, 50  
Handset ringer volume, 26  
Handset settings, 26–37  
HD audio, 116  
Hold, 45  
Hold a call and intercom, 53  
Home area code, 36  
Home directory, 59

## I

---

Icons, 89  
Important safety information, 110  
Indicator lights, 90  
Installation, 5  
Intercom, 51–52  
Interruption to directory  
  download, 24

## K

---

Key tone, 34

## L

---

Last number redial, 48  
LCD Language, 29  
Lights, 90  
Limited warranty, 114–115  
Listening volume, 44

## M

---

Maintenance, 109  
Make a call using speed dial, 66  
Make a cell call, 41  
Make a home call, 39  
Memory match, 69  
Memos, 86  
Message alert tone, 79  
Message capacity, 82  
Message playback, 84, 85  
Message window displays, 87  
Missed calls, 30  
Mute, 44

## N

---

No home line, 32  
Number of rings, 78

## O

---

Operating range, 116

## P

---

Paging, 50  
Phonebook (directory), 59  
Play memos, 86  
Play the announcement, 75  
Predialing, 39  
PTT, 54  
PTT to a group of handsets, 56  
PTT to a single handset, 55  
Pulse dialing, 34, 45  
Push-to-talk, 54

## Q

---

Quick reference guide, 1

## R

---

Reassign a speed dial slot, 66  
Record announcement, 75  
Recording time setting, 80  
Record memos, 86  
Redial list, 48  
Register a handset, 94, 100  
Remote access code, 79, 88  
Remove a device, 19  
Remove a downloaded directory, 65  
Rename a device, 20  
Repeat messages, 84, 85  
Replace a handset, 95  
Replace an active device, 21  
Review the active devices list, 18  
Review the caller ID log, 70  
Review the directory, 63  
Review the redial list, 48  
Ringer mute, 44  
Ringer tone, 27  
Ringer volume, 26

# Index

## S

---

- Safety information, 110
- Save a caller ID log entry to the directory, 72
- Save a redial entry to the directory, 49
- Search for a contact, 63
- Set date/time, 8, 28
- Share an outside call, 50
- Silence the ringer, 44
- Skip messages, 84, 85
- Speakerphone, 44
- Speed Dial, 66
- Stop messages, 84, 85

## T

---

- Technical specifications, 116
- Telephone base installation, 6
- Telephone base lights, 90
- Telephone operating range, 116
- Telephone operation, 39–49
- Telephone settings, 26–38
- Temporary tone dialing, 45
- Time, 8, 28
- Transfer a call, 47, 53
- Transfer a call from a handset to a headset, 40
- Troubleshooting, 96–108
- Turn on or off the answering system, 74

## U

---

- Use a Bluetooth headset, 39
- Using the home and cell lines together, 43

## V

---

- View the directory download information, 24
- Voice announce caller ID, 35
- Voicemail, 31, 42, 81
- Volume, 26, 34, 38, 44, 84, 85

## W

---

- Wall mounting, 10
- Warranty, 114–115
- Website, 35

# Remote access wallet card

The wallet card below lists the commands needed to control your answering system from any touch-tone telephone.

Cut along dotted line.



Call your telephone number, then enter your 2-digit remote access code (preset to **19**).

Action	Remote command
--------	----------------

- |                               |                                    |
|-------------------------------|------------------------------------|
| Play all messages .....       | <b>1</b>                           |
| Play new messages.....        | <b>2</b>                           |
| Delete the message.....       | <b>3</b> (during message playback) |
| Delete all old messages ..... | <b>33</b>                          |
| Repeat or go back .....       | <b>4</b>                           |
| Stop.....                     | <b>5</b>                           |
| Help menu .....               | <b>*5</b>                          |
| Skip the message.....         | <b>6</b>                           |
| Record announcement .....     | <b>*7</b>                          |
| Turn system on or off .....   | <b>0</b>                           |
| End remote access call.....   | <b>8</b> (or hang up)              |

Fold here.

**TL92271/TL92371/TL92471**

**DECT 6.0 cordless telephone/answering system with BLUETOOTH® wireless technology**

© 2011 Advanced American Telephones. All Rights Reserved.  
AT&T and the AT&T logo are trademarks of AT&T Intellectual Property licensed to Advanced American Telephones, San Antonio, TX 78219.  
Printed in China.



[www.telephones.att.com](http://www.telephones.att.com)

The *Bluetooth*<sup>®</sup> word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by Advanced American Telephones and its parent, VTech Holdings Limited, is under license. VTech Holdings Limited is a member of Bluetooth SIG, Inc. Other trademarks and trade names are those of their respective owners.

© 2011 Advanced American Telephones. All Rights Reserved.  
AT&T and the AT&T logo are trademarks of AT&T Intellectual Property licensed to  
Advanced American Telephones, San Antonio, TX 78219.  
Printed in China. Issue 8 AT&T 06/11.