

Quick start guide TL92273/TL92373/TL92473

This quick start guide provides you with basic instructions only. For more complete instructions, refer to the Abridged user's manual provided in the package, or see the Complete user's manual at www.telephones.att.com/manuals.

Parts checklist

Your package contains:

- Handset
 (2 for TL92273)
 (3 for TL92373)
 (4 for TL92473)
 (4 for TL92473)
 (5 for TL92273)
 (6 for TL92273)
 (7 for TL92273)
 (9 for TL92273)
 (1 for TL92273)
 (1 for TL92273)
 (2 for TL92273)
 (3 for TL92273)
- (2 for TL92373) (3 for TL92373) (4 for TL92473)

 Telephone base

 Wall mount bracket
- Telephone line cord
 Telephone base power adapter
 Abridged user's manual
 Quick start guide

Basic steps to set up & operate your phone

Basic installation

- **1** Install telephone base & charger
- 2 Install handset battery
- 3 Install telephone base on the wall (optional)


Common settings

- 4 Set date and time
- **5** Set ringer volume
- 6 Add a Bluetooth cell phone / headset
- 7 Download a cell phone directory
- 8 Record own announcement
- **9** Set number of rings

Common operations

- 10 Directory
- 11 Caller ID

Install telephone base & charger



Install handset battery








- Charge for at least 30 minutes before initial settings.
- Charge for 11 hours before initial use.

Install telephone base on the wall (optional)

Follow the instructions below only if you would like to mount the telephone on a wall.







INSTALLATION COMPLETED!

Keep reading for common settings and operations.

4

Set date and time

Set the date/time before using the answering system.

Using a cordless handset:

- 1. Press MENU -> Press V/▲ to Set date/time -> Press SELECT.
- 2. Enter the month (MM), day (DD) and year (YY) -> Press NEXT.
- 3. Enter the hour (HH) and minute (MM).
- 4. Press **▼**/**▲** to choose **AM** or **PM** -> Press **SAVE**.



Set ringer volume

You can set the ringer volume level to one of the six levels or turn the ringer off.

Using a cordless handset:

- 1. Press MENU -> Press V/▲ to Ringers -> Press SELECT.
- 2. Press **SELECT** to select **Ringer volume**.
- 3. Press **▼**/**▲** to choose the desired level -> Press **SEI**.



Add a Bluetooth cell phone / headset

To use a Bluetooth enabled cellular phone or headset with your telephone, you must first pair and connect your Bluetooth cellular phone or headset with the telephone base.

Bluetooth wireless technology operates within a short range (up to 30 feet). Keep the connected device within 15 feet of the telephone base for optimal performance.

To pair and connect a cell phone using a cordless handset:

- 1. Press MENU -> Press V/▲ to Bluetooth -> Press SELECT.
- 2. Press **SELECT** to select **Add device**.
- 3. Press **SELECT** to select **Add cellular**.
- 4. Disconnect the cell phone from any Bluetooth device -> Press NEXI.
- 5. Place the cell phone next to the telephone base.
- 6. Press NEXT to turn on the telephone base discoverable mode.
- 7. Turn on the Bluetooth feature of your cell phone and search for or add new advices. Once your cell phone finds your AT&T phone (AT&T DECT 6.0), press the appropriate key on your cell phone to continue the pairing process.
- Enter the cell phone passcode (typically **0000**) if required -> Press **SEI**.
- Enter the PIN (default PIN: **0000**) of the telephone base into your cell phone if required.

To pair and connect a headset using a cordless handset:

- 1. Press MENU -> Press V/▲ to Bluetooth -> Press SELECT.
- 2. Press **SELECT** to select **Add device**.
- 3. Press **▼**/**△** to **Add headset** -> Press **SELECT**.
- 4. Disconnect your headset from any Bluetooth device -> Press NEXI.
- 5. Set your headset to discoverable mode -> Press NEXT
- 6. Press ▼/▲ to choose your headset if required -> Press SELECT.
- Enter the PIN (typically **0000**) of your headset if required and press **NEXI**.



Download a cell phone directory

Before downloading a directory, make sure the cell phone is paired, active, and connected to your TL92273/TL92373/TL92473.

To download a cell phone directory using a cordless handset:

- 1. Press MENU -> Press V/▲ to Bluetooth -> Press SELECT.
- 2. Press ▼/▲ to Download dir -> Press SELECT
- 3. Press ∇/Δ to choose among **Phone memory**, **SIM card only** or **Phone** and SIM -> Press SELECT.
- 4. Press **NEXI** to start downloading if necessary.
- Enter the cell phone passcode if necessary, then press **SEI**.
- Press a key on your cellphone to confirm the directory download if required.
- 5. Press **OK** to exit.

If you are using Bluetooth-enabled cell phones with Android® OS 2.3 or above, you may also download the **Connect to Cell**™ application (consists of Caller ID manager and Alerts manager) i using the Google Play® Store app to extend the flexibility of your TL92273/TL92373/TL92473. Scan the QR code on the right to download the application.



Record own announcement

You can use the preset announcement to answer calls, or replace it with your own recorded announcement.

Using a cordless handset:

- 1. Press MENU -> Press V/▲ to Answering sys -> Press SELECTI.
- 2. Press **SELECT** to select **Announcement**.
- 3. Press **SELECT** to select **Record annc**.
- 4. Facing the handset, record your announcement and press **STOP** to end recording.



Set number of rings

You can set the answering system to answer an incoming call after 2, 3, 4, 5 or 6 rings, or toll saver. If you choose toll saver, the answering system answers a call after two rings if you have new messages, or after four rings when there are no new messages.

Using a cordless handset:

- 1. Press MENU -> Press ▼/▲ to Answering sys -> Press SELECT.
- 2. Press **▼**/**▲** to **Ans sys setup** -> Press **SELECT**.
- 3. Press **▼/**▲ to # of rings -> Press **SELECT**.
- 4. Press **▼**/**▲** to choose among **6**, **5**, **4**, **3**, **2** or **Toll saver** -> Press **SELECT**.

SETUP DONE!

Keep reading for some common operations.

Directory

The directory stores up to 200 entries.

To add an entry in the home directory:

Using a cordless handset:

- 1. Press MENU -> Press V/▲ to Directory -> SELECI.
- 2. Press **OPTION** to select **Home**.
- 3. Press **SELECT** to select **Add contact**.
- 4. Enter a telephone number -> Press NEXT.
- 5. Press ▼/▲ to select Home, Cell, Work or Other -> Press NIXII.
- 6. Enter a name -> Press SAVE.

To review and dial a directory entry:

Using a cordless handset:

- 1. Press DIR in idle mode -> Press ▼/▲ to select the desired directory -> Press **REVIEW**.
- 2. Press **▼**/**▲** to browse through the directory, or press the dialing keys to start a name search.
- 3. Press **AHOME** or **■)/SPEAKER** to call using the home line.



Press (*) CELL 1 or (*) CELL 2 to call using the cell line.



Caller ID

The caller ID log stores up to 50 entries.

To review and dial a caller ID entry:

Using a cordless handset:

- 1. Press CID in idle mode -> Press ▼/▲ to scroll through the list.
- 2. Press **AHOME** or **♦)/SPEAKER** to dial with the home line.



Press (*) CELL 1 or (*) CELL 2 to dial with the cell line.

2 DEF 3 **⊠**1 CID


To erase the missed call indicator:

Using a cordless handset:

The screens display **XX missed calls** when you have incoming calls that have not been answered. When you have reviewed all the missed calls, the missed call indicator is erased.

If you want to erase the missed call indicator without reviewing the caller ID log, press and hold CANCEL in idle mode.


Handset operation




Make or answer a cell call.

Decrease the listening volume.

 Answer an incoming CELL 1/CELL 2 call during a CELL 1/CELL 2 call.



- Make or answer a home call
- Answer a call waiting call during a home call.



- redial list.
- Add a dialing pause while dialing or entering a number.
- Make a home call using the speakerphone.
- · Answer a home or cell call using the speakerphone.

Answering system operation

Your telephone has a built-in answering system and supports voicemail feature offered by your telephone service provider (subscription is required, and fees may apply).

Answering system and voicemail

To use the built-in answering system:


Refer to this Quick start quide for basic instructions. For complete instructions, see the Abridged user's manual in the package or the Complete user's manual at www.telephones.att.com/manuals.



To use the voicemail:

Press and hold 1 on the handset to dial the preset voicemail number, and then enter a security code. Contact your telephone service provider for detailed information.

The built-in answering system must be turned on to answer and record messages.



Adjust the speaker

volume.



For more detailed instructions, please refer to the Abridged user's manual provided in your package, or for a full set of installation and operation instructions, refer to the online TL92273/TL92373/TL92473 **DECT 6.0 cordless telephone/answering system with BLUETOOTH® wireless** technology Complete user's manual at www.telephones.att.com/manuals.

For customer service or product information, visit our website at www.telephones.att.com or call 1 (800) 222-3111. In Canada, dial 1 (866) 288-4268.

The Bluetooth® word mark and logos are owned by Bluetooth SIG, Inc. and any use of such marks by Advanced American Telephones and its parent, VTech Holdings Limited, is under license. VTech Holdings Limited is a member of Bluetooth SIG, Inc. Other trademarks and trade names are those of their respective owners.

© 2013 Advanced American Telephones. All Rights Reserved. AT&T and the AT&T logo are trademarks of AT&T Intellectual Property licensed to Advanced American Telephones, San Antonio, TX 78219. Android® and Google Play® are registered trademarks of Google Inc. Connect to Cell[™] is a trademark of Advanced American Telephones. Printed in China. Issue 2 AT&T 04/13.