



at&t

Quick start guide

E5921/E5922B/E5923B/E5924B
**5.8 GHz cordless telephone/
answering system with caller ID/
call waiting**



Installation and setup

Choose a central location close to a telephone jack and a power outlet not connected to a wall switch. The telephone base can be placed on a flat surface or mounted on a standard wall plate. For optimum range and better reception, place the telephone base in a high and open location.

Avoid placing the telephone base too close to:

- Communication devices such as: personal computers, computer routers, television sets, VCRs, wireless routers (wireless broadband, wi-fi, or 802.11) or other cordless telephones.
- Excessive heat sources.
- Noise sources such as a window with traffic outside, motors, microwave ovens, refrigerators, or fluorescent lighting.
- Excessive dust sources such as a workshop or garage.
- Excessive moisture.
- Extremely low temperature.
- Mechanical vibration or shock such as on top of the washing machine or work bench.

1. Plug one end of the telephone line cord into the telephone jack at the bottom of the telephone base.

2. Plug the small end of the larger power adapter into the power jack at the bottom of the telephone base.

5. Plug the other end of the telephone line cord into a telephone jack.

3. Route cords through slots.

DSL filter
(Optional for DSL users, see number four in the note section, below.)

Telephone line cord

4. Plug the large end of the larger power adapter into an electrical outlet not controlled by a wall switch.




NOTES:

1. Use only the power cord supplied with this product, if you need a replacement, visit our web-site at www.telephones.att.com, call 1 (800) 222-3111. In Canada dial 1 (866) 288-4268.
2. Be sure to use an electrical outlet not controlled by a wall switch.
3. This power adapter is intended to be plugged into a vertical wall outlet or a floor outlet. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.
4. If you receive high speed internet through your telephone line (commonly referred to as DSL), and you are experiencing interference during telephone conversations and/or your caller ID features are not functioning properly, install a DSL filter to the telephone line between the telephone base and the telephone wall jack. Contact your DSL service provider for a DSL filter.

Installation and setup

After battery installation, the battery may have enough charge to allow some calls. For best performance, place the handsets in the telephone base or the charger and allow to charge for 16 hours before use.

You can keep the battery charged by returning the handsets to the telephone base or the charger after use. When the battery is fully depleted, a recharge takes about 12 hours. The average talk time on a fully charged battery is about eight hours, and the standby time is approximately five days. Actual battery life depends on usage conditions and age of battery.




1. Plug the battery securely into the plug inside the handset battery compartment, matching the color-coded label.



2. Place the battery and wires neatly inside the compartment.



3. Slide battery compartment cover towards the center until it clicks into place.



4. The battery may have enough charge to allow for some calls. For best performance, place handset in telephone base or charger to charge for at least 16 hours before first use.



To replace the battery, press in and push outward on the tab to open the battery compartment cover. Lift out the old battery and disconnect it from the compartment. Follow the instructions on this page to install and charge the new battery.

Caution: Use only the supplied rechargeable battery or replacement battery (model 27910, part number 89-0099-00-00) or equivalent. To order a replacement battery, visit our website at www.telephones.att.com or call 1 (800) 222-3111. In Canada, call 1 (866) 288-4268.

Quick reference guide

Cordless handset

CID

Press to display caller ID information.

PHONE/FLASH


Press to make or answer a call. During a call, press to receive an incoming call if call waiting is activated.

MUTE/DELETE

While on a call, press to mute microphone.
While reviewing the call log, press to delete an individual entry, or press and hold to clear the caller ID log.
While predialing, press to delete digits.

SPEAKER

Press to activate handset speakerphone.
Press again to resume normal handset use.



MENU/SELECT

Press to display the menu.
When in the menu, press to select an item or save an entry or setting. Press up or down NavKey or to scroll up or down while in menus. While entering names or numbers, press left or right NavKey or to move the cursor to the left or right.

DIR

Press to display directory entries.

OFF/CLEAR


During a call, press to hang up. While using menus, press to cancel an operation, back up to the previous menu, or exit the menu display.

REDIAL/PAUSE

Press to view redial memory. While entering numbers, press and hold to insert a dialing pause.

INT

Press to initiate an intercom conversation or transfer a call.



Feature menu



Menu

Feature menu


- DIRECTORY
- CALL LOG
- RINGER VOLUME
- RINGER TONE
- KEY TONE
- LANGUAGE
- CLR VOICE MAIL
- DIAL TYPE

Using menus

Press up or down NavKey or to scroll through menu items.
Press **MENU/SELECT** to select or modify a highlighted item.
Press **OFF/CLEAR** to cancel an operation, back up to the previous menu, or exit the menu display.

Quick reference guide

Telephone base



MUTE
While on a call, press to mute microphone; press again to resume.

VOLUME
Press to adjust speakerphone listening volume.

FLASH
During a call, press to receive an incoming call if call waiting is activated.

SPEAKER
Press to turn speakerphone on or off (begin or end a call).

REDIAL/PAUSE
Press to dial out the most recently dialed number using the speakerphone.


Answering system controls

SETUP
Press to listen to setup options.

CLOCK
Press to review or set clock.

ANNC
Press to review or record announcement; press again to quit.

RECORD
Press to record a memo or after pressing **ANNC.** to record an outgoing announcement.



REPEAT
Press to repeat message; press twice, or once at the beginning of the date and time announced, to play previous message.

DELETE
Press to delete message currently playing; hold to delete all old messages.

SKIP
Press to skip message.

ANSWER ON
Press to turn answering system on or off.

PLAY/STOP
Press to start or stop message playback.



www.telephones.att.com