



Quick start guide

TL74108/TL74208/TL74308/

TL74408/TL74258/TL74358/

TL74458

**5.8 GHz corded/cordless
telephone/answering system with
caller ID/call waiting**



Installation preparation

You must install and charge the handset battery before using the cordless handset.



See page 3
for easy instructions.

If you subscribe to high-speed Internet service (Digital Subscriber Line - DSL) through your telephone lines, you must install a DSL filter between the telephone base and the telephone wall jack (see page 2). The filter will prevent noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters.

Your product may be shipped with a protective sticker covering the handset or telephone base display - remove it before use.

For customer service or product information, visit our website at **www.telephones.att.com** or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.

Avoid placing the telephone base too close to:



- Communication devices such as: television sets, VCRs, or other cordless telephones.
- Excessive heat sources.
- Noise sources such as a window with traffic outside, motors, microwave ovens, refrigerators, or fluorescent lighting.
- Excessive dust sources such as a workshop or garage.
- Excessive moisture.
- Extremely low temperature.
- Mechanical vibration or shock such as on top of the washing machine or work bench.

Telephone base installation

If you subscribe to high-speed Internet service (Digital Subscriber Line - DSL) through your telephone lines, you must install a DSL filter between the telephone base and the telephone wall jack. The filter will prevent noise and caller ID problems caused by DSL interference. Please contact your DSL service provider for more information about DSL filters.

Install the telephone base as shown below.

Telephone base installation

1. Plug the small end of the telephone base power adapter into the power jack at the bottom of the telephone base.
 2. Plug one end of the telephone line cord into the telephone jack at the bottom of the telephone base.
 3. Route cords through slots.
 4. Plug the telephone base power adapter into an electrical outlet not controlled by a wall switch.
 5. Plug the other end of the telephone line cord into a telephone jack.
 6. Plug the coiled handset cord into the  jack at the left of the telephone base.
- 
- The diagram illustrates the installation of a telephone base. It shows a top-down view of the base unit with various ports and slots. A power adapter is shown being plugged into the base and then into a wall outlet. A telephone line cord is shown being plugged into the base and then into a wall jack. A coiled handset cord is shown being plugged into the base. A DSL filter is shown being plugged into the line cord between the base and the wall jack. Arrows indicate the path of the cords and the location of the components.
- DSL filter (not included, required for DSL users).
- Telephone line cord


IMPORTANT INFORMATION

1. Use only the power adapters supplied with this product or equivalent. To order a replacement power adapter, visit our website at **www.telephones.att.com**, or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.
2. The power adapters are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.

Handset battery installation & charging

Install the battery as shown below. After installing the battery, you can make and receive short calls, but replace the handset in the telephone base or additional charger when the handset is not being used. For optimal performance, charge the handset battery for at least 16 hours before use. When fully charged, the handset battery provides approximately five hours of talk time or three days of standby time.

If the battery is depleted, it may take approximately four minutes to charge the handset before it can resume screen display. The screen will continue to display **LOW BATTERY** until the battery has charged for approximately one hour.



Step 1

Plug the battery securely into the plug inside the handset battery compartment, matching the color-coded label.



Step 2

Place the battery in the compartment with **THIS SIDE UP** facing up as indicated.



Step 3

Align the cover flat against the battery compartment cover, then slide it upwards until it clicks into place.

Step 4

Charge the handset by placing the handset face out in the charger. The **CHARGE** light will be on when the handset is charging.




IMPORTANT INFORMATION

Use only the battery supplied with this product. To order a replacement or spare battery (AT&T model 27910, part number 89-0099-00-00) or equivalent, visit our website at **www.telephones.att.com**, or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.

Charger installation

1. Plug the small end of the handset charger power adapter into the jack on the underside of the charger, then route the cord through the slot as shown.



2. Plug the handset charger power adapter into a power outlet not controlled by a wall switch.

IMPORTANT INFORMATION

1. Use only the power adapters supplied with this product or equivalent. To order a replacement power adapter, visit our website at **www.telephones.att.com**, or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.
2. The power adapters are intended to be correctly oriented in a vertical or floor mount position. The prongs are not designed to hold the plug in place if it is plugged into a ceiling, under-the-table or cabinet outlet.

Quick reference guide - handset

CHARGE indicator

On when the handset is in the charger.

CID

Press to display the caller ID information.

PHONE/FLASH

Press to make or answer a call.
During a call, press to receive an incoming call if call waiting is activated.

REDIAL/PAUSE

Press to view the redial memory.
While entering numbers, press and hold to insert a dialing pause.

MUTE/REMOVE

During a call, press to mute the microphone.
While reviewing the caller ID history, press to delete an individual entry, or press and hold to clear the caller ID history. While predialing, press to delete digits.

SPEAKER

Press to turn on the handset speakerphone.
Press again to resume normal handset use.



Press or to scroll up or down while in menus.
While entering names or numbers, press or to move the cursor, where the next character will appear, to the left or right.

MENU/SELECT

Press to enter the menu.
While in the menu, press to select an item or save an entry or setting.

DIR

Press to display the directory.

VOLUME ▼▲


While on a call, press the button located on the side of the handset to adjust listening volume.
When the handset is not in use, press to adjust the ringer volume.

OFF/CLEAR

During a call, press to hang up.
While using menus, press to cancel an operation, back up to the previous menu, or exit the menu display.


INT

Press to begin an intercom conversation or to transfer a call.




Feature menu

The > symbol highlights a menu item.



Feature menu

DIRECTORY
CALL LOG
RINGER VOLUME
RINGER TONE
KEY TONE
LANGUAGE
CLR VOICE MAIL



Using menus

Press or to scroll through menu items.

Press **MENU/SELECT** to select or modify a highlighted item.

Press **OFF/CLEAR** to cancel an operation, back up to the previous menu, or exit the menu display.

Quick reference guide - telephone base

- **HANDSET LOCATOR/INTERCOM:** While phone is idle, press to page handset, or initiate an intercom call.
- **FLASH:** During a call, press to receive an incoming call if call waiting is activated.

- **CLOCK:** Press to review or set the clock.

- **SETUP:** Press to hear and change the settings.

- **ANNC.:** Press to review or record the outgoing announcement; press again to quit.

- **RECORD:** Press to record a memo, or after pressing **ANNC.**, to record an outgoing announcement.

- **▶/■ PLAY/STOP:** Press to start or stop message playback.

- **X DELETE:** Press to delete the message currently playing. When in idle mode, press twice to delete all old messages.

- **ANSWER ON:** Press to turn the answering system on or off.

- **◀REPEAT:** Press to repeat the message; press **twice** to play the previous message.

- **▶SKIP:** Press to skip the message.

- **▶SPEAKER:** Press to turn on the telephone base speakerphone. Press again to hang up.



- **CLEAR:** While using menus, press to cancel an operation, or exit the menu display.

- **CID:** Press when the phone is idle to display the call history. While entering numbers or letters, press to move the cursor to the left.

- **MENU/SELECT:** Press to enter the menu. While in the menu, press to select an item or save an entry or setting.

- **DIR:** Press when the phone is idle to display the directory. While entering or modifying names, press to advance cursor.

- **DISP DIAL:** Press to dial the number currently displayed.

- **REDIAL/PAUSE:** Before dialing any numbers, press to display the last number called. While dialing or entering numbers into your directory, press and hold to insert a dialing pause.

- **▲VOLUME:** Press to adjust the volume of the speakerphone (if speakerphone is on), message playback (during playback) or ringer (if the telephone base is not being used).

- **MUTE:** Press to turn off the microphone; press again to resume your conversation.

IN USE

- On when handset is in use, when the answering system is answering an incoming call or you are registering a handset.
- Flashes when another telephone is in use on the same line, or you are deregistering a handset from the telephone base.
- Flashes quickly when there is an incoming call.

VOICEMAIL

- Flashes when you have new voicemail. Voicemail is a service offered by your local telephone company, and is different from answering system messages.

For complete instructions, please refer to the user's manual. If you are unable to find your manual, please visit www.telephones.att.com to read and/or download the manual.



www.telephones.att.com