



Quick start guide

CL83114/CL83214/CL83314/CL83364/
CL83414/CL83464

This quick start guide provides you with basic instructions only. For more complete instructions, refer to your Abridged user's manual provided in the package, or see the online Complete user's manual at www.telephones.att.com/manuals.


Telephone base installation

Plug the large end of the telephone base power adapter into a power outlet not controlled by a wall switch.

Plug one end of the telephone line cord into a telephone jack or a DSL filter.

Charger installation

Plug the power adapter into a power outlet not controlled by a wall switch.



If you have DSL high-speed Internet service, a DSL filter (not included) is required.

Route the telephone line cord through this slot.

Plug the power cord and the telephone line cord into the jacks.

Caution: Use only the power adapter(s) provided with this product. To obtain a replacement, visit our website at www.telephones.att.com or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.

Battery installation

Install the battery as shown below. Charge your handset(s) before initial use. The battery is fully charged after ten hours of continuous charging.




Step 1

Plug the battery connector securely into the socket inside the handset battery compartment. Insert the supplied battery with the label **THIS SIDE UP** facing up as indicated.



Step 2

Align the cover flat against the battery compartment, then slide it upwards until it clicks into place.



CHARGE light

Step 3

Charge the handset by placing it face forward in the telephone base or charger. The **CHARGE** light on the handset is on during charging.

Caution: Use only the supplied rechargeable battery or replacement battery (model BT183342/ BT283342).

Quick reference guide - handset

CHARGE light

On when the handset is charging in the telephone base or charger.

▼CID/VOLUME

- Press ▼CID to show caller ID log when the handset is not in use.
- Press to scroll down while in menus.
- Press to decrease the listening volume when on a call.

REDIAL/PAUSE

- Press repeatedly to view the last ten numbers dialed.
- While entering numbers, press and hold to insert a dialing pause.

(PHONE/FLASH

Press to make or answer a call.

✉ 1

Press and hold to set or dial your voicemail number.

TONE ✕/a>A

- Press to switch to tone dialing temporarily during a call if you have pulse service.
- While entering names, press to change the next letter to upper or lower case.

🔊/SPEAKER

Press to make or answer a call using the speakerphone.

Handset side view



PUSH TO TALK

- Press to initiate a one-to-one or one-to-group broadcast.
- Press and hold to broadcast to a group of system devices.

▲DIR/VOLUME

- Press ▲DIR to show directory entries when the handset is not in use.
- Press to scroll up while in menus.
- Press to increase the listening volume when on a call.

MENU/SELECT

- When the handset is not in use, press to show the menu.
- While in the menu, press to select an item or save an entry or setting.

OFF/CANCEL

- During a call, press to hang up.
- While in a menu, press to cancel an operation, back up to the previous menu, or exit the menu display, or press and hold this button to exit to idle mode.

QUIET# (pound key)

Press and hold to enter the QUIET mode setting screen, or to deactivate QUIET mode.

EQ

During an outside call, intercom call, message or announcement playback, press to change the audio quality to best suit your hearing.

MUTE/DELETE

- During a call, press to mute the microphone.
- Press to delete digit or character.

Quick reference guide - telephone base

CANCEL

- While in a menu, press to cancel an operation, back up to the previous menu or exit the menu display.
- Press and hold to go back to idle mode.

▼CID

- Press to display the caller ID log when the phone is not in use.
- Press to scroll down while in menus and lists.

MENU/SELECT

- When the telephone base is not in use, press to show the menu.
- While in the menu, press to confirm or save an entry or setting.

▲DIR

- Press to display the directory when the phone is not in use.
- Press to scroll up while in menus and lists.

FLASH

During a call, press to answer an incoming call when you receive a call waiting alert.

✉ 1

Press and hold to set or dial your voicemail number.

📶/HANDSET LOCATOR

While the phone is idle, press to page all handsets.

REDIAL/PAUSE

- Press repeatedly to view the last 10 numbers dialed.
- While entering numbers, press and hold to insert a dialing pause.

▼/VOLUME/▲

- While in idle mode, press to adjust the base ringer volume.
- When on a call, press to adjust the listening volume.

•/RECORD

Press to record a memo or an announcement.

◀/REPEAT

- During playback, press to repeat the playing message.
- During playback, press twice to play the previous message.

▶/SKIP

Press to skip a message.

▶/PLAY/STOP

Press to start or stop message playback.

X/DELETE

- While reviewing the caller ID log, the directory or the redial memory, press to delete an individual entry.
- Press to delete digit or character.

🔊/ANS ON/OFF


Press to turn the built-in answering system on or off.

MUTE

- During a call, press to mute the microphone.
- When the phone is ringing, press to mute the ringer temporarily.

🔊/SPEAKER

Press to make or answer a call using the speakerphone.



Initial settings

We recommend you program your telephone system before use. The following are a few examples of common features to set before using the telephone. Refer to the **Handset settings**, **Telephone base settings** and **Answering system settings** in the Abridged user's manual or the online Complete user's manual for detailed instructions on setting all telephone features.

Set date/time

Set the date/time before using the answering system.

Using a cordless handset or the telephone base:

- MENU -> ▼ or ▲ -> Set date/time -> SELECT.
- Enter the month, day and year using the dialing keys -> SELECT.
- Enter the hour and minute using the dialing keys.
- ▼ or ▲ to choose AM or PM -> SELECT.

Basic answering system setup via voice guide

You can follow the voice guide to record your own announcement, set the number of rings and set the message alert tone.

Using the telephone base:

- MENU -> ▼ or ▲ -> Answering sys -> SELECT.
- ▼ or ▲ -> Voice guide -> SELECT.
- Set up the answering system by inputting the designated numbers as instructed.

Record your own announcement

Your outgoing announcement plays when calls are answered by the answering system. You can use the preset announcement to answer calls, or replace it with your own recorded announcement.

Using a cordless handset:

- MENU -> ▼ or ▲ -> Answering sys -> SELECT.
- SELECT to select Announcement.
- SELECT to select Record ann.
- Facing the handset, record your announcement and press 5 to end recording.

Using the telephone base:

- /RECORD -> ▼ or ▲ -> Announcement -> SELECT.
- Speak towards the telephone base to record your announcement and press 5 to end recording.

Number of rings

You can set the answering system to answer an incoming call after two, three, four, five or six rings, or toll saver. If you choose toll saver, the answering system answers a call after two rings if you have new messages, or after four rings when there are no new messages.

If you want the built-in answering system instead of the voicemail to answer a call, you should set the answering system to answer a call at least two rings before the voicemail is set to answer. Contact your telephone service provider for information on your voicemail settings.

Using a cordless handset or the telephone base:

- MENU -> ▼ or ▲ -> Answering sys -> SELECT.
- ▼ or ▲ -> Ans sys setup -> SELECT.
- ▼ or ▲ -> # of rings -> SELECT.
- ▼ or ▲ to choose among 2, 3, 4, 5, 6 or Toll saver -> SELECT.

Ringer volume

You can set the ringer volume level to one of the six levels or turn the ringer off.

Using a cordless handset or the telephone base:

- MENU -> ▼ or ▲ -> Ringers -> SELECT.
- SELECT to select Ringer volume.
- ▼ or ▲ to choose the desired level -> SELECT.

Reset language to English

If you have accidentally changed the screen display language and want to switch it back to English, follow the steps below.

- MENU in idle mode -> enter 364#.

Telephone operation

Operation	Steps
Making a call	Using a cordless handset: Press (PHONE or ☎)/ SPEAKER -> Enter the telephone number. Using the telephone base: Press ☎ /SPEAKER -> Enter the telephone number.
On-hook dialing (predialing)	Using a cordless handset: Enter the telephone number -> Press (PHONE or ☎)/ SPEAKER to call. Using the telephone base: Enter the telephone number -> Press ☎ /SPEAKER to call.
Answering a call	Using a cordless handset: Press (PHONE or ☎)/ SPEAKER , or press any dialing keys (0-9 , TONE ✕ or #). Using the telephone base: Press ☎ /SPEAKER, or press any dialing keys (0-9 , TONE ✕ or #).
Ending a call	Using a cordless handset: Press ⏻ OFF or return the handset to the telephone base or charger. Using the telephone base: Press ☎ /SPEAKER.
Handset speakerphone	During a call, press ☎ /SPEAKER to switch between handsfree speakerphone and normal handset use.
Redial	Using a cordless handset: Press REDIAL repeatedly to select the desired entry -> (PHONE or ☎)/SPEAKER to call. Using the telephone base: Press REDIAL repeatedly to select the desired entry -> ☎ /SPEAKER to call.
Volume control	Press VOLUME▼ to decrease or press VOLUME▲ to increase the listening volume during a call.
Call waiting (Requires subscription from telephone service provider)	Press FLASH on the handset or FLASH on the telephone base to put current call on hold and to take the new call; press again to switch back and forth between calls.

Caller ID

This product supports caller ID services offered by most telephone service providers. The telephone stores caller ID information of the last 50 incoming calls in the telephone base. This information is common to all devices.

Missed call indicator
When a handset or the telephone base is in idle mode and has new or missed calls, its screen shows XX Missed calls . You can erase the missed call indicator either by reviewing the call log one by one, or by <u>pressing and holding</u> CANCEL on the handset or CANCEL on the telephone base in idle mode.
Review and dial a number in the call log
1. CID in idle mode -> ▼ or ▲ to scroll through the list. 2. (PHONE or ☎)/SPEAKER on the handset, or ☎ /SPEAKER on the telephone base to call when the desired entry is displayed.
Caller ID announce
When this feature is on and you have an incoming call, the handset and/or base speaks “ <i>Call from...</i> ” and the name of the caller based on the directory or caller ID information. You can turn this feature off for the base or each individual handset, or both. 1. MENU -> ▼ or ▲ -> Settings -> SELECT . 2. ▼ or ▲ -> Caller ID annc -> SELECT . 3. ▼ or ▲ to choose Set all On/Off , Local handset or Base -> SELECT . 4. ▼ or ▲ to choose On or Off -> SELECT .

Call block

If you have subscribed to Caller ID service, you can use the call block feature to reject certain calls automatically. The call block list can store up to 20 entries. This feature is only available on the telephone base.

Operation	Steps
Adding a call block entry	1. MENU -> ▼ or ▲ -> Call block -> SELECT . 2. SELECT to select Block list . 3. ▼ or ▲ -> Add new entry -> SELECT . 4. Enter a telephone number up to 30 digits -> SELECT . 5. Enter a name up to 15 characters -> SELECT .
Blocking calls without number	1. MENU -> ▼ or ▲ -> Call block -> SELECT . 2. ▼ or ▲ -> Calls w/o num -> SELECT . 3. ▼ or ▲ to choose Not block or Block -> SELECT .

Directory

The directory can store up to 50 entries, which are shared by all system devices.

Operation	Steps
Adding an entry	1. MENU -> ▼ or ▲ -> Directory -> SELECT . 2. ▼ or ▲ -> Add contact -> SELECT . 3. Enter a telephone number up to 30 digits -> SELECT . 4. Enter a name up to 15 characters -> SELECT .
Searching/dialing an entry	1. DIR in idle mode. 2. Press ▼ or ▲ to browse through the directory, or press the dialing keys (0-9) to start a name search. 3. Press (PHONE or ☎)/SPEAKER on a handset to call. -OR- Press ☎ /SPEAKER on the telephone base to call.

Answering system

About answering system and voicemail
Your telephone has separate indicators for two different types of voice messages: those left on the built-in answering system and those left at your telephone service provider’s voicemail. To listen to messages recorded on the built-in answering system, refer to the Message playback section below; to listen to voicemail, contact your telephone service provider for more information.
Turn answering system on/off
The answering system must be turned on to answer and record -> messages. Using a cordless handset: 1. MENU . 2. ▼ or ▲ -> Answering sys -> SELECT . 3. ▼ or ▲ -> Answer ON/OFF -> SELECT . 4. ▼ or ▲ to choose On or Off -> SELECT . When the answering system is on, the handset shows ANS ON . Using the telephone base: <ul style="list-style-type: none">Press ⓪/ANS ON/OFF to turn the answering system on or off. If the answering system is turned on, it announces, “<i>Calls will be answered.</i>” If the answering system is turned off, it announces, “<i>Calls will not be answered.</i>”
Message alert tone
When this feature is on, and there is at least one new message, the telephone base beeps every 10 seconds. Using a cordless handset or the telephone base: 1. MENU -> ▼ or ▲ -> Answering sys -> SELECT . 2. ▼ or ▲ -> Ans sys setup -> SELECT . 3. ▼ or ▲ -> Msg alert tone -> SELECT . 4. ▼ or ▲ to choose On or Off -> SELECT .

Answering system (continued)

Call screening																				
Use this feature to choose whether incoming messages can be heard over at telephone base when they are being recorded. If you turn call screening on, you hear the incoming message at the telephone base. While monitoring an incoming message, you can answer the call by pressing (PHONE on the handset or ☎)/SPEAKER on the telephone base. Using a cordless handset or the telephone base: 1. MENU -> ▼ or ▲ -> Answering sys -> SELECT . 2. ▼ or ▲ -> Ans sys setup -> SELECT . 3. SELECT to select Call screening . 4. ▼ or ▲ to choose On or Off -> SELECT .																				
Message playback																				
Using the telephone base: Press ▶/■ /PLAY when the telephone base is in idle mode. Using a handset: Press MENU twice when the handset is in idle mode. Options during playback																				
Feature	On the telephone base	On a handset	Adjust playback volume	Press ▼ /VOLUME/▲	Press ▼ VOLUME or ▲ VOLUME	Stop playback	Press ▶/■ /STOP	Press 5	Skip to the next message	Press ▶▶ /SKIP	Press 6	Repeat the message	Press ◀◀ /REPEAT	Press 4	Play the previous message	Press ◀◀ /REPEAT twice	Press 4 twice	Delete the message	Press X /DELETE	Press DELETE
Feature	On the telephone base	On a handset																		
Adjust playback volume	Press ▼ /VOLUME/▲	Press ▼ VOLUME or ▲ VOLUME																		
Stop playback	Press ▶/■ /STOP	Press 5																		
Skip to the next message	Press ▶▶ /SKIP	Press 6																		
Repeat the message	Press ◀◀ /REPEAT	Press 4																		
Play the previous message	Press ◀◀ /REPEAT twice	Press 4 twice																		
Delete the message	Press X /DELETE	Press DELETE																		

For more detailed instructions, please refer to the Abridged user’s manual provided in your package, or for a full set of installation and operation instructions, refer to the online **CL83114/CL83214/CL83314/CL83364/CL83414/CL83464 DECT 6.0 cordless telephone/answering system with caller ID/call waiting** Complete user’s manual at **www.telephones.att.com/manuals**.

For customer service or product information, visit our website at **www.telephones.att.com** or call **1 (800) 222-3111**. In Canada, dial **1 (866) 288-4268**.