


Caution: Use only the supplied rechargeable battery or replacement battery (model BT183342/BT283342).

 $| \wedge$

Telephone base



base is not in use.

Basic answering system setup via voice quide

You can follow the voice guide to record your own announcement, set the number of rings and set the message alert tone.

Using the telephone base:

- 1. MENU -> ▼ CID or ▲ DIR -> Answering sys -> SELECT.
- 2. ▼ CID or ▲ DIR -> Voice guide -> SELECT.
- 3. Set up the answering system by inputting the designated numbers. as instructed.

Record your own announcement

Your outgoing announcement plays when calls are answered by the answering system. You can use the preset announcement to answer calls, or replace it with your own recorded announcement.

Using a cordless handset or the telephone base:

1. MENU -> ▼ CID or ▲ DIR -> Answering sys -> SELECT.

- 2. SELECT to select Announcement.
- 3. SELECT to select Record annc.
- 4. Speak towards the handset or the telephone base to record your announcement and press 5 to end recording.

Number of rings

You can set the answering system to answer an incoming call after 2, 3, 4, 5, or 6 rings. You can also select toll saver. If you choose toll saver, the answering system answers a call after two rings when you have new messages, and after four rings when there are no new messages. This enables you to check for new messages and avoid paying unnecessary long distance charges if you are calling from out of your local area.

If you want the built-in answering system instead of the voicemail to answer a call, you should set the answering system to answer a call at least two rings before the voicemail is set to answer. Contact your telephone service provider for information on your voicemail settings.

Using a cordless handset or the telephone base:

- 1. MENU -> ▼ CID or ▲ DIR -> Answering sys -> SELECT.
- 2. ▼ CID or ▲ DIR -> Ans sys setup -> SELECT.
- 3. ▼ CID or ▲ DIR -> # of rings -> SELECT.
- 4. **V CID** or **A DIR** to choose among **2**, **3**, **4**, **5**, **6**, or **Toll** saver -> SELECT.

Ringer volume

You can set the ringer volume level to one of the six levels, or turn the ringer off.

Using a cordless handset or the telephone base:

1. MENU -> ▼ CID or ▲ DIR -> Ringers -> SELECT.

- 2. SELECT to select Ringer volume.
- 3. ▼ CID or ▲ DIR to choose the desire level -> SELECT.

Reset language to English

If you have accidentally changed the screen display language and want to switch back to English, follow the step below.

Using a cordless handset or the telephone base:

• MENU in idle mode -> enter 364#.

Note: Set the date/time before using the answering system.

Using a cordless handset or the telephone base:

- 1. MENU -> ▼ CID or ▲ DIR -> Set date/time -> SELECT.
- 2. Enter the month, day and year using the dialing keys ->
- 3. Enter the hour and minute using the dialing keys.
- 4. ▼ CID or ▲ DIR to choose AM or PM -> SELECT.



Operation	Steps
Making a call	Using a cordless handset: Press & PHONE or D/SPEAKER -> Enter the telephone number.
	Using the telephone base: Press ◀୬/SPEAKER -> Enter the telephone number.
On-hook dialing (predialing)	Using a cordless handset: Enter the telephone number -> Press \ PHONE or ↓)/SPEAKER to call. Using the telephone base: Enter the telephone number ->
	Press ()/SPEAKER to call.
Answering a call	Using a cordless handset: Press \ PHONE or \D /SPEAKER, or press any dialing keys (0-9, TONE X or #).
	Using the telephone base:
	Press ()/SPEAKER , or press any dialing keys (0-9, TONE X or #).
Ending a call	Using a cordless handset:
	Press #OFF or return the handset to the telephone base or charger.
	Using the telephone base: Press 4)/SPEAKER.
Handset speakerphone	During a call, press ()/SPEAKER to switch between handsfree speakerphone and normal handset use.
Redial	Using a cordless handset: Press REDIAL repeatedly to select the
	desired entry -> \ PHONE or ∢)∕SPEAKER to call.
	Using the telephone base: Press REDIAL repeatedly to select the desired entry -> ◀》/SPEAKER to call.
Volume control	Using a cordless handset: Press ▼ to decrease or press ▲ to increase the listening volume during a call.
	Using the telephone base: Press VOL ▼ to decrease or press VOL ▲ to increase the listening volume during a call.
Call waiting (Requires subscription from telephone service provider)	Press FLASH on the handset or FLASH on the telephone base to put current call on hold and to take the new call; press again to switch back and forth between calls.

Caller ID

This product supports caller ID services offered by most telephone service providers. The telephone stores caller ID information of the last 50 incoming calls in the telephone base. This information is common to all devices.

Caller ID announce

When this feature is on and you have an incoming call, the handset and/or base speaks "Call from ... " and the name of the caller based on the directory or caller ID information. You can turn this feature off for the base or each individual handset, or both.

Using a cordless handset or the telephone base: 1. MENU -> ▼ CID or ▲ DIR -> Settings -> SELECT.

2. ▼ CID or ▲ DIR -> Caller ID annc -> SELECT.

3. **V CID** or **A DIR** to choose **Set all On/Off**, **Local handset** or Base -> SELECT.

4. ▼ CID or ▲ DIR to choose On or Off -> SELECT.

Review and dial a number in the call log

- 1. CID in idle mode -> ▼ CID or ▲ DIR to scroll through the
- 2. **\PHONE** or **\)/SPEAKER** on the handset or **\)/SPEAKER** on the telephone base to call when the desired entry is displayed.

Erase missed calls indicator in the call log

When the screen shows XX Missed calls, scroll the call log one by one, or press and hold CANCEL on the handset or on the telephone base in idle mode

දිදුරි Directory

The directory can store up to 50 entries, which are shared by all system devices.

Operation	Steps	
Adding an entry	1. MENU -> ▼ CID or ▲ DIR -> Directory -> SELECT.	
	2. ▼CID or ▲ DIR -> Add contact -> SELECT.	
	 Enter a telephone number up to 30 digits -> SELECT. 	
	4. Enter a name up to 15 characters -> SELECT .	
Searching/dialing	1. DIR in idle mode.	
an entry	 Press ▼ CID or ▲ DIR to browse through the directory, or press the dialing keys (0-9) to start a name search. 	
	 Press \PHONE or >/SPEAKER on a handset to call. -OR- 	
	Press 🜒 / SPEAKER on the	

Smart call blocker*

If you have subscribed to caller ID service, then you can use the Smart call blocker feature to filter incoming calls from unknown callers.

Turn Smart call blocker on or off

Smart call blocker is set to on, and to allow all incoming calls by default. To turn on or off Smart call blocker:

CALL BLOCK in idle mode -> SELECT -> ▼ CID or ▲ DIR to choose **On** or **Off** -> **SELECT**.

Call controls

Notes:

cuir corre		
Call ca	ategories	Call control / Set profile options
Welcome calls	 Numbers saved in allow list. Numbers saved in directory. Numbers not found in block list. Caller ID names saved in star name list. 	The telephone allows these calls to get throug and ring.
Unwelcome calls	 Numbers saved in block list. 	The telephone blocks these calls from ringing through.
Unknown calls	Calls without numbers Numbers that are "out of area" or set to "Private".	You can choose one of the following five profile options for handling all unknown calls: Screen unknown The telephone plays the screening announcemer and then ask the caller to say his/her name before the call rings on your telephone. You can then answer the call, and hear the caller's name announced. You can decide whether to accep or reject the call, or to forward the call to the answering system.
	 Uncategorized calls With absent caller ID number. Numbers not found in directory. Numbers not found in allow list. Numbers not found in block list. With caller ID names not found in star name list 	Screen robot The telephone plays the screening announcemer and then ask the caller t press the pound key (#) before the call rings on your telephone. You can then answer the call. Allow unknown (default setting) The telephone allows th calls to get through and ring. Unknown to answering system The telephone forwards the calls to the answerin system without ringing. Block unknown The telephone rejects the calls with block announcement.

Set up allow list, block list and star name list

Add numbers from caller ID log

Adding CID log entry to block list	2. 3.	Press ▼ CID on the handse telephone base -> ▼ CID or Press SELECT when the des appears. ▼ CID or ▲ DIR -> Block lis SELECT twice. Press SELECT again to save
Adding CID log entry to allow list	3.	Press ▼ CID on the handse telephone base -> ▼ CID or Press SELECT when the des appears. ▼ CID or ▲ DIR -> Allow list Press SELECT twice to save
Adding CID log entry to star name list	1. 2. 3.	Press ▼ CID on the handse telephone base -> ▼ CID or Press SELECT when the des appears. ▼ CID or ▲ DIR -> Star nat SELECT twice.

Add numbers manually

nt

Image: Press CALL BLOCK. Very Derrest of the second sec
1. Press CALL BLOCK. 2. ▼ CID or ▲ DIR -> Allow list -> 3. ▼ CID or ▲ DIR -> Add new ent SELECT. 4. Enter a telephone number up to -> SELECT. 5. Enter a name up to 15 characters ->
Image: Press CALL BLOCK. V 2. V CID or ▲ DIR -> Star name list SELECT. 3. V CID or ▲ DIR -> Add new ent SELECT. 4. Enter a name up to 15 characters ->
I. Press CALL BLOCK. V 2. ♥ CID or ▲ DIR -> Stase seto SELECT. tar 3. ♥ CID or ▲ DIR -> Ad SELECT.

Set profile

There are five profile setting options, which allows you to quickly set up Smart call blocker.

- Smart call blocker is on, once you install your telephone. It allows all incoming calls to get through and ring by default. You can change the Smart call blocker settings to screen incoming calls from numbers or names that are not yet saved in your directory, allow list, block list, or star name list. You can easily add incoming phone numbers to your allow list and block list. This allows you to build up your lists of allowed and blocked numbers, and Smart call blocker will know how to deal with these calls when they come in again
- If you turn off Smart call blocker, all incoming calls will ring, including numbers saved in your block list.
- When QUIET mode is on, and Smart call blocker is on and in screening mode, all screened calls will be sent to the answering system after screening.

Set profile	Steps
Screen unknown Screen all unknown calls	 CALL BLOCK -> ▼ CID c -> Set proile -> SELECT. Press SELECT to select S unknown.
Screen robot Screen robocalls	 CALL BLOCK -> ▼ CID c -> Set proile -> SELECT. ▼ CID or ▲ DIR -> Scree -> SELECT.
Allow unknown Block calls on the block list only (default settings)	 CALL BLOCK -> ▼ CID c -> Set proile -> SELECT. ▼ CID or ▲ DIR -> Allow unknown -> SELECT.

* Includes licenced Qaltel[™] technology. Qaltel[™] is a trademark of Truecall Group Limited. et or on r **A** DIR. esired entry

ist ->

et or on or **A DIR**.

esired entry

-> SELECT.

et or on or **A DIR**. esired entry

ame list ->

SELECT. ntry -> 30 digits

> SELECT.

SELECT. ntry ->

30 digits

> SELECT.

list ->

ntry -> -> SELECT.

1. During a call, press CALL BLOCK.

Notes

2. Press SELECT to end the call.

The allow list stores up to 200 entries, the block list stores up to 1,000 entries, and the star name list stores up to 10 names.

pharmacies that use robocalls to communicate important information to you. Robocall uses an autodialer to deliver pre-recorded messages. By entering the name of the organizations into the star name list, it ensures these calls will ring through when you only know the caller names but not their numbers.

Set profile Steps UnknownToAns.S CALL BLOCK -> ▼ CID or ▲ DIR -> Set proile -> SELECT. Forward all VCID or DIR -> unknown calls to the answering UnknownToAns.S -> SELECT. svstem Block unknown CALL BLOCK -> ▼ CID or ▲ DIR -> Set proile -> SELECT. Block all unknowr calls ▼ CID or ▲ DIR -> Block unknown -> SELECT.

Add a screened number to the block list or allow list

If you select Screen unknown or Screen robot in Set

profile, the telephone plays a screening announcement to the caller, and asks the caller to respond before the call rings through to you. After the caller responds, the telephone rings and you can then pick up the call. The telephone then asks whether you want to answer or reject the call, or to forward the call to the answering system. The telephone announces "To answer the call, press 1. To answer and always allow this number, press 2. To block this number, press 3. To send this call to the answering system, press 4. To repeat these options, press *".

You can add a screened number to the block list or to the allow list.

	Add current number to the allow list	Þ	Press 2 to answer the call, and add the current number to the allow list.
	Add current number to the block list	Þ	Press 3 to block the call, and add the current number to the block list.
-	Notes		

- > Unknown calls without caller ID information will not have the option 2, "answer and always allow this number", and option 3, "to block this number". No number will be added to the allow list or block list for these calls
- If you do not want to take the call, press JOFF to end the call.



About answering system and voicemail

Your telephone has separate indicators for two different types of voice messages: those left on the built-in answering system and those left at your telephone service provider's voicemail. To listen to messages recorded on the built-in answering system, refer to the Message playback section; to listen to voicemail, contact your telephone service provider for more information.

Turn answering system on or off

The answering system must be turned on to answer and record messages.

Using a cordless handset:

- 1. MENU -> ▼ CID or ▲ DIR -> Answering sys -> SELECT.
- ▼ CID or ▲ DIR -> Answer ON/OFF -> SELECT.
- 3. ▼ CID or ▲ DIR to choose On or Off-> SELECT.

When the answering system is on, the handset shows ANS ON.

Using the telephone base:

Press **U/ANSWER ON** to turn the answering system on or off. If the answering system is turned on, it announces, "Calls will be answered." If the answering system is turned off, it announces, "Calls will not be answered."

Message alert tone

When this feature is on, and there is at least one new message, the telephone base beeps every 10 seconds.

Using a cordless handset or the telephone base:

- 1. MENU -> ▼ CID or ▲ DIR -> Answering sys -> SELECT
- 2. VCID or ADIR -> Ans sys setup -> SELECT.
- 3. ▼ CID or ▲ DIR -> Msg alert tone -> SELECT.
- 4. ▼ CID or ▲ DIR to choose On or Off -> SELECT.

Call screening

Use this feature to choose whether incoming messages can be heard over at the telephone base when they are being recorded. If you turn call screening on, you hear the incoming message at the telephone base. While monitoring an incoming message, you can answer the call by pressing **\PHONE** on the handset or **\)/SPEAKER** on the telephone

Using a cordless handset or the telephone base:

- 1. MENU -> ▼ CID or ▲ DIR -> Answering sys -> SELECT.
- 2. ▼ CID or ▲ DIR -> Ans sys setup -> SELECT.
- 3. SELECT to select Call screening.
- 4. ▼ CID or ▲ DIR to choose On or Off -> SELECT

Message playback

Using the telephone base:

Press ///PLAY when the telephone base is in idle mode.

Using a cordless handset:

> Press MENU twice when the handset is in idle mode. Options during playback

	0	
Feature	On the telephone base	On a handset
Adjust playback to volume	Press VOL / A VOL	Press VCID or DIR
Stop playback	Press >/ //STOP	Press 5
Skip to the next message	Press >>/SKIP	Press 6
Repeat the message	Press «/REPEAT	Press 4
Play the previous message	Press 4/REPEAT twice	Press 4 twice
Delete the message	Press DELETE	Press DELETE

For more detailed instructions, please refer to the Abridged user's manual provided in your package, or for a full set of installation and operation instructions, refer to the online CL83519 DECT 6.0 cordless telephone/ answering system with caller ID/call waiting Complete user's manual at www.telephones.att.com/manuals.

For customer service or product information, visit our website at www.telephones.att.com or call 1 (800) 222-3111. In Canada, dial 1 (866) 288-4268.

or **A DIR** Screen

or **A DIR** en robot

or **A DIR** w



announcement and add the number to the block list.

Option while on a call When you are on a call and speaking to the caller, and you do not want to continue the call, you can end the call with block